



FRAMING CONFIGURATION – Common Settings – Configuration Settings

Modified on: Sat, 9 Jan, 2021 at 8:12 PM


Framing Configuration may be found in two locations:



OR:



Configuration Settings



Use for all Vertical/Horizontal Framing Elements (except Openings) – if ON, then the selected Joist and Rim Joist families will be used for other framing elements, like connections, bridgings, noggings, etc. without an option to change it to a custom family.

Main Type of Joists (or Rim Joists) – pick a family and type for the Joist or Rim Joist.

Sample joist and rim joist families that come with **Roof+**:

Metric Joist – [M_RWF Common Joist.rfa](#)

Metric Rim Joist – [M_RWF Rim-Bridging Joist.rfa](#)

Imperial Joist – [I_RWF Common Joist.rfa](#)

Imperial Rim Joist – [I_RWF Rim-Bridging Joist.rfa](#)

Do not use any other families!

You can use other families only in special cases. Contact us support@agacad.com

Width (b) – shows the width, b, parameter value of the selected family type.

Depth (h, d) – shows the depth, h or d, parameter value of the selected family type.

Define Depth (h, d) by Layer Thickness – the software will create a new type for the selected family and change the depth value to the roof layer thickness so that the frames will fit the layer in the wall.

Roof Frame Panels – if ON, then roof frames are assembled in factory; if OFF – assembled on-site.