



FRAMING CONFIGURATION – Opening Framing – General

Modified on: Sun, 10 Jan, 2021 at 5:16 PM

Framing Configuration may be found in two locations:



OR:



Opening Framing

Window Framing | Opening Framing | Window - Window Join Framing

Edit Configurations

Non-structural Roofs. Width of Openings:

From	To	Configuration	Preassembled	Opening Element Preassembled
0	10000	M_Window Non-bearing Framing	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Edit Configurations

Structural Roofs. Width of Openings:

From	To	Configuration	Preassembled	Opening Element Preassembled
0	10000	M_Window Bearing Framing	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Settings for framing **Windows** and other **Openings**.

Settings for **Window – Window Join Framing**.

Window, or Opening settings are saved under separate names and can be adjusted for different opening sizes (From – To).

Also, the software will recognize if the opening is inserted into a structural (bearing) or non-structural roof.

Window Framing

Window Framing | Opening Framing | Window - Window Join Framing

Edit Configurations

Non-structural Roofs. Width of Openings:


From	To	Configuration	Preassembled	Opening Element Preassembled
0	10000	M_Window Non-bearing Framing	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Edit Configurations






Structural Roofs. Width of Openings:

From	To	Configuration	Preassembled	Opening Element Preassembled
0	10000	M_Window Bearing Framing	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Window Framing – settings for framing single windows.



Opening Framing

-  Common Settings
-  Roof Common Joists
-  Opening Framing
-  End Connection
-  Edge Joist

Opening Framing
Window Framing
Window - Window Join Framing

✖ Edit Configurations

Non-structural Roofs. Width of Openings:


From	To	Configuration	Preassembled	Opening Element Preassembled
0	10000	M_Opening Non-bearing Framing	<input type="checkbox"/>	<input type="checkbox"/>

✖ Edit Configurations

Structural Roofs. Width of Openings:

From	To	Configuration	Preassembled	Opening Element Preassembled
0	10000	M_Opening Bearing Framing	<input type="checkbox"/>	<input type="checkbox"/>

Opening Framing – settings for framing single openings which are mostly used for Ducts, Pipes, or other MEP elements.



Window – Window Join Framing

- Common Settings
- Roof Common Joists
- Opening Framing
- End Connection
- Edge Joist

Window Framing | Opening Framing | **Window - Window Join Framing**

Edit Configurations

Non-structural Roofs. Width of Join:


From	To	Configuration	Preassembled	Opening Element Preassembled
0	100	M_Window - Window Join Non-b	<input type="checkbox"/>	<input type="checkbox"/>

Edit Configurations

Structural Roofs. Width of Join:

From	To	Configuration	Preassembled	Opening Element Preassembled
0	100	M_Window - Window Join Bearing	<input type="checkbox"/>	<input type="checkbox"/>


Window – Window Join Framing – settings for framing joined windows. Window – window join settings are saved under a separate name and they can be adjusted for different join sizes (From – To).



Preassembling

Preassembled – fills in information for the framing elements (like trimming joists, headers, etc.) from the selected configuration. The configuration can later be scheduled and separately displayed in shop drawings.

Opening Element Preassembled – fills in information for the opening, which can be later scheduled and separately displayed in shop drawings.




Fills information into these parameters:

FM Module Type – writes opening type name.

FM Module Mark – writes **FM Module Type** + **Mark** (from Roof) + **Mark** (from Opening) + unique number.

FM Module Preassembled – writes Yes/No if element is (or is not) included in the preassembly.

Example:



All these parameters can later be used in the schedules and view filters.