


EXPORT SETUP

Modified on: Sun, 1 Aug, 2021 at 11:09 AM



Export Setup – settings where you can define CNC file locations, project information parameters, identification and marking of elements, CNC command naming, etc.

Configuration

EasyFrame Exporter. Export Setup

Configuration : Default Configuration Save Duplicate Rename Delete

Common Settings

Location for export of CNC files

Project file location
 Custom location

Custom location:

Project Information Parameters

Project Name:

Object Number:

Element Identification and Mark

Automatically skip not marked Elements
 Automatically skip filtered out Elements

Assembly Station Mode

Export as one file

Configuration – configuration with export settings. You can use sample or create new configurations. Also, you can rename or delete the existing configurations.

By default, **CNC Exporter** configurations are saved in *C:\Users\user name\AppData\Roaming\Tools 4 Revit\EFWood22 (or other Revit version)\Export Configuration* catalog. The content from this catalog can be copied to other users' computers if needed. The path can be changed in **CNC Exporter – Easy Frame** → **Configuration Files' Location**.


Configuration Files' Location [-] [□] [×]

Select where to store configuration files

- Personal Configurations**
C:\Users\Renata\AppData\Roaming\Tools 4 Revit\EFEWood22\Export Configuration [Browse...]
- Shared Company Configurations**
[] [Browse...]
- Shared Company Project I**
[] [Browse...]
- Shared Company Project II**
[] [Browse...]
- Shared Company Project III**
[] [Browse...]
- Shared Company Project IV**
[] [Browse...]
- Shared Company Project V**
[] [Browse...]
- Shared Company Project VI**
[] [Browse...]

[Save]

Location for export of CNC files



Common Settings

Common Settings

Location for export of CNC files

Project file location

Custom location

Custom location

C:\Users\Renata\AppData\Roaming\Tools 4 Revit\EFEWood22

Project Information Parameters

Project Name:

Object Number:

Element Identification and Mark

Default Configuration

Automatically skip not marked Elements


Automatically skip filtered out Elements

Assembly Station Mode


Export as one file

Location for export of CNC files – select where to export CNC files. It can be project file location or any other custom location.

Project Information Parameters




Project Information Parameters – define parameters to take values of project name and project number. These parameters comes from **Revit** → **Manage** → **Project Information**:





Result in exported EZF file.

Element Identification and Mark




Element Identification and Mark – select element identification and marking configuration. This goes to advanced settings where you can predefine marking for plates/rims joists, girders, studs, joists and columns. Also you can make special element filtering.



[Read more about every advanced feature here >>](#)


[.https://helpdesk.agacad.com/support/solutions/articles/44002243445-advanced-setup](https://helpdesk.agacad.com/support/solutions/articles/44002243445-advanced-setup)

Automatically skip not marked Elements



Automatically skip not marked Elements – automatically skips elements if **CNC Part Number** parameter is empty. If this option is switched OFF then the product will show a warning message with information about missing value.

Such element is not exported in EZF file:



Automatically skip filtered out Elements

Element Identification and Mark

Default Configuration

Automatically skip not marked Elements

Automatically skip filtered out Elements

Automatically skip filtered out Elements – automatically skips filtered out element from configuration.

Configuration : Default Configuration

Frame

Plates/Rim Joists/Girders

Studs/Joists/Columns

Element Filtering

Element Filtering

Filter by :

FM Module Mark : Instance Shared

equals

Joists

And

(

Filter by :

None

none

And


Filter by :

None

none

)

Assembly Station Mode



The screenshot shows the 'Common Settings' tab of the AGACAD Export Setup dialog. The 'Assembly Station Mode' section is highlighted with a red border, containing the 'Export as one file' checkbox.

Common Settings

Location for export of CNC files

- Project file location
- Custom location

Custom location:

Project Information Parameters

Project Name:

Object Number:

Element Identification and Mark

Default Configuration


- Automatically skip not marked Elements
- Automatically skip filtered out Elements

Assembly Station Mode

Export as one file


Assembly Station Mode – select if export has to be in one file or in separate files for each wall/floor/roof panel.

Framing Elements




Framing Elements – Easy Frame CNC Exporter exports only main frame of wall, floor, roof.

Export Frames




Order Hosts by – possibility to order hosts by ID or Mark.

Export File Name




Export File Name – predefine rules for defining file name. Some of parameters comes from **Revit** → **Manage** → **Project Information**:



*Example, exported file name consists **Author** and **Project Name** parameter values from **Project Information**:*

Name



 AGACAD-Hotel CNC.ezf

