

# **IDEA RCS 6**

## **Reinforced Concrete Section**

User guide

## Content:

1	Getting started .....	10
1.1	System requirements .....	10
1.2	Installation .....	10
2	Terminology .....	11
2.1	Section .....	11
2.2	Loads extreme .....	12
2.3	Design Member .....	12
2.4	Reinforced section .....	12
3	User interface .....	13
3.1	Control of view in the Main window .....	13
3.1.1	DXF export settings .....	14
3.2	Table editor .....	14
4	Starting new project .....	16
4.1	Project data and default values setting .....	18
5	Working with sections .....	20
5.1	Ribbon group Set .....	21
5.2	Ribbon group Import .....	21
5.3	Ribbon group Section .....	23
5.3.1	New section input .....	23
5.4	Ribbon group Extreme .....	23
5.4.1	Editing load extremes using table editor .....	24
5.5	Ribbon group Design Member .....	25
5.5.1	New design member input .....	25
5.6	Ribbon group Reinforced cross-section .....	27
5.6.1	New Reinforced cross-section .....	27
5.6.2	Copy of reinforced section .....	27
5.6.3	Copy of reinforcement .....	27
5.7	Ribbon group Calculation .....	29
5.8	Ribbon group Report .....	29
5.8.1	Global report setting .....	30
6	Design members .....	32
6.1	Design member data common to all members .....	33
6.2	Compression member data .....	34
6.3	Data for Flexural slenderness calculation .....	35
6.3.1	Ribbon group Design member .....	35

7 Reinforced cross-sections.....	36
7.1 Ribbon group Reinforced cross-section .....	36
8 Cross-section shape .....	37
8.1 Input of new cross-section.....	37
8.2 General cross-sections.....	38
8.3 Cross-section dimensions input.....	38
8.4 Input of general section by coordinates of vertexes .....	39
8.4.1 Input of openings into general cross-section.....	39
8.4.2 New general opening.....	40
8.4.3 New rectangular opening .....	41
8.4.4 New circular opening .....	43
8.4.5 Shift origin of general cross-section.....	45
8.5 Dimension line of cross-section shape .....	45
8.6 Cross-sectional shape modifications .....	46
8.6.1 Composite cross-section modification .....	46
9 Prestressing reinforcement .....	48
9.1 Ribbon group Tendons .....	48
9.2 New layer of tendons defined by coordinates .....	49
9.3 New layer of tendons on edge .....	51
9.4 Editing tendons.....	53
9.5 Exploding tendon layer .....	54
9.6 Ribbon group Tendon ducts .....	54
9.7 New layer of tendon ducts defined by coordinates .....	55
9.8 New layer of tendon ducts on edge .....	57
9.9 Editing tendon ducts.....	59
9.10 Exploding tendon duct layer .....	59
9.11 Deleting prestressing reinforcement.....	59
9.12 Numbering of cross-section points.....	59
10 Construction and action stages .....	60
10.1 Construction stages .....	60
10.1.1 Ribbon group Time axis points .....	61
10.1.2 Ribbon group Time axis label .....	61
10.1.3 Ribbon group Cross-section .....	61
10.2 Action stages .....	63
10.2.1 Effect in cross-section components.....	64
10.2.2 Ribbon group Recalculation of losses .....	64

10.2.3 Ribbon group Resultant of stage .....	65
11 Load effects input.....	66
11.1 1D section internal forces.....	66
11.2 2D Section internal forces .....	68
11.2.1 Ribbon group Recalculation of design forces .....	69
11.3 Second order effects .....	70
11.3.1 Ribbon group Recalculation of internal forces .....	71
11.4 Load effects on staged sections .....	72
11.4.1 Taking load actions from action stages .....	73
11.4.2 Ribbon group Stage resultant .....	73
12 Concrete reinforcement .....	74
12.1 Concrete reinforcement of 1D members .....	75
12.1.1 Editing cover of 1D sections .....	75
12.1.2 Input of 1D members reinforcement by template .....	76
12.1.3 Input of one-way slabs reinforcement by a template .....	78
12.1.4 Reinforcement design.....	79
12.1.5 Shear reinforcement of 1D members .....	80
12.1.6 User settings of reinforced cross-section .....	88
12.1.7 Longitudinal reinforcement.....	91
12.2 2D members reinforcement.....	104
12.2.1 Input of 2D members reinforcement by a template.....	104
12.2.2 Input of new bars for 2D member cross-sections.....	105
12.2.3 Editing 2D members longitudinal reinforcement.....	106
12.2.4 Shear reinforcement of 2D members .....	107
12.3 User defined reinforcement templates.....	109
12.3.1 Reinforcing by user defined reinforcement template .....	109
12.3.2 Templates manager .....	110
12.4 Deleting reinforcement.....	112
12.5 Import of reinforced cross-section .....	112
12.6 Export of reinforced cross-section .....	112
12.7 Numbering of cross-section points.....	112
12.8 Dimensioning of reinforced cross-section.....	112
13 Check results .....	114
13.1 Setting of Check execution of 1D members.....	114
13.2 Setting of Check execution of 2D members.....	115
13.3 Setting the evaluated combination .....	115

13.4 Setting of the checked direction for 2D members section checks.....	116
13.5 Overall check.....	117
13.5.1 Ribbon group Component labels.....	118
13.6 Ultimate limit state checks .....	119
13.7 Section Capacity check .....	120
13.7.1 Ribbon group Type of results.....	120
13.7.2 Ribbon group Combinations .....	121
13.7.3 Ribbon group Checked directions .....	121
13.7.4 Ribbon group Diagram type.....	121
13.7.5 Ribbon group Interaction surface sections .....	121
13.7.6 Ribbon group Draw points .....	121
13.7.7 Grid of interaction surface sections.....	121
13.7.8 Ribbon group Export of interaction diagram .....	122
13.7.9 Ribbon group Drawing settings.....	122
13.7.10 Ribbon group Colors settings.....	122
13.8 Shear check .....	123
13.8.1 Ribbon group Combinations .....	123
13.8.2 Ribbon group Code and calculation settings.....	123
13.8.3 Ribbon group Resistance area .....	123
13.9 Torsion check .....	124
13.9.1 Ribbon group Combinations .....	124
13.9.2 Ribbon group Code and calculation settings.....	124
13.10 Interaction check of shear, torsion, bending and normal force .....	125
13.10.1 Ribbon group Combinations .....	125
13.10.1 Ribbon group Code and calculation settings.....	125
13.10.2 Ribbon group View .....	125
13.10.3 Ribbon group View setting .....	125
13.10.4 Ribbon group Checked directions .....	125
13.10.5 Ribbon group Strain .....	125
13.10.6 Ribbon group Stress .....	126
13.10.7 Ribbon group Results label .....	126
13.10.8 Ribbon group Results graph.....	126
13.10.9 Ribbon group Resultant forces .....	127
13.10.10 Ribbon group Cross-section.....	127
13.10.11 Ribbon group Type of results.....	128
13.10.12 Check by Stress-strain diagram.....	129

---

13.11 Fatigue check.....	131
13.11.1 Ribbon group View .....	131
13.11.2 Ribbon group View setting .....	131
13.11.3 Ribbon group checked directions .....	131
13.11.4 Ribbon group Strain .....	131
13.11.5 Ribbon group Stress .....	131
13.11.6 Ribbon group Results label .....	131
13.11.7 Ribbon group Results graph .....	131
13.11.8 Ribbon group Resultant forces .....	131
13.11.9 Ribbon group Cross-section .....	131
13.11.10 Ribbon group Type of results .....	131
13.11.11 Ribbon group Fatigue combination .....	131
13.12 Serviceability limit state (SLS) .....	132
13.13 Stress limitation check .....	133
13.13.1 Ribbon group View .....	133
13.13.2 Ribbon group View setting .....	133
13.13.3 Ribbon group checked directions .....	133
13.13.4 Ribbon group Strain .....	133
13.13.5 Ribbon group Stress .....	133
13.13.6 Ribbon group Results label .....	133
13.13.7 Ribbon group Results graph .....	133
13.13.8 Ribbon group Results .....	133
13.13.9 Ribbon group Cross-section .....	133
13.13.10 Ribbon group Stiffness .....	134
13.13.11 Ribbon group Type of results .....	134
13.14 Crack width check .....	135
13.14.1 Ribbon group View .....	135
13.14.2 Ribbon group checked directions .....	135
13.14.3 Ribbon group View setting .....	135
13.14.4 Ribbon group Strain .....	135
13.14.5 Ribbon group Stress .....	135
13.14.6 Ribbon group Results label .....	135
13.14.7 Ribbon group Results graph .....	135
13.14.8 Ribbon group Results .....	135
13.14.9 Ribbon group Cross-section .....	135
13.14.10 Ribbon group Type of results .....	135

13.14.11 Ribbon group Stiffness .....	135
13.14.12 Ribbon group Crack .....	136
13.15 Flexural slenderness check .....	137
13.16 Brittle failure check .....	138
13.17 Detailing check .....	139
13.18 Advanced analysis .....	140
13.19 Response check .....	141
13.19.1 Ribbon group Combinations .....	141
13.19.2 Ribbon group View .....	141
13.19.3 Ribbon group View setting .....	141
13.19.4 Ribbon group checked directions .....	141
13.19.5 Ribbon group Strain .....	141
13.19.6 Ribbon group Stress .....	141
13.19.7 Ribbon group Results label .....	141
13.19.8 Ribbon group Results graph .....	141
13.19.9 Ribbon group Resultant forces .....	141
13.19.10 Ribbon group Cross-section .....	141
13.19.11 Ribbon group Type of results .....	141
13.20 Stiffness calculation .....	142
13.20.1 Ribbon group View .....	142
13.20.2 Ribbon group View setting .....	142
13.20.3 Ribbon group Strain .....	142
13.20.4 Ribbon group Stress .....	142
13.20.5 Ribbon group Results label .....	142
13.20.6 Ribbon group Results graph .....	142
13.20.7 Ribbon group Results .....	142
13.20.8 Ribbon group Cross-section .....	142
13.20.9 Ribbon group Stiffness .....	142
13.20.10 Ribbon group Type of results .....	142
13.21 Calculation of M-N- $\kappa$ diagram .....	143
13.21.1 Ribbon group View .....	143
13.21.2 Ribbon group M-N- $\kappa$ .....	143
13.21.3 Ribbon group View setting .....	143
13.21.4 Ribbon group Strain .....	143
13.21.5 Ribbon group Stress .....	143
13.21.6 Ribbon group Results label .....	143

---

13.21.7 Ribbon group Results graph .....	144
13.21.8 Ribbon group Results .....	144
13.21.9 Ribbon group Cross-section .....	144
14 Report for the current section .....	145
14.1 Report setting .....	145
14.1.1 Group Data .....	146
14.1.2 Group checks .....	146
14.1.3 Group Setting .....	146
14.1.4 Detailed report setting for check chapters .....	147
14.2 Standard report .....	148
14.3 Detailed report .....	149
15 Code and calculation settings .....	150
16 Application setting .....	153
16.1 Units setting .....	153
16.2 Application global settings .....	154
16.2.1 Results display settings .....	154
16.2.2 Reinforcement display settings .....	155
16.2.3 Cross-section display setting .....	156
16.2.4 Text height settings .....	156
16.2.5 Miscellaneous .....	157
17 Format of text files for import and export .....	158
17.1 File TXT .....	158
17.2 File .NAV .....	159
17.3 Import from XML file .....	162
17.3.1 Chapter Cross-sections .....	163
17.3.2 Chapter Materials .....	169
17.3.3 Chapter Members 1D .....	170
17.3.4 Chapter Haunches .....	171
17.3.5 Arbitrary members .....	171
17.3.6 2D members .....	172
17.3.7 Load cases .....	172
17.3.8 Combinations .....	172
17.3.9 Named selections .....	172
17.3.10 General rules used when converting internal forces to loads extremes in IDEA RCS .....	173
17.3.11 Internal forces on members .....	175
17.3.12 Member 2D – internal forces .....	175





## 1 Getting started

### 1.1 System requirements

.NET Framework 4 needs to be installed on a computer to provide the optimal functioning of this application – you can download it from the Microsoft website:

<http://www.microsoft.com/downloads/details.aspx?displaylang=en&FamilyID=0a391abd-25c1-4fc0-919f-b21f31ab88b7>

In case of a missing .NET Framework 4 the installation is not launched.

### 1.2 Installation

Administrator rights are required for an adequate installation.

## 2 Terminology

IDEA RCS is a software for the calculation of reinforced concrete section checks according to EN 1992-1-1 and 1992-2 with or without a national application document and for the calculation of reinforced concrete section checks according to SIA 262:2003.

It is a standalone application used in addition to a standard static analysis.

IDEA RCS can be used in two modes:

- As a standalone application in addition to a standard static analysis. Cross-sections, reinforcement and load effects have to be entered by user.
- As a module linked to superior application. Cross-sections and load effects or prestressing reinforcement are generated from superior application. In this mode not all functionality may be available as in standalone application. Data for standalone IDEA RCS application can be exported from IDEA RCS running as a module.

Program can perform checks for:

- Concrete member sections with longitudinal, torsional and shear reinforcement for Ultimate limit state Design (ULS) and Serviceability Limit State Design (SLS) with an optional function to calculate the long or short term stiffness of (cracked) cross-section for deflection verification. Moreover, a detailed response check for user defined internal forces is available as well as a possibility to analyze the interaction of all internal forces including shear and torsional forces. A set of practical cross-section like T-, L-, Rectangular, Circular or O-shaped cross-section can be used as well as a free form cross-section (so called 'general cross-section')
- Concrete slab sections in a defined point for one-way, two-way slabs, walls or deep beams for Ultimate limit state Design (ULS) and Serviceability Limit State Design (SLS). Moreover, a detailing response check and check of the crack width is available.
- Prestressing can be applied into cross-sections of beams either using pre-tensioned tendons or using post-tensioned tendons.

### 2.1 Section

The application works with individual sections. The section is defined with relation to specific member data and reinforcement data (configurations).

One or more sets of loads effects (loads extremes) are assigned to each section.

One IDEA RCS project can contain multiple sections with multiple members, reinforcement configurations and load effects.

The application works for types of sections

- **1D member sections.** For a 1D member section only the member data and the load effects of 1D members can be specified. Cross-sections can be reinforced with reinforcement or tendons. Tendons are taken into account as reinforcement – effects of prestressing are not taken into account.
- **2D member sections.** For a 2D member section only the member data and load effects of 2D members can be specified.
- **1D staged member sections.** For a 1D staged member section data and staged load effects of 1D member can be specified. Cross-sections can be reinforced with reinforcement or tendons. Effects of prestressing in tendons are taken into account.

## 2.2 Loads extreme

Loads extreme is a set of combinations of internal forces, specifically one combination for Ultimate Limit States and three for Serviceability Limit States (Characteristic, Frequent, Quasi-permanent).

More loads extremes can be assigned to one section. When check of single section is performed, reinforced section is checked only for current loads extreme. When summary check of all sections is performed, each section is checked for all loads extremes assigned to section.

## 2.3 Design Member

The design member data defines the information about the whole element (type, exposure class, creep coefficient, etc.) for which a specified section is being checked. User defined design member data can be assigned to multiple sections. Any change in the design member data is reflected in all related sections, which are assigned to the design member, for which data is edited.


## 2.4 Reinforced section

The reinforced section defines the information about reinforcement configuration: section geometry, longitudinal reinforcement, shear reinforcement, applied cover(s) and reinforcement materials. User defined Reinforced section configuration can be assigned to multiple sections. Any change in the Reinforced section data is reflected in all sections with the assigned Reinforced section data.

## 3 User interface

The user interface consists of the following parts:.

- Navigator – set of commands logically ordered, starting first from the input, through the check options to output and reporting.
- Ribbon groups – shows commands related to the current navigator command.
- Main window – shows the image, diagram or text dialog related to the current navigator command.
- Data window – shows the info related to the current navigator command, or the selected object in the Main window, with different tables or properties.
- Information window – actual information related to project are shown for quick user reference



### 3.1 Control of view in the Main window

The view in 2D window can be set by mouse or by tool in the left upper corner of the window.



- zoom all. Click this button to fit the whole structure to the 2D window.

To set the required view using keyboard and mouse following combinations can be used:


- Click and hold mid mouse button – moving the mouse pans the view.
- Roll with mid mouse button – moving the mouse increases/decreases the view.

- Push CTRL+SHIFT and hold mid mouse button – moving the mouse defines the window for zoom.

Click on right mouse button over 2D window shows context menu with following commands:

- **Zoom all** – zoom to show the whole current structure in the 2D window.
- **Print** – start printing of the current content of 2D window on selected printer.
- **To bitmap** – start export of the current content of 2D window to the raster graphics file (PNG, GIF, BMP, JPEG, TIFF).
- **To clipboard** – copy of the current content of 2D window to the Windows clipboard.
- **To DXF** – start export of the current content of 2D window to the 2D DXF file.

### 3.1.1 DXF export settings



Following export parameters can be set in the Save as dialog when exporting the view to the 2D file:

- **Scale** – if the option is selected, the scale ratio used to create the drawing in exported DXF can be set.
- **Output units** – select units of the drawing in the exported DXF file.
- **Layers** – select the mode of layers generation. Layers can be generated according to the line type, the line thickness, the entity type or the entity color.
- **Fill regions** – switch on/off export of filled regions (otherwise only outlines are exported).
- **Dimensions** – switch on/off export of dimension lines.

## 3.2 Table editor

Some input data (vertexes of general cross-sections, values of internal forces etc.) can be entered using table editor.

Copy to clipboard and paste from clipboard can be used to enter the value to single cell or to fill the range of cells (using shortcuts CTRL-C (CTRL-INS) and CTRL-V (SHIFT-INS)).

	Y [mm]	Z [mm]
1	-750	537
2	-750	357
3	-110	297
4	-110	-713
5	-225	-743
6	-225	-963
7	225	-963
8	225	-743
9	110	-713
10	110	297
11	750	357
12	750	537
*		

- Cells (ranges) can be pasted to the table from the Microsoft Excel table
- When pasting the data to the table the data are inserted to the current position in the table.
- If the number of columns in the clipboard is greater than the number of columns in the target table, the redundant columns are ignored.
- If the number of rows in the clipboard is greater than one, the rows following the current row in the target table are overwritten. If the number of inserted rows is greater than the number of rows in the target table, the required number of new rows is inserted to the target table

- If a range is selected in the target table and the clipboard contains only value of one cell, all cells in the selected range are filled with the same value when pasting from the clipboard.
- To add a new row to the table click cell \* in the indexes column or use the keyboard shortcut **CTRL + ENTER** (the last row of the table must be set as current row)


Following keyboard shortcuts can be used when working with the table editor:

- **CTRL + +** - insert a row before the current row.
- **CTRL + ENTER** - append a row to the current row.
- **CTRL + -** - delete the current row.
- **CTRL + A** - select the whole table
- **CTRL + C (CTRL + INS)** – copy the selected cells to the clipboard.
- **CTRL + V (SHIFT + INS)** – paste the clipboard content to the table
- **TAB** – change the current cell by moving forwards through the cells
- **SHIFT + TAB** – change the current cell by moving backwards through the cells
- **<, >, ^, v** - change the current cell by moving left, right, up, down
- **F2** – switch to edit mode of the cell and place the cursor to the end of the current cell. Move to the other cell to finish the edit mode with preserving the changes or push **ESC** to discard the changes.
- **ESC** – close the edit mode discarding the changes.

## 4 Starting new project

- **If IDEA RCS is started from superior application, creating a new project is not available.**

A short-cut has been placed on the desktop automatically during the installation. Double click the short-cut to launch the program. The user can **Create a new project** or **Open an existing project** from the list of recently opened projects.



Click **Create new project** to display the dialog for definition of the initial project parameters and initial member type.



**T**
Project data
✕

Project Name  
--- Not Defined ---

Project Description

Author  
--- Not Defined ---

Project No.

Date  
2. července 2015 15

**National Code**

Code	NA	<input checked="" type="checkbox"/> EN 1992-1-1
EN	EN	<input type="checkbox"/> 1992-2
		<input type="checkbox"/> 1992-3
		<input type="checkbox"/> Fatigue

Design Working Life  
50 years

Default Exposure Classes

<input type="checkbox"/> No corrosion (X0)	<input checked="" type="checkbox"/> Carbonation XC3	<input checked="" type="checkbox"/> Chlorides XD1
<input type="checkbox"/> Chlorides from sea XS1	<input type="checkbox"/> Freeze/Thaw Attack XF1	<input type="checkbox"/> Chemical Attack XA1

Default Concrete Class  
C30/37

Default Reinforcement Steel Grade  
B 500B

Default Prestressing Steel Grade  
Y1860S7-15.7

**Section type of first input section**

**Member type of first input section**

Create in-plane loaded slab, this member takes all force components into account, detailing rules are applied as for slabs

OK

After defining the required default values, choosing the proper member type and clicking **OK**, a new project with the proper member and section is created. The selected section is set as current section – see list **Current section** in Navigator.

## 4.1 Project data and default values setting

To change project data and choose default materials click **Project data** in ribbon group **Settings**. Dialog **Project data** appears with project details and table National code. Project identification data are available in the header.

- **Code** – click to set current code to EC-EN or to load user defined settings of code parameters.
- **NA** – click to load one of available National Annex parameter sets.
- **EN 1992-2** – switch on/off option to check a cross-section according to code EN 1992-2. If EN 1992-2 is selected, data for flexural slenderness check cannot be entered and flexural slenderness check cannot be performed.
- **EN 1992-3** – switch on/off check of cross-sections according to EN 1992-3 Liquid retaining and containment structures.
- **Fatigue** – switch on/off the availability to input fatigue load combinations and to perform the fatigue check.

- **Annex NN** - switch on/off the fatigue check according to the Annex NN. This option is available only if the national code EN 1992-2 is selected.
- **Design working life** – (list-box) setting for value of the Design working life.
- **Exposure classes** – (check-boxes) setting for new members. The Exposure class influences the available materials of concrete and reinforcement
- **Default concrete class** – (list-box) the default concrete grade from the displayed list is assigned to newly input reinforced sections.
- **Default reinforcement steel grade** – (list-box) the default reinforcement grade from the displayed list is assigned to newly entered reinforcement bars and stirrups
- **Default prestressing steel grade** – (list-box) the default prestressing reinforcement grade from the displayed list is assigned to newly input prestressing tendons.

## 5 Working with sections

Click navigator command **Project data > Sections** to open the dialog with all defined sections in the current project

In the Main dialog window, sections are arranged as they are created (minimally one section is always available).

The list of loads extremes assigned to the current section is displayed in Data window.

	Section Name	Section Type	Design Member	Member Type	Reinforced Cross-Section	Va
1	S 1	Staged	M 1	Beam	R 1	
2	S 2	Reinforced	M 2	Slab	R 2	

Data					
	Extreme Name	Time [d]	Value	Result Status	
1	S 1 - E 1	18250,0	250,0	✘	
2	S 1 - E 2	28,0	0,0	?	

In the Main dialog window it is possible to rename a section in the column **Section name**. In the columns **Design Member** and **Reinforced Cross-section** the appropriate design member data or reinforced cross-section from lists of available member data/reinforced cross-sections in project can be assigned.

If the section is already calculated, the maximum unity check value from all possible checks for all loads extremes is displayed in column **Value**. In the column **Status** the actual check status (OK/NOT OK) is displayed.


Name of loads extreme can be changed in column **Extreme Name** in Data window. Age of concrete is displayed in column **Age**. For each loads extreme maximal value from all checks and corresponding status are displayed in columns **Value** and **Result status**.

Value of age can be edited only for loads extreme, which is assigned to prestressed sections. The value of age describes position on time axis, in which check is performed.

Ribbon groups **Import**, **Set**, **Section**, **Extreme**, **Design member**, **Reinforced section**, **Calculation**, **Report** and **Print** are available.

## 5.1 Ribbon group Set

- If IDEA RCS is started from superior application, this ribbon group is not available.



Click **Set** to display menu with commands for fast input of new section with new reinforced section, new member data and new loads extreme.

- **Beam** – adds a new 1D-member section with type Beam with a new reinforced section
- **Compression member** – adds a new 1D-member section with type Compression member with a new reinforced section.
- **One-way slab** - adds new 1D-member section with member type One\*way slab with a new reinforced section.
- **Shell-Slab** - adds a new 2D-member section with member type Shell-slab (combination of membrane and bending forces, detailing rules according slabs) with a new reinforced section.
- **Shell-Wall** - adds a new 2D-member section with member type Shell-wall (combination of membrane and bending forces, detailing rules according walls) with a new reinforced section
- **Slab** - adds a new 2D-member section with member type Slab (bending forces) with a new reinforced section.
- **Wall** - adds a new 2D-member section with member type Wall (membrane forces) with a new reinforced section.
- **Deep beam** - adds a new 2D-member section with member type Deep beam (membrane forces) with a new reinforced section.


## 5.2 Ribbon group Import

- If IDEA RCS is started from superior application, this ribbon group is not available.



Click XML to start import of sections, reinforced cross-sections and loads extremes from XML file, which was exported from program SCIA Engineer– see **Errore. L'origine riferimento non è stata trovata.**

If XML file contains result tables for different types of combinations, load cases and result classes, program IDEA RCS cannot assign such results to particular load effects automatically. In this case a dialog with a list of all load types from imported result tables and result types from SCIA Engineer can be assigned to appropriate load types used in IDEA RCS.




Each row of table represents one load effect, which was found in imported XML file. The conversion table contains following columns:

- **Name** – names of imported load cases, combinations or result classes are displayed in this column
- **Type** – type of load, which was found for particular load name, is displayed in this column.
- **Fundamental ULS, Characteristic, Quasi-permanent, Accidental** – if checkbox in particular column is checked, imported result from appropriate row is assigned to selected load effect type in IDEA RCS.

## 5.3 Ribbon group Section

- **If IDEA RCS is started from superior application, this ribbon group is not available.**




Click buttons in ribbon group **Section** to add, copy or remove sections. The existing member (or newly created) and reinforced cross-section can be assigned to a new section.

- **New 1D Reinforced** - add a new section for a 1D-member reinforced with concrete reinforcement – see **5.3.1 New section input**
- **New 1D staged** - add a new staged section for a 1D-member – see **5.3.1 New section input**
- **New 2D** - add a new section for a 2D-member – see **5.3.1 New section input**
- **Copy** – copy the defined sections including assigned loads extremes
- **Delete** – delete the defined sections including assigned loads extremes
- **Explode tapered** – explode section, which was generated from members with haunches, to separate sections. This option can be used only for data stored from IDEA RCS, which was launched as module from superior linked application.

### 5.3.1 New section input

Parameters of new section:



- **Section description** – input/edit name of a section.
- **Design Member** – selection of a design member from the list-box of design members, the selected design member is assigned to a new section. Only those design members are available which are according the section type, being only 1D-members or 2D-members.
  - **New** –launches the input of a new design member into the list of design members.
  - **Reinforced cross-section** – selection of reinforced cross-section from a list-box of cross-sections, selected cross-section is assigned to new section. List of available reinforced cross-sections is filtered according to selected member in **Design Member** list-box (i.e. for design member Compression member only those cross-sections can be selected whose shape and reinforcement is conforming to requirements for compression members)
- **New** –launches the input of new reinforced cross-section into list of reinforced cross-sections.

## 5.4 Ribbon group Extreme

- **If IDEA RCS is started from superior application, this ribbon group is not available.**



Click buttons in ribbon group **Extreme** to add, to copy or to remove load extremes.

- **New** – adds new load extreme into current section.
- **Table editor** – start editing of load extremes using the table editor – see **3.2 Table editor**.

- **Copy** – copies selected load extreme.
- **Delete** – deletes selected load extreme.

#### 5.4.1 Editing load extremes using table editor

To edit the content of internal forces extremes for the current section click **Table editor** in the ribbon group **Extreme**.

The dialog contains tabs with tables for particular load combination types. One load extreme of current section represents one row in the table.

The edit of load extremes using table editor is not available for prestressed sections.

The table editor is described in **3.2 Table editor**.



## 5.5 Ribbon group Design Member

➤ If IDEA RCS is started from superior application, this ribbon group is not available.



- **New 1D** - adds a new 1D design member
- **New 2D** - adds a new 2D design member
- **Delete unused** – deletes inserted design members which are not assigned to any section

### 5.5.1 New design member input

The dialog provides setting of the design member parameters for the related section. The content of dialog differs according to type of design member. For Beam and One-way slab design members, the parameters for flexural slenderness check can be specified on tab **Flexural slenderness**.

Name

Member Data
Flexural slenderness

**Exposure Classes**

<input type="checkbox"/> No corrosion (X0)	<input checked="" type="checkbox"/> Carbonation	<input type="checkbox"/> Chlorides
	XC1	XD1
<input type="checkbox"/> Chlorides from sea	<input type="checkbox"/> Freeze/Thaw Attack	<input type="checkbox"/> Chemical Attack
XS1	XF1	XA1


Relative humidity	65 %
Creep coefficient	Calculated
Member type	Beam
Structural member importance	Major
Redistribution of moments	<input type="checkbox"/>
Reduction of moments	<input type="checkbox"/>
Reduction of shear force	<input type="checkbox"/>
Limited interaction check	<input type="checkbox"/>

**Design Member**

Name: M 4

Member Data | Flexural slenderness

$l_n$	1,00	m
$l_{eff}$	$l_n + a_1 + a_2$	m
Support condition - left	Non-continuous member	
$t_1$	0,40	m
Support condition - right	Non-continuous member	
$t_2$	0,40	m




The diagram shows a horizontal beam supported by two columns. The columns are represented by orange hatched rectangles. The beam is shown in yellow. The effective length of the beam is labeled as  $l_{eff}$  and is indicated by a dimension line between two vertical dashed lines that extend from the top of the beam to the top of the columns. The beam is supported by the columns, which are shown with diagonal hatching and arrows indicating reaction forces.

OK Cancel

## 5.6 Ribbon group Reinforced cross-section

- **If IDEA RCS is started from superior application, this ribbon group is not available.**

Click buttons in ribbon group **Reinforced Section** to add, to copy or to remove reinforced cross-sections.




- **New 1D** - adds a new reinforced cross-section for members 1D.
- **New 2D** - adds a new reinforced cross-section for members 2D
- **Copy** – copy of inserted reinforced cross-sections.
- **Copy reinforcement** – copy reinforcement from one reinforced section to another one
- **Delete unused** – deletes existing reinforced cross-sections which are not assigned to any section.

### 5.6.1 New Reinforced cross-section

Click **New 1D** or **New 2D** in ribbon group Reinforced cross-section to input new reinforced section. Dialog for input of reinforced cross-section name appears. Other data (shape, longitudinal and shear reinforcement) are specified later using navigator commands **Reinforced cross-section**.

### 5.6.2 Copy of reinforced section




To copy reinforced section click **Copy** in ribbon group **Reinforced section**.

Input name of newly created reinforced section to the edit box **Reinforced cross-section name**.

Select the reinforced section to be copied in the list **Copied reinforced cross-section**.

### 5.6.3 Copy of reinforcement


Click **Copy reinforcement** in the ribbon group **Reinforced section** to copy the reinforcement from one reinforced section to other one.



- **Reinforced cross-section to copy reinforcement from** – in the list, select the source reinforced cross-section to copy the reinforcement from
- **Filter of reinforced cross-section to copy the reinforcement to** – according to the filter the **List of reinforced cross-sections** contains suitable reinforced sections, to which is possible to copy the reinforcement from the source reinforced cross-section.
  - **All existing reinforced cross-sections** – turn this option on to display all existing reinforced cross-section in the **List of reinforced cross-sections**.
  - **Reinforced cross-sections with identical shape** – turn this option on to display reinforced cross-sections, which are of the same cross-section type as the source reinforced section, in the **List of reinforced cross-sections**.
  - **Reinforced cross-sections with identical dimension** – turn this option on to display reinforced cross-sections, which are of the same cross-section type and of the same dimensions as the source reinforced section, in the **List of reinforced cross-sections**.
- **Delete existing reinforcement** – turn this option on to delete the existing reinforcement from the target reinforced section before copying. If the option is off, the copied reinforcement is added to the old one.
- **List of reinforced sections** – the list contains suitable target reinforced sections, filtered according to the current filter settings. Columns in the list:
  - **Copy to** – switch on/off to copy the reinforcement to particular target reinforced section
  - **Name** – display name of target reinforced section.
  - **Shape** – display name of shape of target reinforced section.
  - **Preview** – click to display the preview of result of copy of reinforcement from the source to the target reinforced section.
- **Select all** – select all checkboxes in the column **Copy to**
- **Unselect all** - unselect all checkboxes in the column **Copy to**


Click **OK** to copy the reinforcement according to the current settings and to close the dialog.

## 5.7 Ribbon group Calculation



- **All** – calculates all sections. All sections, which had been correctly user defined, are calculated. Overall report is displayed afterwards.

## 5.8 Ribbon group Report




Use commands in ribbon group Report to generate the report and to setup the report content:

- **Brief** – shows brief report for sections with **Print** option enabled in report settings.
- **Standard** – shows standard report for sections with **Print** option enabled in report settings.
- **Detailed** – shows detailed report for sections with **Print** option enabled in report settings.
- **Setting** – shows the report setting dialog for the selection of sections to be printed and the selection of chapters to be printed for each section - see **5.8.1 Global report setting**


### 5.8.1 Global report setting

Here, you can choose the chapters you want to print. You can make a detailed print setting for each section independently.



- **Table of contents** – turns on/off the table of content to be printed in the report.
- **Project data** – turns on/off the chapter about general project information entered in **Project data** dialog to be printed in the report.
- **List of sections** – turns on/off the chapter about overall results of all checked sections to be printed in the report. This setting is taken into account in Standard and Detailed report.
- **Code setting** – turns on/off the chapter about code dependent variables to be printed in the report. This setting is taken into account in Detailed report only.
- **List of members** – turns on/off the chapter about member data to be printed in the report. This setting is taken into account in Detailed report only.

**List of reinforced cross-sections** - turns on/off the chapter about reinforced cross-section to be printed in the report. This setting is taken into account in Detailed report only.

- **List of materials** - turns on/off the chapter about material characteristics to be printed in the report. This setting is taken into account in Detailed report only.
- **Table of sections** contains list of sections defined in the project. Columns in the table:
  - **Section name** – name of the section.
  - **Detailed settings** – list-box of available Detailed settings. The setting is used in report for selected section. Selected setting can be changed by clicking edit-button . More description can be found in **14.1.4 Detailed report setting for check** .
  - **Print** – turns on/off the print of output for the section into report.
- **Select all to print** – turns on the **Print** option for all sections in the list
- **Unselect all to print** – turns off the **Print** option for all sections in the list
- **New setting** – adds new detailed print setting to existing detailed report settings.

## 6 Design members

Click navigator command **Project > Design members** to display and edit all design members in project.

Ribbon group **Design members** is available.

The screenshot shows the main window of the IDEA RCS software. On the left, there is a table with three columns: Name, Value, and Result Status. The table contains three rows of design members. The first row, 'M 1', has a value of 1000,0 and a red 'X' icon. The second row, 'M 2', has a value of 160,0 and a red 'X' icon. The third row, 'M 3', has a value of 90,7 and a green checkmark icon. On the right, there is a panel titled 'Design member M 1' with a list of sections: 'TRAM T1 Bilineár, TRAM T1 Šírka Trhlin, TRAM T1 Stiffness'. Below this, there are two tabs: 'Member Data' and 'Flexural slenderness'. The 'Flexural slenderness' tab is active, showing a form with 'Exposure Classes' (No corrosion (X0), Carbonation, Chlorides, Chlorides from sea, Freeze/Thaw Attack, Chemical Attack) and a table of properties: Relative humidity (70 %), Creep coefficient (Calculated), Member type (Beam), Structural member importance (Major), and checkboxes for Redistribution of moments, Reduction of moments, Reduction of shear force, and Limited interaction check.

Name	Value	Result Status
M 1	1000,0	✘
M 2	160,0	✘
M 3	90,7	✔

A table with list of design members in project and corresponding check results is displayed in the left part of the main window. The list of sections, to which is the current design member assigned, and the tabs of design member properties corresponding to the design type, are displayed in the right part of the main window.

Columns of the design members table:

- **Name** – input name of the design member.
- **Value** – extreme value of check of all sections, to which is the design member assigned.
- **Result status** – overall status of check of all sections, to which is the design member assigned.



## 6.1 Design member data common to all members

General data of the current design member can be modified on the tab **Member data** (the same parameters are shown as described in **5.5.1 New design member input**).

Member Data
Flexural slenderness

Exposure Classes

<input type="checkbox"/> No corrosion (X0)	<input checked="" type="checkbox"/> Carbonation XC1	<input type="checkbox"/> Chlorides XD1
<input type="checkbox"/> Chlorides from sea XS1	<input type="checkbox"/> Freeze/Thaw Attack XF1	<input type="checkbox"/> Chemical Attack XA1

Relative humidity	70	%
Creep coefficient	Calculated	
Member type	Beam	
Structural member importance	Major	
Redistribution of moments	<input type="checkbox"/>	
Reduction of moments	<input type="checkbox"/>	
Reduction of shear force	<input type="checkbox"/>	
Limited interaction check	<input type="checkbox"/>	

The options to switch on/off taking into account redistribution and reduction are available only for design members of type **Beam** and **One-way slab**.

## 6.2 Compression member data

If the type of current design member is **Compression member**, the compression member properties can be modified on the tab **Imperfections, 2<sup>nd</sup> order**.


If the current member is defined as a compression member, click navigator command **Design member > Imperfections, 2<sup>nd</sup> order** to launch the edit-dialog of compression member data (same parameters are shown as after **5.5.1 New design member input**).

Member Data		Imperfections, 2nd order	
Length of compression member	5	m	
Effective length	Acc. to supports		
Restraint perpendicular to an axis	y	z	
End	Free	Rigid	
Beginning	Rigid	Rigid	
Effect of imperfections and 2nd order	Calculated		
Geometric imperfection			
Use for ULS	<input checked="" type="checkbox"/>		
Use for SLS	<input type="checkbox"/>		
Effect considered	Isolated member		
Direction of imperfections	From code setting		
Second order effect			
Analysis of second order effects	<input checked="" type="checkbox"/>		
Braced member to y axis	<input type="checkbox"/>		
Braced member to z axis	<input checked="" type="checkbox"/>		
Method of analysis	Nominal stiffness		
Factor c0 to y axis	User defined		
c0y			9,60 -
Factor c0 to z axis	User defined		
c0z			9,60 -

### 6.3 Data for Flexural slenderness calculation

If the type of current design member is **Beam** or **One-way slab**, data for flexural slenderness calculation can be modified on tab

Member Data	Flexural slenderness
$l_n$	6 m
$l_{eff}$	$l_n + a_1 + a_2$ m
Support condition - left	Non-continuous member ▼
$t_1$	0,30 m
Support condition - right	Non-continuous member ▼
$t_2$	0,30 m

#### 6.3.1 Ribbon group Design member

See 5.5 Ribbon group Design Member.

## 7 Reinforced cross-sections

Click navigator command **Project > Reinforced cross-sections** to display and edit all reinforced cross-sections in project.

Ribbon group **Reinforced cross-section** is available.

The screenshot shows the 'Main' window of the software. On the left, there is a table with three columns: 'Name', 'Value', and 'Result Status'. The table contains three rows of data. Row 1 (R 1) has a value of 100,0 and a green checkmark. Row 2 (R 2) has a value of 1000,0 and a red 'X'. Row 3 (R 3) has a value of 160,0 and a red 'X'. To the right of the table, the text 'Reinforced cross-section: R 1' is displayed, followed by 'List of sections associated with reinforced cross-section: TRAM T1 Bilineár, TRAM T1 Šifka Trhlin,'. Below this text is a small icon. On the right side of the window, there is a technical drawing of a reinforced cross-section. The drawing shows a horizontal beam with a vertical reinforcement bar. Dimensions are given in millimeters: total height 500, top flange thickness 80, web height 420, and total width 1850. The web width is 200, and the flange extends 825 on both sides. A coordinate system with Z (vertical) and Y (horizontal) axes is shown.

	Name	Value	Result Status
1	R 1	100,0	✓
2	R 2	1000,0	✗
3	R 3	160,0	✗

A table with list of reinforced cross-sections in project and corresponding check results is displayed in the left part of the main window. The list of sections, to which is the current reinforced section assigned, and the picture of current reinforced cross-section are displayed in the right part of main window.

Columns of the Reinforced cross-sections:

- **Name** – input name of the reinforced cross-section.
- **Value** – extreme value of check of all sections, to which is the reinforced cross-section assigned.
- **Result status** – overall status of check of all sections, to which is the reinforced cross-section assigned.

### 7.1 Ribbon group Reinforced cross-section

See **5.6 Ribbon group Reinforced cross-section**.

## 8 Cross-section shape

For the current section (selected in **Current section** list in the top part of Navigator window) navigator command **Design > Shape** launches the input of cross-section shape.


Ribbon groups **New cross-section**, **Openings**, **Shift origin**, **Import – Export**, **Dimension lines** and **Calculation** are available.

### 8.1 Input of new cross-section

- **If IDEA RCS is started from superior application, input of new cross-section may not be available.**

Ribbon group **New cross-section** contains icons of all the available cross-sectional shapes. Click required shape to launch the dialog for input of cross-sectional parameters. Available shapes are filtered according to member type of current member (beam, compression member, one-way slab, 2D members).


Cross-sections available for beam members:



Cross-sections available for compression members:



Cross-sections available for staged sections (licence for time dependent analysis is required):



## 8.2 General cross-sections



Click General or CSS in ribbon group New cross-section to define new general cross-section:


- **General** – input general one-component cross-section defined by cross-section vertexes. Holes in the cross-section can be defined too – see **8.4**

**Input of general section by coordinates of vertexes.** Neither staged nor composite cross-section can be defined this way.

- **CSS** – start IDEA CSS plugin module, in which the general multi-components staged cross-section can be defined – see the user guide for IDEA CSS. The command is available only if the licence for IDEA CSS is available.

## 8.3 Cross-section dimensions input

Dialog with geometrical parameters of the cross-section appears after clicking the required cross-section icon in the ribbon group **New cross-section**. The dialog content depends on the shape of the selected cross-section.




Input the required dimensions and click **OK** to input the cross-section. New cross-section is drawn in the Main window.

## 8.4 Input of general section by coordinates of vertexes

- **If IDEA RCS is started from superior application, input of general cross-section and its components may not be available.**

Click **General** in ribbon group **New cross-section** to input an one-component general cross-section defined by coordinates of vertexes.


New general shape is defined by table of vertexes coordinates – see **3.2 Table editor**.



Dialog options:

- **Import** – click to import vertex coordinates from text or .NAV file - see more in **4.4 Format of text files**.


### 8.4.1 Input of openings into general cross-section



To input new openings into general cross-section use commands on ribbon group **Openings**. This ribbon group is available after shape of general cross-section has been defined.

### 8.4.2 New general opening

To start input of new opening with general shape click **New general** in ribbon group **Openings**.



The opening of general shape is defined by table of vertex coordinates – see **3.1 3.2 Table editor**.


Dialog options:

- **Origin of coordinate system** – defined vertex coordinates are related to point, which can be selected in the list. Choose from following options:
  - **Point [0,0]** – vertex coordinates are related to origin of cross-section coordinate system
  - **Cross-section vertex** – vertex coordinates are related to vertex, which is selected in list below.
- **Minimum distance between edges** – input minimal allowed distance between edges. If distance between any edges is less than the limit value, it is not possible to insert opening into cross-section.
- **Import** – click to import vertex coordinates from text or .NAV file - see more in **4.4 Format of text files**.



### 8.4.3 New rectangular opening

To start input of new opening with rectangular shape click **New rectangle** in ribbon group **Openings**.



Rectangular opening is defined by width, depth and position of its centre to specified origin point.

- **Origin of coordinate system** – defined vertex coordinates are related to point, which can be selected in the list. Choose from following options:
  - **Point [0,0]** – vertex coordinates are related to origin of cross-section coordinate system
  - **Cross-section vertex** – vertex coordinates are related to vertex, which is selected in list below.
- **Minimum distance between edges** – input minimal allowed distance between edges. If distance between any edges is less than the limit value, it is not possible to insert opening into cross-section.

- **Import** – click to import vertex coordinates from text or .NAV file - see more in **4.4 Format of text files**.

### 8.4.4 New circular opening

To start input of new opening with rectangular shape click **New circle** in ribbon group **Openings**.

Circular opening
✕

Opening dimensions

Diameter	100	mm
----------	-----	----

Position of opening centre point

Y	600	mm
Z	200	mm

	Y [ mm ]	Z [ mm ]
1	650	200
2	647	217
3	638	232
4	625	243
5	609	249
6	591	249
7	575	243
8	562	232
9	553	217
1	550	200
1	553	183
1	562	168
1	575	157
1	591	151
1	609	151
1	625	157
1	638	168
1	647	183

Centroid of cross-section including new opening is not located in origin of coordinate system

Origin of coordinate system

Point [0,0]

▼

Vertex 1

▼

Minimum distance between edges	60	mm
--------------------------------	----	----

OK


Cancel

Circular opening is defined by diameter and position of its centre to specified origin point.

- **Origin of coordinate system** – defined vertex coordinates are related to point, which can be selected in the list. Choose from following options:

- **Point [0,0]** – vertex coordinates are related to origin of cross-section coordinate system
- **Cross-section vertex** – vertex coordinates are related to vertex, which is selected in list below.
- **Minimum distance between edges** – input minimal allowed distance between edges. If distance between any edges is less than the limit value, it is not possible to insert opening into cross-section.


### 8.4.5 Shift origin of general cross-section



The origin of cross-section [0,0] has to be positioned in the cross-sectional centre of gravity. This is essential due to loading, because the entered load is always applied at the point [0,0] of section.

- **Cross-section** – click to recalculate vertex coordinates of outline and openings such that the origin [0,0] is positioned in the cross-sectional centre of gravity. Reinforcement position is not affected.
- **Reinforced cross-section** – click to recalculate vertex coordinates of outline, openings and positions of reinforcement bars, stirrups and tendons such that the origin [0,0] is positioned in the cross-sectional centre of gravity.

### 8.5 Dimension line of cross-section shape



Ribbon group **Dimension lines** can be used to set mode of dimension lines drawing:

- **Not draw** – turns off drawing of dimension lines
- **Standard** – turns on drawing of standard dimension lines of cross-section shape.



## 8.6 Cross-sectional shape modifications

- **If IDEA RCS is started from superior application, editing of shape and material properties may not be available.**





After clicking on cross-section drawn in the Main window the property dialog is displayed in Data window.

Data

Concrete components of cross-section

Geometry	Material
1 	C30/37 

Openings


Name	Geometry
1 O1 	
2 O2 	


Cross-section characteristics (related to centre of gravity of cross-section)

Type	A [ mm <sup>2</sup> ]	Sy [ mm <sup>3</sup> ]	Sz [ mm <sup>3</sup> ]	Iy [ mm <sup>4</sup> ]	Iz [ mm <sup>4</sup> ]
Cross-section *)	838662	0	0	69651706948	101563075680
Reinforcement	402	-236812	0	139459634	18532911

Click edit button  in row **Geometry** of table **Cross-section shape** to start modification of cross-section shape.

Material of cross-section can be selected in list **Material**. The list of all the available materials is filtered according to selected Exposure class in the project.




Click edit-button  next to selected material to show or edit the current material characteristics.

Click edit button  in column **Geometry** of table **Openings** to start editing of opening shape. To delete selected opening click **Delete** in ribbon group **Openings**.


### 8.6.1 Composite cross-section modification

Data

Composite cross-section

Geometry	Material 1	Material 2
	C30/37 	C30/37 

Joints

Name	Type	Self weight
1J1	Rough 	<input type="checkbox"/>

Materials for individual cross-section components can be defined for the composite cross-section.

The joints parameters can be defined in the table **Joints**:

- **Type** – select the roughness of the surfaces in the joint.
- **Self weight** – switch on/off taking into account the self-weight of cross-section component above the joint during the joint check.


## 9 Prestressing reinforcement

For the current section (set in list **Current section** in top of Navigator), click navigator command **Design > Prestressing** to input tendons and tendon ducts into the cross-section

Ribbon groups **Tendons**, **Ducts and tubes**, **Delete**, **Import-Export**, **Cross-section points**, **Dimension lines** and **Calculation** are available. Depending on member type or shape of cross-section some of ribbon groups may not be available.

- **If IDEA RCS is started from superior application, some items for input and editing of prestressed reinforcement may not be available.**

### 9.1 Ribbon group Tendons




- **New in line** – adds a new layer of tendons defined by coordinates of first and last tendon in layer.
- **New on edge** – adds a new layer of tendons related to cross-section edge.
- **Explode tendons** – explodes layer of tendons to separate tendons with editable coordinates.



## 9.2 New layer of tendons defined by coordinates



To input layer of tendons defined by coordinates of first and last tendon in layer click **New in line** in ribbon group **Tendons**.



Tendons are defined in layers. A layer is defined by the number of tendons in the layer, the coordinates of the first tendon in the layer, and the coordinates of the last tendon in the layer. Number of strands, type of prestressing, order of prestressing, slope angle, duct diameter, material of prestressing reinforcement and material of tendon duct can be assigned to individual layers.


Particular columns of table with tendon layer:

- **n** – input number of tendons in layer
- **ns** – input number of strands in tendon
- **np** – input order of prestressing. The entered number corresponds to the order of time node, in which is the prestressing applied, on the global time axis (it means that the first time node, in which is the prestressing applied, is nr. 1, the second time node, in which is the prestressing applied, is nr. 2 etc.).
- **Post-tensioned** – if the checkbox is checked, tendon is assumed to be post-tensioned. Duct (with diameter specified in column  $\varnothing$  duct) is generated for post-tensioned tendon. Otherwise tendon is assumed to be pre-tensioned and duct is not generated.
- **$\alpha_{XZ}$**  – input value of tendon slope to centre line in XZ-plane
- **$\alpha_{XY}$**  – input value of tendon slope to centre line in XY-plane
- **Ref. point - begin** – select origin, to which coordinates of first tendon in layer are related. Position of tendon can be related to point [0;0] (centre of gravity) or to selected cross-section vertex.
- **Begin Y, Begin Z** – input values of coordinates of first tendon in layer related to selected origin.

- **Ref. point - end** – select origin, to which coordinates of last tendon in layer are related. Position of tendon can be related to point [0;0] (centre of gravity) or to selected cross-section vertex.
- **Begin Y, Begin Z** – input values of coordinates of last tendon in layer related to selected origin.
- **As** – calculated value of tendons area in layer is displayed
- **Material** – in the list of available materials select material of tendons in layer or click edit button to edit material properties.
- **Ø duct** – input diameter of tendon duct. Minimal value of diameter is determined according to number of strands in tendon.
- **Duct material** - select material of tendon duct.
-  - add new tendons layer into the table
-  - delete tendons layer from table
  
- **Draw dimension lines of actual layer** – switch on/off drawing of dimension lines of tendons defined in the current tendons layer.
- **Import tendons** – click to import tendon coordinates from a text file – see more in **Errore. L'origine riferimento non è stata trovata. Errore. L'origine riferimento non è stata trovata.**

### 9.3 New layer of tendons on edge



To input layer of tendons at cross-section edge click **New on edge** in ribbon group **Tendons**.



Tendons are defined in layers. A layer is defined by the edge, the number of tendons in the layer and cover. Number of strands, type of prestressing, order of prestressing, slope angle, duct diameter and material can be assigned to individual layers.

Particular columns of table with tendons layer:

- **Edge** – select edge, to which layer of tendons is related to.
- **n** – input number of tendons in layer
- **ns** – input number of strands in tendon
- **np** – input order of prestressing. The entered number corresponds to the order of time node, in which is the prestressing applied, on the global time axis (it means that the first time node, in which is the prestressing applied, is nr. 1, the second time node, in which is the prestressing applied, is nr. 2 etc.).
- **Post-tensioned** – if the checkbox is checked, tendon is assumed to be post-tensioned. Duct (with diameter specified in column **Ø duct**) is generated for post-tensioned tendon. Otherwise tendon is assumed to be pre-tensioned and duct is not generated.
- **$\alpha_{XZ}$**  – input value of tendon slope to centre line in XZ-plane
- **$\alpha_{XY}$**  – input value of tendon slope to centre line in XY-plane
- **Edge cover** – input value of cover to cross-section edge
- **Left cover** – input value of cover between the most left tendon in layer and left edge of cross-section
- **Right cover** – input value of cover between the most right tendon in layer and right edge of cross-section
- **As** – calculated value of tendons area in layer is displayed

- **Material** – in the list of available materials select material of tendons in layer or click edit button to edit material properties.
  - **Ø duct** – input diameter of tendon duct. Minimal value of diameter is determined according to number of strands in tendon.
  - **Duct material** - select material of tendon duct.
  -  - add new tendons layer into the table
  -  - delete tendons layer from table
- 
- **Draw dimension lines of actual layer** – switch on/off drawing of dimension lines of tendons defined in the current tendons layer.
  - **Import tendons** – click to import tendon coordinates from a text file – see more in **Errore. L'origine riferimento non è stata trovata. Errore. L'origine riferimento non è stata trovata.**

### 9.4 Editing tendons

Tendons can be edited in similar way as longitudinal reinforcement. Properties of selected tendon are displayed in a table in Data window.

Single tendons

Layer	As [mm <sup>2</sup> ]	Type of prestressing	n <sub>p</sub>	α <sub>XZ</sub> [°]	α <sub>XY</sub> [°]	Material	First point Origin	distance Y [mm]	distance Z [mm]	Y [mm]	Z [mm]
2	150	Pre-tensioned	1	0,0	0,0	Y1860S7-15.7	Point (0,0)	0	100	0	100

Single tendons and linked tendon duct

Layer	n <sub>s</sub>	Ø duct [mm]	As [mm <sup>2</sup> ]	Type of prestressing	n <sub>p</sub>	α <sub>XZ</sub> [°]	α <sub>XY</sub> [°]	Material	Duct material	First point Origin	distance Y [mm]	distance Z [mm]	Y [mm]	Z [mm]
1	6	38	900	Post-tensioned	1	0,0	0,0	Y1860S7-15.7	Metal	Point (0,0)	0	0	0	0

Tendon ducts influence cross section capacity by reducing of cross-section area and shear width

Tendon layer with uniform distance in line

Layer	n	As [mm <sup>2</sup> ]	Type of prestressing	n <sub>p</sub>	α <sub>XZ</sub> [°]	α <sub>XY</sub> [°]	Material	First point Origin	distance Y [mm]	distance Z [mm]	Y [mm]	Z [mm]	Last point Origin	distance Y [mm]	distance Z [mm]	Y [mm]	Z [mm]
2	2	300	Pre-tensioned	1	0,0	0,0	Y1860S7-15.7	vertex 6	80	180	-145	-783	vertex 7	-80	180	145	-783

Tendon layer and linked tendon duct layer with uniform distance in line

Layer	n <sub>s</sub>	n	Ø duct [mm]	As [mm <sup>2</sup> ]	Type of prestressing	n <sub>p</sub>	α <sub>XZ</sub> [°]	α <sub>XY</sub> [°]	Material	Duct material	First point Origin	distance Y [mm]	distance Z [mm]	Y [mm]	Z [mm]	Last point Origin	distance Y [mm]	distance Z [mm]	Y [mm]	Z [mm]
1	6	2	38	1800	Post-tensioned	1	0,0	0,0	Y1860S7-15.7	Metal	vertex 6	80	80	-145	-883	vertex 7	-80	80	145	-883

Tendon ducts influence cross section capacity by reducing of cross-section area and shear width

Tendon layer with uniform distance on cross-section edge

Layer	n	As [mm <sup>2</sup> ]	Type of prestressing	n <sub>p</sub>	α <sub>XZ</sub> [°]	α <sub>XY</sub> [°]	Material	Edge	Edge cover [mm]	Left cover [mm]	Right cover [mm]
2	2	300	Pre-tensioned	1	0,0	0,0	Y1860S7-15.7	6	120	30	30

Tendon layer and linked tendon duct layer with uniform distance on cross-section edge

Layer	n <sub>s</sub>	n	Ø duct [mm]	As [mm <sup>2</sup> ]	Type of prestressing	n <sub>p</sub>	α <sub>XZ</sub> [°]	α <sub>XY</sub> [°]	Material	Duct material	Edge	Edge cover [mm]	Left cover [mm]	Right cover [mm]
1	6	2	38	1800	Post-tensioned	1	0,0	0,0	Y1860S7-15.7	Metal	6	30	30	30

Tendon ducts influence cross section capacity by reducing of cross-section area and shear width

According to input type of selected tendon following tendon properties can be edited:


- For single pre-tensioned tendons in table **Single tendons** can be edited: order of prestressing, slopes in two directions, tendon material characteristics and position related to origin
- For single post-tensioned tendons in table **Single tendons and linked tendon ducts** can be edited: number of strands in tendon, tendon duct diameter, tendon duct material, order of prestressing, slopes in two directions, tendon material characteristics and position related to origin
- For layer of pre-tensioned tendons defined by coordinates in table **Tendon layer with uniform distance in line** can be edited: number of tendons in layer, order of prestressing, slopes in two directions, tendon material characteristics, positions of first and last tendon in layer related to origin.
- For layer of post-tensioned tendons defined by coordinates in table **Tendon layer and linked tendon duct layer with uniform distance in line** can be edited: number of tendons in layer, number of strands in tendon, tendon duct diameter, duct material, order of prestressing, slopes in two directions, tendon material characteristics, positions of first tendon in layer and last tendon in layer related to origin.
- For layer of pre-tensioned tendons defined at cross-section edge in table **Tendon layer with uniform distance on cross-section edge** can be edited: number of tendons in layer, order of prestressing, slopes in two directions, tendon material characteristics, edge cover, left cover, right cover.
- For layer of post-tensioned tendons defined at cross-section edge in table **Tendon layer and linked tendon duct layer with uniform distance on cross-section edge** can be edited: number of tendons in layer, number of strands in tendon,

tendon duct diameter, duct material, order of prestressing, slopes in two directions, material characteristics, edge cover, left cover, right cover.

## 9.5 Exploding tendon layer

To explode selected tendons layer to single tendons click **Explode tendons** in ribbon group **Tendons**. Exploded tendons can be edited separately.


## 9.6 Ribbon group Tendon ducts



- **New in line** – adds a new layer of tendon ducts defined by coordinates of first and last tendon duct in layer.
- **New on edge** – adds a new layer of tendon ducts related to cross-section edge.
- **Explode duct layer** – explodes layer of tendon ducts to separate ducts with editable coordinates.

## 9.7 New layer of tendon ducts defined by coordinates



To input layer of tendon ducts defined by coordinates of first and last duct in layer click **New in line** in ribbon group **Tendon ducts**.



Tendon ducts are defined in layers. A layer is defined by the number of tendon ducts in the layer, the coordinates of the first duct in the layer, and the coordinates of the last duct in the layer. Duct diameter can be assigned to individual layers.

Particular columns of table with duct layer:


- **Ø** – input value of tendon duct diameter.
- **Debonding tube** – if selected, the debonding tube is defined, otherwise tendon duct is defined.
- **Material** – select material of tendon duct.
- **Origin** – select origin, to which coordinates of first duct in layer are related. Position of duct can be related to point [0;0] (centre of gravity) or to selected cross-section vertex.
- **Begin Y, Begin Z** – input values of coordinates of first duct in layer related to selected origin.
- **Origin** – select origin, to which coordinates of last duct in layer are related. Position of duct can be related to point [0;0] (centre of gravity) or to selected cross-section vertex.

- **Begin Y, Begin Z** – input values of coordinates of last duct in layer related to selected origin.
-  - add new ducts layer into the table
-  - delete ducts layer from table
  
- **Draw dimension lines of current layer** – set on/off drawing of dimension lines describing the current tendon duct layer.
- **Import tendon ducts** – click to import tendon ducts coordinates from a text file – see more in **Errore. L'origine riferimento non è stata trovata. Errore. L'origine riferimento non è stata trovata..**



## 9.8 New layer of tendon ducts on edge


To input layer of tendon ducts at cross-section edge click **New on edge** in ribbon group **Tendon ducts**.



Tendon ducts are defined in layers. A layer is defined by the edge, the number of tendon ducts in the layer and cover. Duct diameter can be assigned to individual layers.

Particular columns of table with tendon ducts layer:

- **Edge** – select edge, to which layer of tendons is related to.
- **n** – input number of tendons in layer
- **Ø** – input diameter of tendon duct.
- **Debonding tube** – if selected, the debonding tube is defined, otherwise tendon duct is defined.
- **Material** – select material of tendon duct.
- **Left cover** – input value of cover between the most left tendon in layer and left edge of cross-section
- **Right cover** – input value of cover between the most right tendon in layer and right edge of cross-section
- **Edge cover** – input value of cover to cross-section edge
- - add new ducts layer into the table

-  - delete ducts layer from table
- **Draw dimension lines of current layer** – set on/off drawing of dimension lines describing the current tendon duct layer.
- **Import tendon ducts** – click to import tendon ducts coordinates from a text file – see more in **Errore. L'origine riferimento non è stata trovata. Errore. L'origine riferimento non è stata trovata..**

## 9.9 Editing tendon ducts

Tendon ducts can be edited in similar way as tendons. Properties of selected tendon duct are displayed in a table in Data window.

Single tendon ducts								
Layer	Ø [ mm ]	As [ mm <sup>2</sup> ]	Duct material	First point Origin	distance Y [ mm ]	distance Z [ mm ]	Y [ mm ]	Z [ mm ]
1	34	900	Metal	Point (0,0)	0	-250	0	-250

Tendon duct layer with uniform distance in line														
Layer	n	Ø [ mm ]	As [ mm <sup>2</sup> ]	Duct material	First point Origin	distance Y [ mm ]	distance Z [ mm ]	Y [ mm ]	Z [ mm ]	Last point Origin	distance Y [ mm ]	distance Z [ mm ]	Y [ mm ]	Z [ mm ]
2	2	34	1800	Metal	vertex 4	80	80	-120	-376	vertex 5	-80	80	120	-376

Tendon duct layer with uniform distance on cross-section edge								
Layer	n	Ø [ mm ]	As [ mm <sup>2</sup> ]	Duct material	Edge	Edge cover [ mm ]	Left cover [ mm ]	Right cover [ mm ]
3	2	30	1414	Metal	8	30	30	30


According to input type of selected tendon duct following tendon duct properties can be edited:

- For single tendon ducts in table **Single tendon duct** be edited: diameter of duct, material of duct and position related to origin
- For tendon duct layer defined by coordinates in table **Tendon duct layer with uniform distance in line** can be edited: number of tendon ducts in layer, ducts diameter, duct material, positions of first and last duct in layer related to origin.
- For tendon duct layer defined at cross-section edge in table **Tendon duct layer with uniform distance on cross-section edge** can be edited: number of tendon ducts in layer, ducts diameter, duct material, edge cover, left cover, right cover.

## 9.10 Exploding tendon duct layer

To explode tendon ducts layer into single tendon ducts click **Explode duct layer** in ribbon **Tendon ducts**. Exploded ducts can be edited separately.


## 9.11 Deleting prestressing reinforcement



Use commands in ribbon group **Delete** to delete prestressing reinforcement or tendon duct.

- **Selected** - delete selected tendon, tendon layer, tendon duct or layer of tendon ducts.
- **All** – delete all tendons and tendon ducts.

## 9.12 Numbering of cross-section points



Ribbon group **Cross-section points** can be used to set drawing options of fibre and tendon numbers.

- **Fibre** – select mode of fibres drawing in the list. One of following modes can be chosen:
  - **No labels** – description of fibres is not drawn.
  - **Outside** – fibre numbers are drawn outside the cross-section outline
  - **Inside** – fibre numbers are drawn inside the cross-section outline
- **Tendon numbers** – turns on/off drawing of tendon numbers

## 10 Construction and action stages

### 10.1 Construction stages

- **If IDEA RCS is started from superior application, construction stages may be set to read only.**


For staged section click navigator command **Design > Construction stages** to edit the time axis. Particular nodes on time axis and their properties are present in a table in Main window. The time nodes, when the prestressing is applied or when the cross-section component is cast, can be defined.

The time axis of current design member can be modified also on the tab Construction stages in navigator **Project data > Design members**.


Ribbon groups **Time axis points**, **Time axis label** and **Cross-section** are available.

Columns of table:

- **Name** – name of the node on the time axis.
- **Age** – number of days since casting.
- **Phase** – if the option is selected, a cross-section component in the time node, which has the same number as the number at the checkbox. The order of casting corresponds to the time-order of time nodes. Thus the first time node, in which the cross-section component is cast, has the phase number 1, the second time node, in which the cross-section component is cast, has the phase number 2 etc.
- **Age** – input the equivalent age of concrete, e.g. to take into account the elevated temperature on the maturity of concrete.
- **Prestressing** – if the checkbox is checked, it means that in this node of time axis the prestressing is introduced into the cross-section. The prestressing is applied from tendons, which have set the appropriate order of prestressing. The order of prestressing corresponds to the time-order of time nodes, in which the prestressing is applied. Thus the first time node, in which the prestressing is applied, corresponds with the order of prestressing 1, the second time node, in which prestressing is applied, corresponds with the order of prestressing 2 etc.
- **Description**- a comment to time axis point.
- **Add** – add new point on time axis.
- **Delete** – delete selected point from time axis.



### 10.1.1 Ribbon group Time axis points



Commands in ribbon group **Time axis points**:

- **All** – switch to draw all points of the time axis.
- **Phase** – switch to draw only the points, in which the cross-section component is cast.
- **Prestressing** – switch to draw only the points, in which the prestressing is applied.


### 10.1.2 Ribbon group Time axis label



Commands in ribbon group **Time axis label**:

- **Name** – switch on/off drawing of name of the time axis points.
- **Time** – switch on/off drawing of the time of the time axis points.
- **Phase** – switch on/off drawing of cross-section component number at the corresponding time axis points.
- **Prestressing** – switch on/off drawing of cross-section component number at the corresponding time axis points.

### 10.1.3 Ribbon group Cross-section



Commands in ribbon group **Cross-section**:

- **Not draw** – switch off the drawing of cross-section components for all time axis points.
- **Current** – switch to draw the existing cross-section components for the current time axis point. The cross-section component age must be greater than three days to be able to check it at the time of the time-axis node.

- **All** – switch to draw all existing cross-section components in all nodes of the time-axis.
- **Scale** – set the drawing scale of the cross-sections.

## 10.2 Action stages

- **If IDEA RCS is started from superior application, construction stages may be set to read only.**

Click navigator command **Design > Action stages** to edit increments of load in particular nodes of the time axis. Particular nodes of the time axis and their properties are displayed in a table in Main window.

Ribbon group **Recalculation of losses** is available.

According to selected type of prestressing primary effect of prestressing are calculated and values of secondary effects of prestressing can be defined

Determination of initial state of cross-section

Increments of effects of characteristic permanent load (used for calculation of prestressing losses, ULS and SLS checks)

Time [d]	N [kN]	Vy [kN]	Vz [kN]	T [kNm]	My [kNm]	Mz [kNm]
5,0	0,00	0,00	0,00	0,00	0,00	0,00
28,0	0,00	0,00	0,00	0,00	0,00	0,00
18250,0	0,00	0,00	0,00	0,00	0,00	0,00

Prestressing

Type of prestressing input

Tendon	Time [d]	$\sigma_{pm0}$ [MPa]	$\Delta\sigma_{pr, occurred}$ [MPa]
1	5,0	1394,00	-10,00
2	5,0	1394,00	-10,00

Total effect of prestressing caused by tensioned tendons

Time [d]	Effect of prestressing	N [kN]	Vy [kN]	Vz [kN]	T [kNm]	My [kNm]	Mz [kNm]
5,0	Primary	-2509,20	0,00	0,00	0,00	-1198,79	0,00
	Secondary	0,00	0,00	0,00	0,00	0,00	0,00

Determination of initial state of cross-section – select the mode of determination of initial state of cross-section. If **User input/Import** is set and the type of prestressing input is set to **Stress after long-term losses** or **Estimation of prestressing losses**, the tables to define user values of initial cross-section state are displayed.

### Table **Increments of effects of characteristics permanent load**

Values of load increments for particular points of time axis are specified in particular table rows. Those loads can be transferred into load effect for check in particular time.

**Type of prestressing** – select type of losses calculation and determination of primary effects of prestressing. Following modes of prestressing input can be chosen:

- **Estimation of prestressing losses** – for each tendon in the appropriate time of prestressing the value of maximal stress in tendon is displayed in the table below the list. Coefficient for determination of short-term and long-term losses can be specified.
- **Stress after short-term losses** – in the table below for each tendon in the appropriate time of prestressing the value of calculated stress in prestressing reinforcement just after introduction of prestressing and the value of relaxation occurred in the past is displayed. Table with results of long-term losses is displayed in Data window.
- **Stress after long-term losses** – in the table below for each tendon and the appropriate time of prestressing the stress in tendon after long-term losses can be specified.

## Table Total effect of prestressing

Calculated values of primary effects of prestressing in cross-section are displayed in the table. User defined values of secondary effects of prestressing can be entered into row Secondary effects of prestressing.

### 10.2.1 Effect in cross-section components

If mode **User input/Import** of determination of initial state of cross-section is set, the tables to define user values of initial cross-section state are displayed.

Effects in cross-section components

Type of effects

Time [d]	Component	N [kN]	Vy [kN]	Vz [kN]	T [kNm]	My [kNm]	Mz [kNm]
0,0	1	0,00	0,00	0,00	0,00	0,00	0,00
5,0	1	0,00	0,00	0,00	0,00	0,00	0,00
28,0	1	0,00	0,00	0,00	0,00	0,00	0,00
	2	0,00	0,00	0,00	0,00	0,00	0,00
18250,0	1	0,00	0,00	0,00	0,00	0,00	0,00
	2	0,00	0,00	0,00	0,00	0,00	0,00

Stress in reinforcement bars


Determination of initial effects

Bar	$\sigma_s$ 0,0 [MPa]	$\sigma_s$ 5,0 [MPa]	$\sigma_s$ 28,0 [MPa]	$\sigma_s$ 18250,0 [MPa]
1	0,00	0,00	0,00	0,00
2	0,00	0,00	0,00	0,00
3	0,00	0,00	0,00	0,00
4	0,00	0,00	0,00	0,00
5	0,00	0,00	0,00	0,00
6	0,00	0,00	0,00	0,00

According to the selected type of effect either internal forces or deformation plane can be defined for individual cross-section part at the times of the time axis.

If the **Determination of initial effects** is set to **User input/Import** in the **Stress in reinforcement bars** table, the initial stress can be defined for each reinforcement bar at each time of the time axis.


### 10.2.2 Ribbon group Recalculation of losses



- **Automatic** – if the option is selected, the stresses after long term losses are recalculated automatically after each change in the tables of action stages.
- **Start** – calculate the stresses after long term losses for the currently defined values.



### 10.2.3 Ribbon group Resultant of stage



- **Entire** - internal forces will be related to the centroid of concrete cross-section (without the reinforcement) with modulus of elasticity at the age 28 days. All phases of cross-section are taken into account in the case of composite cross-section irrespective of the fact if they currently exist..
- **Current** - internal forces will be related to the centroid of transformed cross-section determined from currently existing phases of cross-section and their prestressing reinforcement. Change of modulus of elasticity due to concrete aging is considered in all phases of cross-section.

## 11 Load effects input

For the current section and current loads extreme (set in lists **Current section** and **Current extreme** in top of Navigator), click navigator command **Design > Internal forces** to launch the input-dialog of sectional internal forces. The forces are input by the user into particular Load Combination types. The combinations may be of various types. Each type of combination is used for different checks:

- **Fundamental ULS** – values of internal forces defined in this combination type are used to perform ultimate limit states checks (commands **Checks > Ultimate Limit state** in the navigator) and detailing check.
- **Accidental** - values of internal forces defined in this combination type are used to perform ultimate limit states checks (commands **Checks > Ultimate Limit state** in the navigator).
- **Fatigue** – the basic combination for check of fatigue without the cyclic loads.
- **Fatigue with cyclic loads** - the combination for check of fatigue including the cyclic loads.
- **Characteristic load combination** – values of internal forces defined in this combination type are used to perform stress limitation check.
- **Quasi permanent load combination** – values of internal forces defined in this combination type are used to perform stress limitation check, crack widths check, stiffness check and flexural slenderness check.


If the checkbox in column **Use** is not on, the appropriate combination is considered as not defined. Thus the checks, which require this combination, are not performed.

### 11.1 1D section internal forces

- **If IDEA RCS is started from superior application, forces for 1D design members may be set to read only.**

The entered forces are always related to [0, 0] point of the section.

Combination type	Use	N [kN]	Vy [kN]	Vz [kN]	T [kNm]	My [kNm]	Mz [kNm]
Fundamental ULS	<input checked="" type="checkbox"/>	0,0	0,0	0,0	0,0	214,9	0,0
Accidental	<input type="checkbox"/>	0,0	0,0	0,0	0,0	0,0	0,0
Max. cyclic load	<input checked="" type="checkbox"/>	0,0	0,0	0,0	0,0	0,0	0,0
Min. cyclic load	<input checked="" type="checkbox"/>	0,0	0,0	0,0	0,0	0,0	0,0
Characteristic	<input checked="" type="checkbox"/>	0,0	0,0	0,0	0,0	0,0	0,0
Quasi-permanent	<input checked="" type="checkbox"/>	0,0	0,0	0,0	0,0	0,0	0,0



## 11.2 2D Section internal forces

- If IDEA RCS is started from superior application, forces for 2D design members may be set to read only.


For 2D member sections the load effects are defined in the centroidal plane. By default, the checks are performed in the direction of the principal stresses calculated from the entered internal forces. In the table below the load effects input table, it is possible to define different directions for the performed checks.

Ribbon group **Recalculation of design forces** is available when entering internal forces for 2D members.


The internal forces components are filtered according to the selected design member type:

Combination type	Use	mx [kNm/m]	my [kNm/m]	mxy [kNm/m]	nx [kN/m]	ny [kN/m]	nxy [kN/m]	qx [kN/m]	qy [kN/m]
Fundamental ULS	<input checked="" type="checkbox"/>	171,4	1165,9	0,0	-1704,5	-1785,7	0,0	-0,9	39,4
Accidental	<input type="checkbox"/>	0,0	0,0	0,0	0,0	0,0	0,0	0,0	0,0
Max. cyclic load	<input checked="" type="checkbox"/>	0,0	0,0	0,0	0,0	0,0	0,0	0,0	0,0
Min. cyclic load	<input checked="" type="checkbox"/>	0,0	0,0	0,0	0,0	0,0	0,0	0,0	0,0
Characteristic	<input checked="" type="checkbox"/>	0,0	0,0	0,0	0,0	0,0	0,0	0,0	0,0
Quasi-permanent	<input checked="" type="checkbox"/>	171,4	1165,9	0,0	-1704,5	-1785,7	0,0	0,0	0,0

Combination type	Checked direction	Angle from x-axis [°]
Fundamental ULS	Principal stress direction	0,0
Accidental	User direction	0,0
Max. cyclic load	User direction	0,0
Min. cyclic load	User direction	0,0
Characteristic	Principal stress direction	0,0
Quasi-permanent	Principal stress direction	0,0



Sign convention of internal forces



Recalculated internal forces in input direction by theory of Baumann

The recalculated internal forces using the Baumann Theory are displayed in the data window for the user defined internal forces.

## Recalculated design forces

### Design forces in centroidal plane for ULS combination

Angle [ ° ]	Concrete strut	n upper [ kN/m ]	n lower [ kN/m ]	n d [ kN/m ]	m d [ kNm/m ]	v d [ kN/m ]
45,0	No	-755,56	755,56	0,00	119,00	60,00
135,0	No	-120,63	120,63	0,00	19,00	60,00

### Design forces in centroidal plane for SLS Characteristic combination

Angle [ ° ]	Concrete strut	n upper [ kN/m ]	n lower [ kN/m ]	n d [ kN/m ]	m d [ kNm/m ]	v d [ kN/m ]
0,0	No	-507,94	507,94	0,00	80,00	0,00
90,0	No	-507,94	507,94	0,00	80,00	0,00

### Design forces in centroidal plane for SLS Quasi-permanent combination


Angle [ ° ]	Concrete strut	n upper [ kN/m ]	n lower [ kN/m ]	n d [ kN/m ]	m d [ kNm/m ]	v d [ kN/m ]
0,0	No	-507,94	507,94	0,00	80,00	0,00
90,0	No	-507,94	507,94	0,00	80,00	0,00

## Recalculated forces

### Normal forces (design and in principal stress direction) at surfaces for ULS combination

Surface	Checked direction	n1 [ kN/m ]	n2 [ kN/m ]	$\alpha$ n1 [ ° ]	z [ mm ]	Angle [ ° ]	n surface [ kN/m ]
Upper	Principal stress direction	-120,63	-755,56	-45,0	153	-45,0	-120,63
Upper	Perpendicular direction	-120,63	-755,56	-45,0	153	45,0	-755,56
Upper	Compressive concrete strut	-120,63	-755,56	-45,0	153	90,0	0,00
Lower	Principal stress direction	755,56	120,63	45,0	158	45,0	755,56
Lower	Perpendicular direction	755,56	120,63	45,0	158	135,0	120,63

### 11.2.1 Ribbon group Recalculation of design forces



- **Automatic** – if the option is selected, the design forces are recalculated automatically after each change in the table of internal forces in section.
- **Start** – calculate design forces for the currently entered internal forces.

### 11.3 Second order effects

For the current section and current loads extreme (set in lists **Current section** and **Current extreme** in top of navigator), click navigator command **Design > Second order effects** to launch the input-dialog of end moments acting in the compression member and to calculate the second order effects. The end moments can be entered only if the compression member type is used for the current section.

The end moment values, the recalculated internal forces, biaxial bending and slenderness are displayed in the Data window.

Ribbon group **Recalculation of internal forces** is available.

#### First order end moments

Combination type	Load type	My [kNm]	Mz [kNm]
Fundamental ULS	Begin	60,0	0,0
	End	0,0	0,0
Accidental	Begin	0,0	0,0
	End	0,0	0,0

The first order end moments M01 and M02 acc. to 5.8.3.1 (1)

Data

#### Recalculation of internal forces (second order effect and imperfection)

Ultimate limit state - fundamental combination of actions

Axis	N <sub>Ed</sub> [kN]	M <sub>Ed,y/z</sub> [kNm]	M <sub>0,y/z</sub> [kNm]	M <sub>1,y/z</sub> [kNm]	M <sub>0Ed,y/z</sub> [kNm]	M <sub>2,y/z</sub> [kNm]	e <sub>0,z/y</sub> [mm]	e <sub>1,z/y</sub> [mm]	e <sub>0Ed,z/y</sub> [mm]	e <sub>2,z/y</sub> [mm]	e <sub>Ed,z/y</sub> [mm]
y	-800,0	192,9	50,0	17,9	67,9	125,0	63	22	85	156	241
z	-800,0	16,0	0,0	4,5	16,0	0,0	0	6	20	0	20

Biaxial bending

$\lambda_y / \lambda_z$	$\lambda_z / \lambda_y$	$(e_y / h_{eq}) / (e_z / b_{eq})$	$(e_z / b_{eq}) / (e_y / h_{eq})$	Check
4,00	0,25	0,08	12,06	Uniaxial bending

Nonconformity

Nonconformities	
	Second order effects with respect to z-axis are ignored because the slenderness $\lambda$ is below a certain value $\lambda_{lim}$ (see EN 1992-1-1 article 5.8.3.1 (1)).

Slenderness

Axis	l [m]	l <sub>0</sub> [m]	i [mm]	A [-]	B [-]	C [-]	n [-]	$\lambda$ [-]	$\lambda_{lim}$ [-]	$\lambda \leq \lambda_{lim}$
y $\perp$	5,00	10,00	115	0,77	1,21	0,70	0,21	86,60	28,08	2'nd order
z $\perp$	5,00	2,50	115	0,92	1,21	0,70	0,21	21,65	33,74	1'st order

Nominal stiffness

Axis	K <sub>c</sub> [-]	I <sub>c</sub> [mm <sup>4</sup> ]	$\varphi_{err}$ [-]	I <sub>s</sub> [mm <sup>4</sup> ]	k <sub>2</sub> [-]	EI [MNm <sup>2</sup> ]	N <sub>B</sub> [kN]	c <sub>0</sub> [-]	$\beta$ [-]
y $\perp$	0,06	2133333333	1,50	45663540	0,11	13	-1246,6	9,60	1,03
z $\perp$	0,00	2133333333	0,41	45663540	0,00	0	0,0	9,60	0,00


  

Axis	$\theta_1$ [-]	$\alpha_m$ [-]	$\alpha_h$ [-]	$\rho_m$ [-]	M <sub>01</sub> [kNm]	M <sub>02</sub> [kNm]
y $\perp$	0,00	1,00	0,89	1,00	60,0	0,0
z $\perp$	0,00	1,00	0,89	1,00	0,0	0,0

A <sub>c</sub> [mm <sup>2</sup> ]	A <sub>s</sub> [mm <sup>2</sup> ]	k <sub>1</sub> [-]	K <sub>s</sub> [-]	E <sub>cd</sub> [MPa]	$\omega$ [-]	$\varphi$ [-]
160000	1963	1,32	1,00	28397,6	0,23	1,68

### 11.3.1 Ribbon group Recalculation of internal forces



- **Automatic** – if the option is selected, the internal forces including second order effects and imperfections are recalculated after each change in the table of end moments.
- **Start** – calculate internal forces including effect of second order and imperfections for the currently defined end moments.

## 11.4 Load effects on staged sections

- If IDEA RCS is started from superior application, forces staged sections may be set to read only.

Following combinations are used for check of staged sections:


- **Fundamental ULS** – values of internal forces defined in this combination type are used to perform ultimate limit states checks (commands **Checks > Ultimate Limit state** in the navigator) and detailing check.
- **Accidental** - values of internal forces defined in this combination type are used to perform ultimate limit states checks (commands **Checks > Ultimate Limit state** in the navigator).
- **Fatigue** – the basic combination for check of fatigue without the cyclic loads.
- **Fatigue with cyclic loads** - the combination for check of fatigue including the cyclic loads.
- **Characteristics combination** – values of internal forces defined in this combination type are used to perform stress limitation check
- **Frequent combination** – values of internal forces defined in this combination type are used to perform brittle failure check and crack width check.
- **Quasi-permanent combination** – values of internal forces defined in this combination type are used to perform stress limitation check, crack widths check, stiffness check.

Load effects are defined by particular components for staged sections– sum of permanent loads, sum of leading variable actions and sum of accompanying variable actions.

Ribbon groups **Load internal forces** and **Resultant of stage** are available.


Effects of design load (at the time of check)

Combination type	Use	Load type	N [kN]	Vy [kN]	Vz [kN]	T [kNm]	My [kNm]	Mz [kNm]
Fundamental ULS	<input checked="" type="checkbox"/>	Permanent Sum Gdj	0,0	0,0	100,0	0,0	3000,0	0,0
		Variable Sum Qdi	0,0	0,0	80,0	20,0	3000,0	0,0
		Effect of prestressing	-3048,7	0,0	0,0	0,0	-2722,2	61,0
Accidental	<input type="checkbox"/>	Permanent Sum Gdj	0,0	0,0	0,0	0,0	0,0	0,0
		Variable Sum Qdi	0,0	0,0	0,0	0,0	0,0	0,0
		Effect of prestressing	0,0	0,0	0,0	0,0	0,0	0,0
Characteristic	<input checked="" type="checkbox"/>	Permanent Sum Gdj	0,0	0,0	200,0	0,0	2700,0	0,0
		Variable Sum Qdi	0,0	0,0	50,0	0,0	2500,0	0,0
		Effect of prestressing	-3048,7	0,0	0,0	0,0	-2722,2	61,0
Frequent	<input checked="" type="checkbox"/>	Permanent Sum Gdj	0,0	0,0	200,0	0,0	2700,0	0,0
		Variable Sum Qdi	0,0	0,0	0,0	0,0	600,0	0,0
		Effect of prestressing	-3048,7	0,0	0,0	0,0	-2722,2	61,0
Quasi-permanent	<input checked="" type="checkbox"/>	Permanent Sum Gdj	0,0	0,0	200,0	0,0	2700,0	0,0
		Variable Sum Qdi	0,0	0,0	0,0	0,0	0,0	0,0
		Effect of prestressing	-3048,7	0,0	0,0	0,0	-2722,2	61,0





### 11.4.1 Taking load actions from action stages



Components of permanent load actions for particular combinations can be taken from action stages. When taking load action from action stages, sum of all characteristics loads is created from all stages of the same or less age than the is the age of current loads extreme.

To take actions from stages use commands in ribbon **Load internal forces**.

- **All** – takes actions from action stages to all combination types in current loads extreme. Value of characteristic load for fundamental combination is multiplied by coefficient defined in  $\gamma_{Gj,sup}$ .
- **ULS** – takes actions from action stages to ultimate limit state combination in current loads extreme. Value of characteristic load for fundamental combination is multiplied by coefficient defined in  $\gamma_{Gj,sup}$ .
- **SLS** - takes actions from action stages to serviceability limit state combination in current loads extreme.

### 11.4.2 Ribbon group Stage resultant

See DODO

## 12 Concrete reinforcement


For the current section (selected in **Current section** list at the top part of Navigator window) navigator command **Design > Reinforcement** launches the definition of longitudinal and shear reinforcement.

According to the type of current design member and shape of cross-section following ribbon groups are available:

- For beam and compression member: **Input by reinforcement templates, User templates, User settings, Cover, Stirrups, Longitudinal reinforcement, Delete, Import, Export, Cross-section points, Dimension lines and Calculation.**
- For one-way slab: **Input by reinforcement templates, User templates, User settings, Links, Longitudinal reinforcement, Delete, Import, Export, Cross-section points, Dimension lines and Calculation.**
- For two-way slab: **Input by reinforcement templates, User templates, User settings, Longitudinal reinforcement, Delete, Import, Export and Calculation.**

## 12.1 Concrete reinforcement of 1D members

### 12.1.1 Editing cover of 1D sections



To edit concrete cover at particular cross-section edges click **Set** in ribbon group **Cover**.

Values of cover related to particular cross-section edges can be changed in table.

To switch drawing of existing reinforcement switch on/off the option **Draw reinforcement**.


Reinforced cross-section covers

Component/Edge	c [mm]	
1	1/1	30
2	1/2	30
3	1/3	30
4	1/4	30
5	1/5	30
6	1/6	30
7	1/7	30
8	1/8	30
9	1/9	30
10	1/10	30
11	1/11	30
12	1/12	30
13	1/13	30
14	1/14	30
15	2/1	30
16	2/2	30
17	2/3	30
18	2/4	30

Draw reinforcement

OK Cancel

### 12.1.2 Input of 1D members reinforcement by template



Reinforcement templates are available for some pre-defined sectional shapes. Reinforcement templates available for the current

cross-section are displayed in ribbon group **Input by reinforcement templates**.

Click button with required reinforcement template to set the parameters of the inserted template in the settings dialog.

- **Design** – switch on/off design of reinforcement (calculation of required number of bars) when applying reinforcement template – see **12.1.4 Reinforcement design**.
- **Strut optimisation** – switch on/off performing the optimisation of concrete strut during design and check of reinforcement to achieve the optimal utilisation of truss analogy component selected in the code and calculation settings.

Reinforcement template parameters for I-shaped cross-section:

Reinforcement layout for I-shaped cross-section
✕

Longitudinal reinforcement		
Number of upper bars $n_{RB_U}$		17
Upper bars diameter $d_{ULR}$		16 mm
Number of lower bars $n_{RB_L}$		15
Lower bars diameter $d_{LLR}$		16 mm
Number of edge bars $n_{RB_S}$		0
Side bars diameter $d_{SLR}$		10 mm
Steel grade	B 500B	
Stirrups		
Stirrups diameter $d_s$		10 mm
Steel grade	B 500B	
Diameter of mandrel by code	<input checked="" type="checkbox"/>	
Torsion check	<input checked="" type="checkbox"/>	
Stirrups cover $c_s$		30 mm
Stirrups distance		0,08 m
Maximum distance by code	<input checked="" type="checkbox"/>	

**Design summary**

	$A_{s,d}$	$A_{s,p}$	Ratio [%]
Upper layer [ mm <sup>2</sup> ]	3413	3418	99,9
Lower layer [ mm <sup>2</sup> ]	2838	3016	94,1
Stirrups [ mm <sup>2</sup> /m ]	1775	1963	90,4

Recalculate

OK

Cancel

Click **OK** to add the reinforcement into the cross-section.

For some cross-sections templates with special definition of reinforcement layout are available. Those templates enable to input reinforcement bars with different diameters in one reinforcement layer at once.

The reinforcement layer is defined by string, which describes diameters of individual bars in the layer. Individual diameters are separated by space, characters 'x' or '\*' can be used to define multiple diameters, e. g. ,20 16 16 20' or ,20 2\*16 20'.

Reinforcement layout
✕

Main longitudinal reinforcement	
Diameters in upper layer   $l_{U1}$	12x22 mm
Diameters in upper layer   $l_{U2}$	mm
Diameters in lower layer   $l_{L1}$	10x20 mm
Diameters in lower layer   $l_{L2}$	mm
Steel grade	B 500B <span style="float: right;">▼ </span>
Distances between layers	Minimum distance <span style="float: right;">▼</span>
Longitudinal reinforcement for detailing	
Add detailing reinforcement	<input checked="" type="checkbox"/>
Detailing bars diameter $d_{DR}$	10 mm
Longitudinal reinforcement on side of cross-section	
Number of edge bars $n_{RBs}$	0
Side bars diameter $d_{SLR}$	10 mm
Stirrups	
Stirrups diameter $d_s$	10 mm
Steel grade	B 500B <span style="float: right;">▼ </span>
Diameter of mandrel by code	<input checked="" type="checkbox"/>
Torsion check	<input checked="" type="checkbox"/>
Stirrups cover $c_s$	30 mm
Stirrups distance	0,14 m
Maximum distance by code	<input checked="" type="checkbox"/>


**Design summary** ⓘ

	$A_{s,d}$	$A_{s,p}$	Ratio [%]
Upper layer [ mm <sup>2</sup> ]	4185	4562	91,8
Lower layer [ mm <sup>2</sup> ]	3098	3142	98,6
Stirrups [ mm <sup>2</sup> /m ]	1066	1122	95,0

Recalculate

OK
Cancel

### 12.1.3 Input of one-way slabs reinforcement by a template



For one way slabs basic templates to define reinforcement at particular faces are available. Available templates are displayed in the ribbon group **Input by**

**reinforcement templates.**

- **Design** – switch on/off design of reinforcement (calculation of required number of bars) when applying reinforcement template – see **12.1.4 Reinforcement design.**
- **Strut optimisation** – switch on/off performing the optimisation of concrete strut during design and check of reinforcement to achieve the optimal utilisation of truss analogy component selected in the code and calculation settings.

Reinforcement layout for one-way slab

Longitudinal reinforcement		
Upper bars distance $\text{dist RB}_U$		280 mm
Lower bars distance $\text{dist RB}_L$		380 mm
Upper bars diameter $d_U$		10 mm
Lower bars diameter $d_L$		10 mm
Bars material	B 500B	
Cover $c_c$		30 mm

Design summary Recalculate

	$A_{s,d}$	$A_{s,p}$	Ratio [%]
Upper layer [mm <sup>2</sup> ]	276	280	98,5
Lower layer [mm <sup>2</sup> ]	204	207	98,8

OK Cancel

For one way slabs the distance between bars or bars number, bars diameter, bars material and concrete cover are defined in the template dialog.


### 12.1.4 Reinforcement design


The reinforcement design can be performed, when applying reinforcement template on design members of type **Beam** and **One-way slab**.

To perform the design, option **Design** in ribbon group **Input by reinforcement templates** must be switched on.

The design of number of longitudinal reinforcement bars and design of stirrups distance according to the current reinforcement diameters is performed, when launching the dialog of reinforcement template. The design is performed respecting all load extremes, which are assigned to the current reinforced cross-section. ULS checks of capacity N-M-N , shear, torsion, interaction and crack width check should satisfy for the designed reinforcement.

Table of reinforcement areas of longitudinal and shear reinforcement is displayed in the bottom part of reinforcement template dialog:

- **As,d** – designed area of required reinforcement.
- **As,p** – area of real reinforcement of required reinforcement.
- **Ratio** – ratio of designed area to the real reinforcement area.
- **Recalculate** – button gets active after change of reinforcement template parameters. Click the button to perform new design of number of longitudinal reinforcement bars and design of stirrups distance, respecting the current diameters of appropriate reinforcement bars.
-  - displays tooltip describing design assumptions.

Design summary 

Recalculate

	A <sub>s,d</sub>	A <sub>s,p</sub>	Ratio [%]
Upper layer [ mm <sup>2</sup> ]	5066	5309	95,4
Lower layer [ mm <sup>2</sup> ]	2796	2815	99,3
Stirrups [ mm <sup>2</sup> /m ]	1066	1122	95,0

### 12.1.5 Shear reinforcement of 1D members

Shear reinforcement of beams and columns is defined using stirrups. Shear reinforcement of one-way slabs is defined using links.

#### 12.1.5.1 Ribbon group Stirrup




Ribbon group **Stirrups** is available for beam and compression design member1D types.

- **New general** - adds a new stirrup by coordinates of stirrup vertexes and stirrup diameter
- **New around bars** – adds a new stirrup by vertexes defined by selection of longitudinal reinforcement bars.
- **New from points** – adds a new stirrup by vertexes defined by selection of cross-section vertexes.
- **Explode stirrups** - Stirrups defined from templates can be transformed to a generally defined (general) stirrup with editable vertexes. Particular vertexes of stirrup than can be edited as by stirrup defined by points.



### 12.1.5.2 New general stirrup input

The stirrup shape is defined by coordinates of the stirrup vertexes. A vertex is the intersection of two stirrup branches axes.





Particular dialog options:


- **Stirrup diameter** – input value of stirrup diameter.
- **Stirrups material** – select or edit material of stirrup.
- **Shear check** – if the checkbox is checked, stirrup is taken into account for shear check.
- **Torsion check** – if the checkbox is checked, stirrup is taken into account for torsion check.
- **Stirrups distance** – input value of longitudinal distance between stirrups.
- **Diameter of mandrel** – input value of mandrel diameter.
- **Origin of coordinate system** – defined vertex coordinates are related to point, which can be selected in the list. Choose from following options:
  - **Point [0,0]** – vertex coordinates are related to origin of cross-section coordinate system.
  - **Cross-section vertex** – vertex coordinates are related to vertex, which is selected in list below.
- **Import bars** – click to imports the stirrup coordinates from a text file – see more in **Errore. L'origine riferimento non è stata trovata. Errore. L'origine riferimento non è stata trovata.**

### 12.1.5.3 New stirrup around bars of longitudinal reinforcement

Stirrup shape is defined by selection of longitudinal reinforcement bars.

Following two options are available to create selection of bars:

- Sequential selection of bar numbers in **Reinforcement bar** lists .Click  to add new item behind current row. Click  to delete current row.
- Gradually, bars of longitudinal reinforcement are selected by mouse. Stirrup is generated around selected bars. Selected bars are listed in **Reinforcement bars** list. After selection of bars is finished, list of bars (stirrup vertexes) can be edited.




Particular dialog options:

- **Stirrup diameter** – input value of stirrup diameter.
- **Stirrups material** – select or edit material of stirrup.
- **Shear check** – if the checkbox is checked, stirrup is taken into account for shear check.
- **Torsion check** – if the checkbox is checked, stirrup is taken into account for torsion check.
- **Stirrups distance** – input value of longitudinal distance between stirrups.
- **Start selection of bars by mouse** – click to start selection of bars to create stirrup around them.  
If the selection is in progress, command **Start selection of bars** is replaced by commands:
  - **Finish selection of bars** – finishes selection of bars, **Close stirrup** and **Step back** disappear. Stirrup is not closed automatically.
  - **Close stirrup** –closes stirrup creating branch between first and last defined point, finishes selection of bars.
  - **Step back** – deletes last defined stirrup branch.

### 12.1.5.4 New stirrup by cross-section vertexes

Stirrup shape is defined by selection of cross-section vertexes. Particular points determine particular vertexes of stirrup.

Points are selected by mouse in the picture of cross-section. The created stirrup passes through selected points.



Particular dialog options:

- **Stirrup diameter** – input value of stirrup diameter.
- **Stirrups material** – select or edit material of stirrup.
- **Shear check** – if the checkbox is checked, stirrup is taken into account for shear check.
- **Torsion check** – if the checkbox is checked, stirrup is taken into account for torsion check.
- **Stirrups distance** – input value of longitudinal distance between stirrups.
- **Diameter of mandrel** – input value of mandrel diameter.
- **Start selection of points** – click to start selection of points to create stirrup.

If the selection is in progress, command **Start stirrup shape definition** is replaced by commands:

- **Finish selection of points** – finishes selection of points, **Close stirrup** and **Step back** disappear. Stirrup shape is not closed automatically.
- **Close stirrup** – closes stirrup creating branch between first and last defined point, finishes selection of bars.
- **Step back** – deletes last defined stirrup branch.
- **Draw outline points** – switch on/off drawing of points in vertexes of the cross-section outline offset. The offset corresponds to the cover defined at particular cross-section edges.
- **Draw opening points** – switch on/off drawing of points in vertexes of the cross-section opening offset. The offset corresponds to the cover defined at particular opening edges.

- **Draw intersections points** – switch on/off drawing of points in intersections of offset edges of cross-section outline and cross-section opening.

### 12.1.5.5 Editing stirrups

Similarly to the cross-section shape it is possible to edit the selected stirrup. The properties of stirrup are displayed in Data window table.

Stirrups								Vertexes	
Stirrup	Type	∅ [ mm ]	Material	s s [ mm ]	Shear	Torsion	n dm [ - ]	Y [ mm ]	Z [ mm ]
1	Vertexes derived from shape	10	B 500B	200	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1,30	-190	210
2	Vertexes derived from shape	10	B 500B	200	<input checked="" type="checkbox"/>	<input type="checkbox"/>	1,30	-190	120
								190	120
								190	210

According to selected stirrup type, the following properties can be adjusted in Data window:

- For a stirrup created from a template, it is possible to adjust the stirrup diameter, material characteristics and the distance between two adjacent stirrups, check type and radius of mandrel as a multiple of stirrup diameter. The positions of the stirrup vertexes are listed in a Vertex table and can't be changed by the user.
- For separately user defined stirrups, there is a list of coordinates in the Vertex table. In this list, the coordinates are editable by user.

### 12.1.5.6 Exploding stirrups

To convert stirrup created by reinforcement template into general stirrup defined by vertexes click **Explode stirrup** in ribbon group **Stirrups**.

### 12.1.5.7 Ribbon group Links




Use commands in ribbon group **Links** to define shear reinforcement in one-way slabs:

- **New** – add new links into the cross-section.

### 12.1.5.8 New links

Click **New** in ribbon group **Links** to add new links into the cross-section.







Options of **Links** dialog:

- **Diameter** – input diameter of link bar.
- **Material** – select material of link bar.
- **Distance between bars** – input the distance between axes of links in the plane of cross-section.
- **Number of links** – the calculated number of links per meter is displayed.
- **Link layers distance** – input the distance between links along the design beam.
- **Upper edge cover** – input the value of concrete cover at the top edge of the cross-section.
- **Lower edge cover** – input the value of concrete cover at the lower edge of the cross-section.
- **Diameter of mandrel by code** – if the checkbox is selected, the mandrel diameter is calculated automatically according to the national code rules. Otherwise, the requested value of mandrel diameter can be defined.
- **Diameter of mandrel** – input the requested value of mandrel as multiple of link bar diameter.
- **Anchorage length by code** – if the checkbox is selected, the anchorage length of link is calculated automatically according to the national code rules. Otherwise, the requested value of anchorage length can be defined.
- **Anchorage length** – input the requested value of anchorage length.


#### 12.1.5.9 Editing links

The properties of the selected link can be edited in the data window.

Data										
Layers of links										
Link	Ø [ mm ]	n [ /m ]	Distance [ mm ]	A s [ mm <sup>2</sup> ]	Upper cover [ mm ]	Lower cover [ mm ]	s s [ mm ]	n dm [ - ]	Anchorage length [ mm ]	Material
1	6	4.50	222	127	20	20	200	4.00	50	B 500B  
2	6	3.00	333	85	20	20	200	4.00	50	B 500B  

Diameter, distance between axes of links, top cover, bottom cover, distance along the design member, mandrel diameter, anchorage length and material of the links layer can be edited in the **Layers of links** table.

### 12.1.6 User settings of reinforced cross-section



Ribbon group **User setting** contains commands to modify some shear and torsion calculation parameters of reinforced cross-section:

- **Set for shear** – input of user defined dimensions of effective cross-section for shear check.
- **Set for torsion** – input or modification of equivalent thin-shaped cross-section for check of torsion.

#### 12.1.6.1 Input of effective cross-section for shear

If necessary, automatically determined values of effective cross-section for shear check can be modified by user defined values.

To input dimensions of effective cross-section for shear click **Set for shear** in ribbon group **User settings**.

 The dialog box titled 'Parameters for shear check' contains a table with four rows. Each row has a checkbox in the first column, a text label in the second, a numerical value in the third, and a unit in the fourth. At the bottom are 'OK' and 'Cancel' buttons.
 

<input type="checkbox"/>	User value of shear width $b_w$	220	mm
<input type="checkbox"/>	User value of effective depth $d$	1350	mm
<input type="checkbox"/>	User value of lever arm $z$	1215	mm
<input type="checkbox"/>	User value of angle $\theta$	40,0	°


Calculated values of effective cross-section dimensions and overridable values of shear check from code and calculation settings are displayed in dialog. To enable input of user defined values check particular checkbox in first column.



### 12.1.6.2 Input of equivalent cross-section for torsion

Equivalent thin-walled section is used for calculation of torsion. Equivalent cross-section can be calculated using:

- stirrups which are marked as effective for torsion
- area and perimeter of real cross-section
- user defined values of cross-sectional area and perimeter.




Particular options of dialog:

- **Create from real stirrups** – create equivalent thin-walled cross-section using outlines of stirrups, which are marked as effective for torsion. If this option is active, it is possible to click Start stirrup shape definition and adapt shape of stirrups for check of torsion
- **Calculate from area and perimeter** – calculate equivalent thin-walled cross-section using area and perimeter of original cross-section. Diameter, material and stirrups distance are taken from first stirrup, which is marked as effective for torsion.

- **Manual input** – values of area, perimeter and thickness of equivalent thin-walled cross-section including diameter, material and distance of stirrups are specified by user.
- **Start stirrup shape definition** – displays dialog, where shape of stirrup for determination of equivalent cross-section can be edited. Input of shape is done similarly to input of new stirrup shape using cross-section vertexes
- **Default stirrup shape** – restores shape of stirrup, which was defined as effective for torsion.

## 12.1.7 Longitudinal reinforcement

### 12.1.7.1 Ribbon group Longitudinal reinforcement




Group **Longitudinal reinforcement** contains buttons for the definition of longitudinal reinforcement.

- **New in line** - adds a new layer of longitudinal reinforcement defined by coordinates of edge bars.
- **New on edge** - adds a new layer of longitudinal reinforcement related to cross-section edge.
- **Bent-up bars** – input of bent-ups of existing longitudinal reinforcement – see **12.1.7.9 Bent-up bars of longitudinal reinforcement**.
- **New on all edges** – input of new separate longitudinal reinforcement layer on each edge of cross-section at once.
- **New by spacing** – input of new longitudinal reinforcement layer at the edge by the spacing of bars. This input mode is available for one way slabs only.
- **Explode layer** – the longitudinal reinforcement defined from templates can be transformed to separate longitudinal bars with editable coordinates. Exploding of reinforcement layer is not available for reinforcement of 2D members.

### 12.1.7.2 New layer of reinforcement for 1D member by coordinates



To input layer of longitudinal reinforcement defined by coordinates of bars click **New in line** in ribbon group **Longitudinal reinforcement**.



The reinforcement is defined in layers. A layer is defined by the number of bars in the layer, the coordinates of the first bar in the layer, and the coordinates of the last bar in the layer. Bar diameter and material can be assigned to individual layers.


Particular columns of table with longitudinal reinforcement layer:

- **n** – input number of bars in reinforcement layer
- **Ø** – input diameter of bars in reinforcement layer
- **Origin** – select origin, to which coordinates of first bar in layer are related. Position of point can be related to point [0;0] (centre of gravity) or to selected cross-section vertex.
- **Begin Y, Begin Z** – input values of coordinates of first bar in reinforcement layer related to selected origin.
- **Origin** - select origin, to which coordinates of last bar in layer are related. Position of point can be related to point [0;0] (centre of gravity) or to selected cross-section vertex.
- **End Y, End Z** – input values of coordinates of last bar in reinforcement layer towards selected origin.
- **As** – calculated value of reinforcement area in layer is displayed
- **Material** – in the list of available materials select material of bars in reinforcement layer or click edit button to edit material properties.

-  - add new reinforcement layer into the table
-  - delete reinforcement layer from table
- **Draw dimension lines of actual layer** – switch on/off drawing of dimension lines of reinforcement defined in the current reinforcement layer.
- **Import bars** – click to import bar coordinates from a text file – see more in **Errore. L'origine riferimento non è stata trovata. Errore. L'origine riferimento non è stata trovata.**

### 12.1.7.3 New layer of reinforcement for 1D member on edge

To input layer of longitudinal reinforcement at cross-section edge click **New on edge** in ribbon group **Longitudinal reinforcement**.



The reinforcement is defined in layers. A layer is defined by the edge, the number of bars in the layer and cover. Bar diameter and material can be assigned to individual layers.


Particular columns of table with longitudinal reinforcement layer:

- **Edge** – select edge, to which layer of reinforcement is related to.
- **n** – input number of bars in layer.
- **∅** – input diameter of bars in reinforcement layer
- **As** – calculated value of reinforcement area in layer is displayed
- **Material** – in the list of available materials select material of bars in reinforcement layer or click edit button to edit material properties.
- **Cover** – select mode of cover determination in the list. Following modes can be selected:
  - **As defined in cross-section** – values of cover are taken from cross-section shape. Existing stirrups are taken into account.
  - **User defined** – values of cover can be entered in columns **Edge cover**, **Left cover**, **Right cover**
- - add new reinforcement layer to the table.
- - delete reinforcement layer from table.
- **Draw dimension lines of actual layer** – switch on/off drawing of dimension lines of reinforcement defined in the current reinforcement layer.

- **Import bars** – click to import bar coordinates from a text file – see more in **Errore. L'origine riferimento non è stata trovata. Errore. L'origine riferimento non è stata trovata.**

### 12.1.7.4 New longitudinal reinforcement layers on all edges

To input new longitudinal reinforcement layers on all edges of cross-section click **New on all edges** in ribbon group **Longitudinal reinforcement**.



One reinforcement layer is created on each edge of cross-section. Number of bars on the edge is determined automatically respecting the given maximal distance between bars and bars diameter.


Individual dialog options:

- **Bars diameter** – input diameter of bar in the layer.
- **Maximal distance** – input the maximal distance between bars to determine the number of bars on edge.
- **Cover** – input the value of concrete cover, common for all edges.
- **Material** – in the list of available materials select material of bars in reinforcement layer or click edit button to edit material properties.
- **Draw cover** – switch on/off drawing of concrete cover.




### 12.1.7.5 New layers of reinforcement by spacing


Click **New by spacing** in ribbon group **Longitudinal reinforcement** to add new layers of reinforcement defined by bars spacing to the section of one way slab.



The reinforcement is defined by layers. Layer is defined by face, distance between bars, distance of edge bar and concrete cover. Material and diameter can be set for all bars in the layer.

Particular columns of the table:

- **Ø** – input the diameter of bar in the layer.
- **Number** – the calculated number of bars per meter in layer is displayed..
- **Distance** – input the distance between axes of adjacent bars.
- **Edge bar specification** – select the mode to determine the position of the edge bar. One of following modes can be selected:
  - **Symmetrically** – the distance of the first bar from the edge is calculated in such way, that the distances of both edge bars from the edges is the same.
  - **Diameter/2** – the distance of first bar from the edge is set as a half of the bar diameter.
  - **User input** – the required value of the edge bar distance can be defined.
- **Edge bar distance** – input the required value of the edge bar distance (or the calculated value is displayed).
- **As** – the area of reinforcement in the layer is displayed.
- **Surface/Plane** – select the face, to which the layer is defined.
- **Cover** – input the value of concrete cover.
- **Eccentricity** – the calculated value of layer eccentricity to the centroidal plane is displayed.
- **Material** – in the list of available materials select material of bars in reinforcement layer or click edit button to edit material properties.
-  - add new reinforcement layer to the table.

-  - delete reinforcement layer from table.
- **Draw dimension lines of actual layer** – switch on/off drawing of dimension lines of reinforcement defined in the current reinforcement layer.

### 12.1.7.6 Longitudinal reinforcement editing

Similarly to the Cross-section shape it is possible to edit the reinforcement after a bar or stirrup is selected. Then, the properties of reinforcement are shown in Data window table.

### 12.1.7.7 Editing common reinforcement properties




Material and diameter of bars can be mass-edited for all reinforcement bars of longitudinal reinforcement of 1D and 2D members.

Common bar properties can be edited in table **Identical properties for all bars**. If checkbox in column **Identical** is checked, diameter of all bars or material of bars can be set in column **Value**.

If the checkbox **Identical** is checked, column for editing of reinforcement diameter or column for editing of material is not available in main tables for reinforcement editing.

### 12.1.7.8 Editing 1D members longitudinal reinforcement



According to the selected 1D design member's longitudinal reinforcement type, the following properties can be adjusted in Data window:

- For a reinforcement layer created from a template, it is possible to adjust the number of bars in table **Reinforcement layers**. The properties of bars in the selected layer are listed in the table **Layer details**, where the bent-up bars can be defined – see **12.1.7.9 Bent-up bars of longitudinal reinforcement**. Coordinates of individual bars cannot be changed.

Layer	Type	Ø [ mm ]	n	As [ mm <sup>2</sup> ]	Material	Begin Y [ mm ]	Begin Z [ mm ]	End Y [ mm ]	End Z [ mm ]
1	Uniform layer	16	4	804	B 500B	90	202	-90	202
2	Uniform layer	16	4	804	B 500B	-90	-202	90	-202

- For a reinforcement layer defined by the diameters layout it is possible to modify the layout of bars in individual layers, the definition mode of calculation of distance between layers or the distance between layers in table **Reinforcement layers**. The properties of bars in the selected layer are listed in the table **Layer details**, where the bent-up bars can be defined – see **12.1.7.9 Bent-up bars of longitudinal reinforcement**. Coordinates of individual bars cannot be changed.

Reinforcement layers

Layer	Bars in layer 1	Bars in layer 2	Bars in layer 3	Bars in layer 4	Bars in layer 5	As [ mm <sup>2</sup> ]	Material	Distances between layers	User distance [ mm ]
1	2x16					402	B 500B	Minimum distance	
2	3x20					942	B 500B	Minimum distance	

- For a reinforcement layer defined by coordinates of beginning and end point, it is also possible to change the start and end point of a layer in table **Reinforcement layers**. The properties of bars in the selected layer are listed in the table **Layer details**, where the bent-up bars can be defined – see **12.1.7.9 Bent-up bars of longitudinal reinforcement**. Coordinates of individual bars cannot be changed.

Reinforcement layers

Layer	Type	∅ [ mm ]	n	As [ mm <sup>2</sup> ]	Material	First point Origin	distance Y [ mm ]	distance Z [ mm ]	Begin Y [ mm ]	Begin Z [ mm ]	Last point Origin	distance Y [ mm ]	distance Z [ mm ]	End Y [ mm ]	End Z [ mm ]
1	Uniform layer	16	4	804	B 500B	vertex 1	30	30	-120	-220	vertex 1	270	30	120	-220
2	Uniform layer	16	4	804	B 500B	vertex 4	30	-30	-120	220	vertex 4	270	-30	120	220

- For a reinforcement layer defined at cross-section edge, value of cover to particular cross-section edges can be edited in table **Reinforcement layers on cross-section edge**. The properties of bars in the selected layer are listed in the table **Layer details**, where the bent-up bars can be defined – see **12.1.7.9 Bent-up bars of longitudinal reinforcement**. Coordinates of individual bars cannot be changed.

Reinforcement layers

Layer	Type	∅ [ mm ]	n	As [ mm <sup>2</sup> ]	Material	Begin Y [ mm ]	Begin Z [ mm ]	End Y [ mm ]	End Z [ mm ]
1	Uniform layer	16	4	804	B 500B	-112	-212	112	-212
2	Uniform layer	16	4	804	B 500B	112	212	-112	212

- For individual user defined bars, there is a list of coordinates and bends in the **Reinforcement bars** table. Here, the coordinates and bends properties are editable by the user.

Reinforcement bars

Layer	Type	∅ [ mm ]	As [ mm <sup>2</sup> ]	Material	First point Origin	distance Y [ mm ]	distance Z [ mm ]	Y [ mm ]	Z [ mm ]	Bent-up	<sup>s</sup> b [ m ]	α XZ [ ° ]	α YZ [ ° ]
3	Single bar	16	201	B 500B	Point (0,0)	-112	-212	-112	-212	<input type="checkbox"/>			
4	Single bar	16	201	B 500B	Point (0,0)	-37	-212	-37	-212	<input type="checkbox"/>			

- For the one way slab reinforcement layers created by template using the distance between bars the diameter of bars and the distance between centres of adjacent bars can be edited in the table **Reinforcement layers**. The properties of bars in the selected layer are listed in the table **Layer details**. Coordinates of individual bars cannot be changed.

Reinforcement layers

Layer	Type	∅ [ mm ]	n	Distance [ mm ]	As [ mm <sup>2</sup> ]	Material	Begin Y [ mm ]	Begin Z [ mm ]	End Y [ mm ]	End Z [ mm ]
1	Uniform layer	10		250	314	B 500B	-375	65	375	65
2	Uniform layer	10		200	393	B 500B	-400	-65	400	-65

- For the one way slab reinforcement layers created by template using the number of bars in layer the diameter of bars and the number of bars in layer can be edited in the table **Reinforcement layers**. The properties of bars in the selected layer are listed in the table **Layer details**. Coordinates of individual bars cannot be changed.

Reinforcement layers

Layer	Type	Ø [ mm ]	n	As [ mm <sup>2</sup> ]	Material	Begin Y [ mm ]	Begin Z [ mm ]	End Y [ mm ]	End Z [ mm ]
1	Uniform layer	16	6	1206	B 500B	462	62	-462	62
2	Uniform layer	16	8	1608	B 500B	-462	-62	462	-62

- For the one way slab reinforcement layers created by definition of spacing the distance between adjacent bars, the mode of edge bar definition, the distance of the edge bar to the cross-section edge and the cover can be edited in the table **Reinforcement layers for one-way slab**. The properties of bars in the selected layer are listed in the table **Layer details**. Coordinates of individual bars cannot be changed.

Reinforcement layers for one-way slab

Layer	Type	Ø [ mm ]	n [ /m ]	Distance [ mm ]	Edge bar specification	Edge bar distance [ mm ]	As [ mm <sup>2</sup> ]	Surface for cover	Cover [ mm ]	Material
1	Uniform layer	10	5,00	200	Symmetrically	100	393	Lower	20	B 500B
2	Uniform layer	10	5,00	200	User input	195	393	Upper	30	B 500B



If proper checkboxes **Identical** are selected in table **Identical properties for all bars**, diameter or material of reinforcement bar can be changed in this table. If checkboxes are off, diameter or material can be edited in table of particular reinforcement type.


### 12.1.7.9 Bent-up bars of longitudinal reinforcement

Bends on individual bars can be defined in property tables of reinforcement.

To input bends on multiple bars of longitudinal reinforcement click **Bent-up** bars in ribbon group **Longitudinal reinforcement**.

Following two manners are available to create selection of bars:

- Sequential selection of bar numbers in **Reinforcement bar** lists. Click  to add new item behind current row. Click  to delete current row.
- Gradually, bars of longitudinal reinforcement are selected by mouse. Selected bars are listed in **Reinforcement bars** list. After selection of bars is finished, list of bars can be edited.



**Reinforcement bent-up bars** dialog options:

- **Distance of bent-up bars** – input distance between individual bends of bars.
- **Inclination in XZ plane** – input angle of bent-up bar in XZ plane of cross-section (to longitudinal axis of member).
- **Inclination in YZ plane** – input angle of bent-up bar in YZ plane of cross-section (to longitudinal axis of member).
- **Start selection of bars by mouse** – starts to create the selection of bars to be bend.

If the selection is in progress, command **Start selection of bars by mouse** is replaced by commands:

- **Finish selection of bars** – finishes selection of bars, **Clear selection** and **Remove last** disappear.
- **Clear selection** – removes all bar numbers from the selection.
- **Remove last** – deletes last bar number from the selection.

Bent-up bars on individual bar can be defined in property tables of bars, either in the table **Layer details** for the reinforcement defined by layers or in the table **Reinforcement bars** for the individually defined bars.

Layer details

Bar	$\varnothing$ [ mm ]	Material	Y [ mm ]	Z [ mm ]	Bent-up	$s_b$ [ m ]	$\alpha_{XZ}$ [ ° ]	$\alpha_{YZ}$ [ ° ]
1	16	B 500B	90	202	<input type="checkbox"/>			
2	16	B 500B	30	202	<input type="checkbox"/>			
3	16	B 500B	-30	202	<input type="checkbox"/>			
4	16	B 500B	-90	202	<input type="checkbox"/>			

Reinforcement bars


Layer	Type	$\varnothing$ [ mm ]	$A_s$ [ mm <sup>2</sup> ]	Material	First point Origin	distance Y [ mm ]	distance Z [ mm ]	Y [ mm ]	Z [ mm ]	Bent-up	$s_b$ [ m ]	$\alpha_{XZ}$ [ ° ]	$\alpha_{YZ}$ [ ° ]
3	Single bar	16	201	B 500B	Point (0,0)	90	202	90	202	<input type="checkbox"/>			
4	Single bar	16	201	B 500B	Point (0,0)	30	202	30	202	<input type="checkbox"/>			

Bent-up bar is specified using following columns::

- **Bent-up** – switch on/off the bent-up bar.
- $s_b$  – input distance between individual bent-ups.
- $\alpha_{XZ}$  – input angle of bent-up bar in XZ plane of cross-section (to longitudinal axis of member).
- $\alpha_{YZ}$  – input angle of bent-up bar in YZ plane of cross-section (to longitudinal axis of member).


## 12.2 2D members reinforcement

### 12.2.1 Input of 2D members reinforcement by a template



The basic reinforcement templates are available for sections of 2D members.

Bars diameter, angle between layers and the number of bars in the layers can be defined in the dialog for reinforcement input to reinforced cross-sections of 2D members:






### 12.2.2 Input of new bars for 2D member cross-sections



To input layer of longitudinal reinforcement into member 2D cross-section click **New** in ribbon group **Longitudinal reinforcement**.

The reinforcement is defined in layers. The layer is defined by parameters. Some of the parameters are related. It means that changing one of them influences the other(s).



Parameters of one layer:

- $\emptyset$  – input value of bar diameter for all bars in a layer
- **Number /m** - value defines the number of bars per meter in a layer. Value is recalculated after the distance between bars changes.
- **Distance** – input value of distance between bars. Value is recalculated after the number of bars changes.
- **Edge bar specification** – defines the type of calculation of the distance between the edge bars from the slab section edge. One of following modes can be selected:
  - **Symmetrically** – the distance of the first bar from the edge is calculated in such way, that the distances of both edge bars from the edges is the same.
  - **Diameter/2** – the distance of first bar from the edge is set as a half of the bar diameter.
  - **User input** – the required value of the edge bar distance can be defined.
- **Edge bar distance** –calculated value of the edge bar from slab edge. If the **Edge bar specification** is set to **User input**, the value is editable.
- **Angle** –direction of the reinforcement bars
- **As** – calculated reinforcement area
- **Surface/plane** – the surface selection for the definition of reinforcement. It can be the upper, lower or centroidal plane

- **Type of input** – select the mode for definition of the layer position in relation to the slab surface.
  - For the first layer at upper or lower surface following options are available:
    - **By clear cover** – a value entered in the column **Value** defines the distance between the bar's exterior surface and the slab surface.
    - **By axial cover** - a value entered in the column **Value** defines the distance between the bar axis and the slab surface.
  - For the second layer at upper or lower surface additional options are available:
    - **By clear distance from previous** – a value entered in the column **Value** defines the distance between two bar surfaces.
    - **By axial distance from previous** - a value entered in the column **Value** defines the distance between two bar axes.
  - For the centroidal layer following options are available:
    - **Eccentricity** – a value entered in the column **Value** defines the bar axis distance from the centroidal slab plane.
- **Eccentricity** – the calculated value of the bar axis distance from the centroidal slab plane
- **Type** – setting for the reinforcement type. Available options:
  - **Main**
  - **Distribution** – the distribution bars are taken into account only in detailing checks
- **Material** – select reinforcement steel material grade defined for the layer
-  - add new reinforcement layer into the table
-  - delete reinforcement layer from table
- **Import bars** – click to import bar coordinates from a text file – see more in **Errore. L'origine riferimento non è stata trovata.**

### 12.2.3 Editing 2D members longitudinal reinforcement

Reinforcement layers											Identical properties for all bars	
Layer	n	Distance	Type first bar position	First bar position	Angle	As	Surface for cover	Position type	Value	Type	Identical	Value
[/m]		[mm]		[mm]	[°]	[mm <sup>2</sup> ]			[mm]		<input type="checkbox"/>	
1	5.99	167	Distance / 2	84	0.0	677	Lower	By clear cover	20	Vertical	<input checked="" type="checkbox"/>	12
2	5.99	167	Distance / 2	84	90.0	677	Upper	By clear cover	32	Vertical	<input checked="" type="checkbox"/>	B 500B

Layer details				
Bar	Ø	Material	Y	Z
	[mm]		[mm]	[mm]
6	12	B 500B	-334	62
7	12	B 500B	-167	62
8	12	B 500B	0	62
9	12	B 500B	167	62
10	12	B 500B	334	62

According to the selected 2D member's longitudinal reinforcement type, the following properties can be adjusted in Data window:

- Number of bars per meter
- Distance between bars
- Edge bar specification
- Edge bar distance
- Angle of bar direction
- Area of reinforcement
- Value – bar surface distance from slab surface
- Type of reinforcement

If proper checkboxes **Identical** are selected in table **Identical properties for all bars**, diameter or material of reinforcement bar can be changed in this table. If checkboxes are not selected, diameter or material can be edited in table **Reinforcement layers**.

The same rules for input and recalculation of values, which are used when defining new reinforcement, are applied when editing the 2D reinforcement layers.

## 12.2.4 Shear reinforcement of 2D members

### 12.2.4.1 Ribbon group Links




Use commands in ribbon group **Links** to define shear reinforcement in one-way slabs:

- **New** – add new links into the cross-section.

### 12.2.4.2 New links

Click **New** in ribbon group **Links** to add new links into the cross-section.




Options of **Links** dialog:

- **Diameter** – input diameter of link bar.
- **Material** – select material of link bar.
- **Distance in first direction**– input the distance between axes of links in first direction of the cross-section (x-axis).
- **Number of links** – the calculated number of links per meter is displayed.
- **Distance in second direction**– input the distance between axes of links in second direction of the cross-section (y-axis).

- **Upper edge cover** – input the value of concrete cover at the top edge of the cross-section.
- **Lower edge cover** – input the value of concrete cover at the lower edge of the cross-section.
- **Diameter of mandrel by code** – if the checkbox is selected, the mandrel diameter is calculated automatically according to the national code rules. Otherwise, the requested value of mandrel diameter can be defined.
- **Diameter of mandrel** – input the requested value of mandrel as multiple of link bar diameter.
- **Anchorage length by code** – if the checkbox is selected, the anchorage length of link is calculated automatically according to the national code rules. Otherwise, the requested value of anchorage length can be defined.
- **Anchorage length** – input the requested value of anchorage length.
- **First layer angle** – input the angle between rows of links and the first direction of the cross-section (x-axis).


### 12.2.4.3 Editing links

The properties of the selected link can be edited in the data window.

Layers of links										
Link	∅ [ mm ]	Distance x [ mm ]	Distance y [ mm ]	Angle [ ° ]	A s [ mm <sup>2</sup> /m <sup>2</sup> ]	Upper cover [ mm ]	Lower cover [ mm ]	n dm [ - ]	Anchorage length [ mm ]	Material
1	6	200	200	0,0	707	20	20	4,00	50	B 500B 

Diameter, distance between links in the first cross-section direction, distance between links in the second cross-section direction, angle of link rows, upper cover, lower cover, mandrel diameter, anchorage length and material of the links layer can be edited in the **Layers of links** table.

## 12.3 User defined reinforcement templates



The existing reinforcement of cross-section can be stored into the database of user defined reinforcement templates. The stored template can be used to reinforce other sections in the current project or sections in other projects.

Following commands in ribbon group **User templates** are available to work with user templates of reinforcement:


- **Create** – stores the current reinforcement into the database of user reinforcement templates. Dialog **Add template** appears. The target folder must be selected in the tree control in the left part of dialog. The current reinforcement is stored as a template into the selected folder.
- **Apply** – starts input of reinforcement using the user defined reinforcement template – see **12.3.1 Reinforcing by user defined reinforcement template**.
- **Manager** – launches templates manager – see **12.3.2 Templates manager**.

### 12.3.1 Reinforcing by user defined reinforcement template


Dialog **Select template** appears after start of reinforcing by user defined reinforcement template.

Only templates, which have the same cross-section type as the reinforced cross-sections, are available in the tree control in the left part of the dialog.

Select the required template in the tree of available templates. Click **Select** to reinforce the cross-section using the selected template.



### 12.3.2 Templates manager



Template manager is used to manage templates in the database. The templates database collects templates for:

- Reinforcement templates;
- Templates of tendon shapes;
- Templates of connection manufacturing operations.

Template types to be displayed can be selected in the combo box **Filter**.

The templates are stored using the structure of folders and items in folders (similar to the structure of folders and files on drive).

The database structure (with respect to the filter settings) is displayed in the left part of the dialog. Details of selected template or selected folder are displayed in the right part of dialog.

Following actions can be performed in the templates manager:

- **Create new folder** – by command **New folder...** in the main menu to create new folder in the root folder or in the current subfolder.
- **Rename folder** – by command **Edit** in the context menu by right mouse click above the required folder.
- **Move folder** – drag and drop selected folder(s) to the required target folder.

- **Remove folder (s)** – by command **Delete** in the context menu by right mouse click above the selected folder (s). The folder is removed including all subfolders and all templates in removed folders and subfolders.
- **Edit template name and description** – template name and description of selected template is displayed in the right part of the dialog. The template name and description can be modified.
- **Move template** – drag and drop selected template(s) by mouse to the required target folder.
- **Delete template(s)** – by command **Delete** in the context menu by right mouse click above the selected template.
- **Export templates** – by command **Export...** in the main menu. Selected templates are stored into the file with extension \*.EXP. Exported templates can be e.g. used on other computer.
- **Import templates** – by command **Import...** in the main menu. Templates from the selected file with extension \*.EXP are imported into the database of templates.

## 12.4 Deleting reinforcement




Use commands in ribbon group **Delete** to delete reinforcement from cross-section:

- **Selected** – delete selected layer or bar of reinforcement.
- **All** – delete all reinforcement.

## 12.5 Import of reinforced cross-section


- If IDEA RCS is started from superior application, some options of import may not be available.



To import reinforced cross-section (geometry and reinforcement) from text file (format \*.NAV) click **Reinforced cross-section** in ribbon group **Import** - see more in **Errore. L'origine riferimento non è stata trovata. Errore. L'origine riferimento non è stata trovata.**

- **Reinforced cross-section** – start import of cross-section shape including reinforcement from text file
- **Cross-section shape** – start import of cross-section shape from text file
- **Reinforcement** – start import of reinforcement from text file
- **Tendons** – start import of tendons from text file


## 12.6 Export of reinforced cross-section



A reinforced cross-section can be exported to a text file using commands in ribbon group **Export reinforced cross-section**. There are several options:

- **Reinforced cross-section** – exports the cross-section including the reinforcement to a file (format \*.NAV).
- **Cross-section shape** – exports only the cross-section without the reinforcement to a file (format \*.NAV).
- **Reinforcement** – exports only the reinforcement to a file (format \*.NAV).
- **Tendons** – exports only tendons to a file (format \*.NAV)

## 12.7 Numbering of cross-section points




Ribbon group **Cross-section points** can be used to set drawing options of fibre and bar numbers.

- **Fibre** – select mode of fibres drawing in the list. One of following modes can be chosen:
  - **No labels** – description of fibres is not drawn.
  - **Outside** – fibre numbers are drawn outside the cross-section outline
  - **Inside** – fibre numbers are drawn inside the cross-section outline
- **Bar numbers** – turns on/off drawing of reinforcement bar numbers
- **Stirrups shape** – turn on/off drawing of dimensioned stirrups outside the cross-section



## 12.8 Dimensioning of reinforced cross-section



Ribbon group **Dimension lines** can be used to set mode of dimension lines drawing:

- **Not draw** – turns off drawing of dimension lines
- **Standard** – turns on drawing of standard dimension lines of reinforcement.
- **Stationing** – turns on drawing of dimension lines with distances related to reference point

## 13 Check results

The checks can be launched using navigator commands **Checks**.

The cross-section check has a graphical and textual representation. Graphically, the presented results are drawn in the Main dialog window. Results in textual presentation are displayed in the Data window. For the checks, whose graphical presentation is not useful, a picture of reinforced cross-section with overall dimensions and reinforcement data is displayed in the Main window.

The graphical presentation of checks is adjustable by a setting dialog. The setting is saved for the check and later used when the picture is printed into report.

### 13.1 Setting of Check execution of 1D members

Capacity N-M-M	<input type="checkbox"/>
Shear	<input checked="" type="checkbox"/>
Torsion	<input checked="" type="checkbox"/>
Interaction	<input checked="" type="checkbox"/>
Fatigue	<input checked="" type="checkbox"/>
Stress limitation	<input checked="" type="checkbox"/>
Crack width	<input checked="" type="checkbox"/>
Brittle Failure	<input checked="" type="checkbox"/>
Detailing	<input type="checkbox"/>
Response N-M-M	<input checked="" type="checkbox"/>
Stiffnesses	<input checked="" type="checkbox"/>
M-N- $\kappa$ diagram	<input type="checkbox"/>

For the current section, click navigator command **Checks > Setting** to launch the -dialog to select checks, which will be performed in the current section.

Only selected checks are executed. Not selected checks are not calculated and the results are empty. Thus they can't be printed into a report.

- **Capacity N-M-M** – switch on/off the execution of the capacity check.
- **Shear** – switch on/off the execution of the shear check.
- **Torsion** – switch on/off the execution of the torsion check.
- **Interaction** – switch on/off the execution of the check of interaction of normal force, shear force and bending moment.
- **Fatigue** – switch on/off the execution of the fatigue check. This combo box is available only if the fatigue check is switched on in the **Project data** dialog.
- **Stress limitation** – switch on/off the execution of the stress limitation check.
- **Crack width** – switch on/off the execution of the crack width check.
- **Brittle failure** – switch on/off the execution of the brittle failure check. This combo box is available only for prestressed sections and if the code EN 1992-2 is switched on in the **Project data** dialog.
- **Detailing** – switch on/off the execution of the detailing check.
- **Response N-M-M** – switch on/off the execution of the response check.
- **Stiffnesses** – switch on/off the calculation of the stiffnesses of the cross-section.
- **M-N- $\kappa$  diagram** - switch on/off the calculation of the M-N-  $\kappa$  diagrams. This option is available only for Dutch national annex.
- **Unselect all** – unselect all selected checks.
- **Select all** – select all checks.

## 13.2 Setting of Check execution of 2D members

Capacity N-M	<input checked="" type="checkbox"/>
Shear	<input type="checkbox"/>
Interaction	<input checked="" type="checkbox"/>
Fatigue	<input type="checkbox"/>
Stress limitation	<input checked="" type="checkbox"/>
Crack width	<input checked="" type="checkbox"/>
Detailing	<input checked="" type="checkbox"/>
Response N-M	<input checked="" type="checkbox"/>
<input type="button" value="Unselect all"/> <input type="button" value="Select all"/>	

For 2D member sections the following checks are available:

- **Capacity N-M** - switch on/off the execution of the capacity check.
- **Shear** - switch on/off the execution of the shear check.
- **Interaction** - switch on/off the execution of the check of interaction of normal force, shear force and bending moment.
- **Fatigue** - switch on/off the execution of the fatigue check. This combo box is available only if the fatigue check is switched on in the

**Project data** dialog.

- **Stress limitation** - switch on/off the execution of the stress limitation check.
- **Crack width** - switch on/off the execution of the crack width check.
- **Detailing** - switch on/off the execution of the detailing check.
- **Response N-M** - switch on/off the execution of the response check.
- **Unselect all** - unselect all selected checks.
- **Select all** – select all checks.

## 13.3 Setting the evaluated combination

	Fundamental
	Accidental
	Extreme
Combinations	


If the accidental combination is defined and switched on to be used in checks, the evaluation mode of combinations can be set in appropriate checks.

- **Extreme** – switch to evaluate the extreme check values from the fundamental and the accidental combination..
- **Fundamental** – switch to evaluate results for the fundamental combination only.
- **Accidental** – switch to evaluate results for the accidental combination only.

The extreme results are searched when evaluating results of overall checks or when generating the check report.

### 13.4 Setting of the checked direction for 2D members section checks


The checks are executed in the directions of the principal stresses or user defined directions (see **Errore. L'origine riferimento non è stata trovata. Errore. L'origine riferimento non è stata trovata.**)



In the presented checks (graphical and numerical presentation) it is possible to switch between particular directions in which the results of checks are evaluated. In the graphical window an arrow mark is schematically drawn to display the available directions. Clicking the mark the screen switches to another direction.

Available arrows are coloured by

- **Red** - for actual direction
- **Orange** – for direction of the extreme check
- **Blue** – other available directions



Click buttons in ribbon group **Checked directions** to switch between directions. Results for previously/or next checked direction are displayed afterwards.

In the Report, the extreme check is always printed.


### 13.5 Overall check

To display the overview of results for all executed checks in the current section and the current loads extreme click navigator command **Checks > Overall**. In the graphical window the reinforced cross-section with information about longitudinal and shear reinforcement is displayed.

Ribbon group **Components label** is available.

The overview of all check results is displayed in the Data window. The check with the maximal value is labelled as Governing type of check.

Reinforced cross-section : R 1



Concrete : C25/30  
Age : 28,0 d  
Reinforcement : (B 500B)  
3ø22, elevation -327 mm  
Stirrups :  
ø6 - 300 mm  
Cover :  
Upper edge : 30 mm  
Lower edge : 25 mm  
Other edges : 30 mm

---

**Data**

**Overall**

Governing type of check	N <sub>Ed</sub> [ kN ]	M <sub>Ed,y</sub> [ kNm ]	M <sub>Ed,z</sub> [ kNm ]	V <sub>Ed</sub> [ kN ]	T <sub>Ed</sub> [ kNm ]	Value [ % ]	Check
Flexural slenderness	0,00	113,73	0,00			65,86	OK


Type of check	N <sub>Ed</sub> [ kN ]	M <sub>Ed,y</sub> [ kNm ]	M <sub>Ed,z</sub> [ kNm ]	V <sub>Ed</sub> [ kN ]	T <sub>Ed</sub> [ kNm ]	Value [ % ]	Check
Shear	0,00			0,00	0,00	0,00	OK
Torsion					0,00	0,00	OK
Interaction	0,00	0,00	0,00	0,00	0,00	0,00	OK
Stress Limitation		0,00	113,73			44,04	OK
Crack Width		0,00	113,73			45,25	OK
Flexural slenderness	0,00	113,73	0,00			65,86	OK

Limit value of the exploitation of the cross-section      100,00 %

**Nonconformity**

- ⚠ Shear is resisted by concrete, shear reinforcement is required according to detailing provisions, see 6.2.2
- ⚠ Upper or lower design value of internal forces of one of SLS combinations caused to happen concrete stress higher than concrete tensile strength (section is cracked). Based on code and calculation settings it is assumed that the concrete resists no tension in SLS checks for all combinations of current extreme. The assumptions for SLS checks in other extremes of current section are not influenced.
- ⚠ The action of concrete in tension is excluded because the cracks appear, see clause 7.1 (2)
- ⚠ Internal forces caused by fundamental combination of ultimate limit state are equal to zero. That is why the value of the exploitation of the cross-section calculated by interaction diagram is zero too. In such case real reinforcement area in the cross-section is considered for the conditions according to clause 7.4.2 instead of the area of steel required at this section for ultimate limit state. In case that the value of the exploitation is greater than zero, real reinforcement area multiplied by the value of the exploitation is taken as the area of steel required.
- ✅ According EN 1992-1-1 article 7.4.2 check of span/depth is satisfied. Any other calculation of deflection musn't be done.

### 13.5.1 Ribbon group Component labels



- **Reinforcement bars** – show or hide longitudinal reinforcement description in the picture of reinforced cross-section
- **Stirrups** – show or hide stirrups description in the picture of reinforced cross-section
- **Tendons** – show or hide tendons description in the picture of reinforced cross-section
- **Ducts and tubes** – show or hide description of tendon ducts and debonding tubes in the picture of reinforced cross-section.

## 13.6 Ultimate limit state checks

To display the results overview of all executed ultimate limit state checks in the current section and the current loads extreme click navigator command **Checks > Ultimate Limit state**.

The content in the graphical window is the same as described in chapter **13.5 Overall check**. Overview of ultimate limit state checks is displayed in the Data window.

Ribbon group **Components label** is available – see **13.5.1 Ribbon group Component labels**.

## 13.7 Section Capacity check


To execute the capacity check and to display resulting interaction diagrams for the current section and the current loads extreme click navigator command **Checks > Ultimate Limit state > Capacity N-M-N**.

Ribbon groups **Type of results**, **Combinations**, **Checked directions**, **Diagram type**, **Interaction surface section**, **Draw points**, **Grid of interaction surface section**, **Interaction diagram export**, **Colors settings** and **Drawing setting** are available.


In the Main window the interaction diagrams are drawn. In the Data window the text representation is printed.

Either one interaction diagram may be drawn for the current extreme of the current section or all interaction diagrams for all extremes in the current section may be drawn.

Interaction diagram is calculated with respecting effects of prestressing. Thus design values of internal forces without prestressing are used for capacity check.



### 13.7.1 Ribbon group Type of results



Use commands in this ribbon group to switch the modes of interaction diagrams drawing.

- **Extreme** – switch to draw one interaction diagram for the current extreme of the current section.
- **Section** – switch to draw interaction diagrams for all extremes of the current section.



### 13.7.2 Ribbon group Combinations

See 13.3 Setting the evaluated combination.

### 13.7.3 Ribbon group Checked directions

See 13.4 Setting of the checked direction for 2D members section checks.


### 13.7.4 Ribbon group Diagram type



- **Interaction sections** - switch to draw the individual sections of the interaction surface.
- **ULS eccentricity** switch to draw the interaction diagram recalculated to the eccentricity of normal force. (the core of the cross-section). In case that the normal force is zero, a horizontal section in My-Mz plane is drawn.

### 13.7.5 Ribbon group Interaction surface sections

The buttons turn on/off drawings of interaction surface sections.




bending moments  $ME_{d,y}$ ,  $ME_{d,z}$ . If the both sections are zero, the section is drawn in the plane N-My.

- **N - My** – turns on/off drawing of a vertical section of intersection surface through the point  $(0,0,ME_{d,z})$  parallel with the plane N-My.
- **N-Mz** – turns on/off drawing of a vertical section of intersection surface through the point  $(0,0,ME_{d,y})$  parallel with the plane N-Mz.

The buttons on the right side of the ribbon group are used for adjusting the vertical and horizontal scale of interaction diagram, or respectively for a setting of default scale in both directions.


### 13.7.6 Ribbon group Draw points



Buttons turn on/off the drawing of points representing loads in interaction diagram.

- **Loads** - turns on/off the drawing of points representing load effects, i.e. applied design internal forces.
- **Ultimate** – turns on/off drawing of points representing design resistance forces.

### 13.7.7 Grid of interaction surface sections




interaction surface section.

- **User settings** – switch on/off possibility to define user settings of grid distances of interaction surface section. If not selected, the grid setting is determined automatically.
- **Moment** – input step of moment in the grid of

- **Force** -- input step of moment in the grid of interaction surface section.

### 13.7.8 Ribbon group Export of interaction diagram


Interaction diagram can be exported to the text file or into the Microsoft Excel sheet (requires Microsoft Excel to be installed on the workstation).



To export the interaction diagram use commands in ribbon group **Interaction diagram export**:

- **TXT** – export of interaction diagram points to a text file
- **Excel** – run Microsoft Excel and export points of interaction diagram to the first sheet of new workbook.
- **Normal force increment** – value of normal force increment for export of interaction diagram points. The sections on the vertical axis of interaction diagram are generated (parallel to the horizontal axis) respecting the specified value of normal force increment. Intersection points of the section and the curve of interaction diagram are exported to the text file or the Microsoft Excel sheet.


### 13.7.9 Ribbon group Drawing settings



This group is available if **Type of results** is set to **Section**.

- **Extreme** – switch to draw the extremal interaction diagram in the current position.
- **All** – switch to draw all interaction diagrams in the current position.
- **Number** – set the number of interaction diagrams to be drawn. The diagrams with the highest exploitation value are drawn.
- **Position** – set the position on the current design member, for which the interaction diagrams are drawn.

### 13.7.10 Ribbon group Colors settings



This group is available if **Type of results** is set to **Section**.

Use commands in this ribbon group to set the drawing colors of interaction diagrams..

- **Standard** – switch to draw all interaction diagrams in one color – default color for drawing of interaction diagrams.
- **Different colors** – switch to draw each interaction diagram in different color.
- **Legend** – switch on/off drawing of legend describing the points which represents the design resistance forces.

## 13.8 Shear check

To execute the shear check for the current section and the current loads extreme click navigator command **Checks > Ultimate Limit state > Shear**.

In the Main graphical window the reinforced cross-section is displayed with the geometrical, material and overall data about the shear and longitudinal reinforcement. The check itself doesn't have any graphical representation.


In the Data window the detailed text representation of shear check is printed.

Ribbon groups **Combinations**, **Code and calculation settings** and **Resistance region** are available.

### 13.8.1 Ribbon group Combinations

See **13.3 Setting the evaluated combination**.


### 13.8.2 Ribbon group Code and calculation settings



- **Strut optimisation** - switch on/off performing the optimisation of concrete strut during check to achieve the optimal utilisation of truss analogy component selected in the code and calculation settings. If the option is selected, the calculated strut angle is displayed. Otherwise the user

defined value of strut angle can be defined.

### 13.8.3 Ribbon group Resistance area



- **Draw** – switch on/off drawing of shear resistance area. For rectangular and T-sections only.

## 13.9 Torsion check

To execute the torsion check for the current section and the current loads extreme click navigator command **Checks > Ultimate Limit state > Torsion**.

In the Main graphical window the picture of reinforced cross-section and the picture of equivalent thin-walled cross-section are drawn. The check itself doesn't have any graphical representation.

Ribbon groups **Combination** and **Code and calculation settings** are available.

In the Data window a detailed text representation of the torsion check is printed.

### 13.9.1 Ribbon group Combinations

See **13.3 Setting the evaluated combination**.

### 13.9.2 Ribbon group Code and calculation settings

See **13.8.2 Ribbon group Code and calculation settings**.

## 13.10 Interaction check of shear, torsion, bending and normal force

To execute the response check with the interaction of shear, torsion, bending and normal force for the current section and the current loads extreme click navigator command **Checks > Ultimate Limit state > Interaction**.

In the Main graphical window the check is drawn, in the Data window the detailed text representation of the check is printed.

Ribbon groups **Combinations**, **Code and calculation settings**, **View**, **View setting**, **Checked directions**, **Strain**, **Stress**, **Results label**, **Results graph**, **Resultant forces**, **Cross-section**, **Type of results** are available.

### 13.10.1 Ribbon group Combinations

See 13.3 Setting the evaluated combination.

### 13.10.1 Ribbon group Code and calculation settings


See 13.8.2 Ribbon group Code and calculation settings.

### 13.10.2 Ribbon group View



- **2D** – turns on drawing of results in 2D picture (cross-section areas, courses of stress and strain).
- **3D** – turns on drawing of courses of stress and strain of concrete and reinforcement in 3D view.
- **3D forces** – turns on drawing of forces resultants in 3D view.
- **Diagram** - turns on/off drawing of check results as Stress-strain diagrams, draws stress and strain in concrete fibres and reinforcement bars – see 13.10.12 Check by Stress-strain diagram.

### 13.10.3 Ribbon group View setting



- **Rotated css** – turns on/off drawing of cross-section and stress and strain distributions on a rotated cross-section in the way that the neutral axis is horizontal to obtain a larger picture on the screen.
- **Results outside** - turns on/off drawing of a cross-section and stress and strain distributions outside the cross-section. If the stress and strain is drawn inside the cross-section, the strain and stress in concrete and in reinforcement is displayed. The stress in reinforcement bars is not displayed inside the cross-section.

### 13.10.4 Ribbon group Checked directions

See 13.4 Setting of the checked direction for 2D members section checks.


### 13.10.5 Ribbon group Strain



- Set strain courses drawing options. Options for tendons are available only for staged sections.
- **Concrete** - turns on/off drawing of concrete strain distribution.
  - **Reinforcement** – turns on/off drawing of strain in the reinforcement bars.

- **Tendon** – turns on/off drawing of strain in the tendons.
- + - increase the scale of strain display (the strain of concrete and reinforcement are in the same scale).
- -- - decrease the scale of strain display (the strain of concrete and reinforcement are in the same scale).
- + - increase the scale of tendon strain display.
- -- - decrease the scale of tendon strain display.


### 13.10.6 Ribbon group Stress



Set stress courses drawing options. Options for tendons are available only for staged sections.

- **Concrete** - turns on/off display of concrete stress distribution.
- **Reinforcement** - turns on/off display of stress in reinforcement bars.
- **Tendon** - turns on/off display of stress in tendons.
- + - increase the scale of concrete stress drawing (the stress of concrete and reinforcement bars are in different scale).
- -- decrease the scale of concrete stress drawing
- + - increase the scale of stress drawing in the reinforcement bars.
- - - decrease the scale of stress drawing in the reinforcement bars.
- + - increase the scale of stress drawing in the tendons.
- - - decrease the scale of stress drawing in the tendons.


### 13.10.7 Ribbon group Results label



The group provides options for labelling style of results in concrete, reinforcement and tendons. Options for tendons are available only for staged sections.

- **Concrete** – choose labelling style for concrete:
  - **No label** – turns off all the labels.
  - **Extreme** – labels the minimum and maximum strain/stress values in concrete.
  - **All** – labels the strain/stress values in all concrete fibres.
- **Reinforcement** – choose labelling style of reinforcement bars results:
  - **No label** - turns off all the labels in the reinforcement bars.
  - **Extreme** - labels the minimum and maximum strain/stress values in the reinforcement bars.
  - **All** - labels the strain/stress values in all the reinforcement bars.
- **Tendon** – choose labelling style of tendon results:
  - **No label** - turns off all the labels in tendons.
  - **Extreme** - labels the minimum and maximum strain/stress values in tendons.
  - **All** - labels the strain/stress values in all tendons.

### 13.10.8 Ribbon group Results graph




The group provides options to display the courses of stress and strain in concrete, reinforcement and tendons. Options for tendons are available only for staged sections.

- **Concrete** – choose graph style of concrete results:


- **Line** – draws the outline of the graph of stress and strain courses in concrete.
- **Hatch** – draws hatched graph of stress and strain courses in concrete.
- **Fill** – draws graph of stress and strain courses in concrete filled with colour.
- **Reinforcement** - choose graph style of results in reinforcement:
  - **Line** – draws the reinforcement bars in graph of stress and strain courses as lines.
  - **Outline** – draws the outline of reinforcement bars in graph of stress and strain courses.
  - **Fill** – draws the filled outline of reinforcement bars in graph of stress and strain courses.
- **Tendon** - choose graph style of results in tendons:
  - **Line** – draws the tendons in graph of stress and strain courses as lines.
  - **Outline** – draws the outline of tendons in graph of stress and strain courses.
  - **Fill** – draws the filled outline of tendons in graph of stress and strain courses.

### 13.10.9 Ribbon group Resultant forces



- **Fc** - shows/hides the position of the resultant of the concrete compression zone.
- **Frt** - shows/hides the position of the resultant of the tensile reinforcement.
- **Frc** - shows/hides the position of the resultant of the reinforcement in compression.
- **Ftt** - shows/hides the position of the resultant of the tendons.
- **Ac** - shows/hides the hatching of the concrete compression zone.
- **Dimension lines x, d** - shows/hides the dimension lines for the depth of the compression zone and the effective depth of cross-section.
- **Dimension lines of results positions** - shows/hides the dimension lines for the positions of resultant forces.

### 13.10.10 Ribbon group Cross-section



- **Dimension lines** - shows/hides the dimension lines for the cross-section geometry and the centre of gravity.
- **Fibre** – the list-box provides three options to draw the fibre labels:
  - - **Outside** of the outline of the cross-section;
  - **Inside** of the outline of the cross-section;
  - **No label**.
- **Bars numbers** - shows/hides the bar numbers.
- **Tendons numbers** - shows/hides the tendon numbers.
- **Extreme fibre** - highlights the extremely loaded fibre (s).
- **Extreme bar** - highlights the extremely loaded reinforcement bar(s).
- **Extreme tendon** – highlights the extremely loaded tendon(s).
- + - makes the concrete fibre and extreme reinforcement/tendons labels larger.
- -- - makes the concrete fibre and extreme reinforcement/tendons labels smaller.

Options for tendons are available only for staged sections.

### 13.10.11 Ribbon group Type of results



To set which graphs of stress-strain courses should be displayed, use buttons in ribbon group **Type of results**. This group is available only for staged sections.

- **Initials** – turns on/off drawing of courses of stress and strain caused by prestressing and permanent component of load effects.
- **Increment** – turns on/off drawing of courses of stress and strain caused by effects of variable loads in current loads extreme.
- **Total** – turns on/off drawing of courses of stress and strain caused by all effects (initials and variable loads) in current loads extreme.

Options for tendons are available only for staged sections.





### 13.10.12 Check by Stress-strain diagram


To launch the check using a stress/strain diagram click **Diagram** in ribbon group **Check**. This option displays the stress/strain of the concrete fibres and reinforcement bars in a stress/strain diagram.

In the displayed picture the concrete fibre or the reinforcement bar can be reviewed by double-clicking with the left mouse button. For this selected part the stress-strain diagram is displayed for steel or concrete elements with display of position of inserted member. Positioning the mouse over the reinforcement bar or the concrete fibre displays the information bubble with the numerical values for the inserted element.

Ribbon groups **Cross-section**, **Label extremes** and **Stress-strain relationships** are available.



### 13.10.12.1 Ribbon group Cross-section



- **Fibre** - the list-box provides three options to draw the fibre labels:
  - - **Outside** of the cross-section;
  - **Inside** of the outline of cross-section;
  - **No label**.

- **Bars numbers** - shows/hides the bar numbers.
- **Tendon numbers** – shows/hides the tendon numbers.
- **Extreme fibre** - highlights the extremely loaded fibre(s).
- **Extreme bar** - highlights the extremely loaded reinforcement bar(s).
- **Extreme tendon** - highlights the extremely loaded tendon(s).
- + - makes the concrete fibre labels larger.
- -- - makes the concrete fibre labels smaller.

Options for tendons are available only for staged sections.


### 13.10.12.2 Ribbon group Label extremes



- **Fibre** - shows/hides the stress and strain values at the most loaded fibre(s).
- **Bar** - shows/hides the stress and strain values at the most loaded reinforcement bar.
- **Tendon** - shows/hides the stress and strain values at the most loaded tendon.

Options for tendons are available only for staged sections.

### 13.10.12.3 Ribbon group Stress-strain relationships



- **Draw points** - shows/hides the values of points on parabolic part of stress-strain interaction.
  - + - increase the number of points on parabolic part of stress-strain relationship.
  - -- - decrease the number of points on parabolic part of stress-strain relationship.

## 13.11 Fatigue check

To execute the Fatigue check for the current section and the current loads extreme click navigator command **Checks > Serviceability limit state > Fatigue**.

Ribbon groups **View**, **View setting**, **Checked directions**, **Strain**, **Stress**, **Results label**, **Result graph**, **Results**, **Cross-section**, **Type of results** and **Fatigue combination** are available.

In the Main graphical window the check is displayed, in the Data window the detailed text representation of the check is printed.

### 13.11.1 Ribbon group View

See 13.10.2 Ribbon group View.

### 13.11.2 Ribbon group View setting

See 13.10.3 Ribbon group View setting.

### 13.11.3 Ribbon group checked directions

See 13.4 Setting of the checked direction for 2D members section checks.

### 13.11.4 Ribbon group Strain

See 13.10.5 Ribbon group Strain.

### 13.11.5 Ribbon group Stress

See 13.10.6 Ribbon group Stress

### 13.11.6 Ribbon group Results label

See 13.10.7 Ribbon group Results label.

### 13.11.7 Ribbon group Results graph

See 13.10.8 Ribbon group Results graph.

### 13.11.8 Ribbon group Resultant forces

See 13.10.9 Ribbon group Resultant forces.


### 13.11.9 Ribbon group Cross-section

See 13.10.10 Ribbon group Cross-section.

### 13.11.10 Ribbon group Type of results

See 13.10.11 Ribbon group Type of results.

### 13.11.11 Ribbon group Fatigue combination



Use this ribbon group to set the combination for drawing of stress and strain courses of the cross-section.

- **Basic** – switch to draw results for the basic fatigue combination.
- **With cyclic load** – switch to draw results for the fatigue combination including the cyclic loads.

### 13.12 Serviceability limit state (SLS)

To display the overview of Serviceability limit state checks executed for the current section and the current load extreme click navigator command **Checks > Serviceability limit state**.

Ribbon group Components label is available – see **13.5.1 Ribbon group Component labels**.

The graphical representation of the SLS check is same as the representation described in chapter **13.5 Overall check**.

Overview of serviceability limit state checks is displayed in the Data window.

## 13.13 Stress limitation check

To execute the Stress limitation check for the current section and the current loads extreme click navigator command **Checks > Serviceability limit state > Stress limitation**.

Ribbon groups **View**, **View setting**, **Checked directions**, **Strain**, **Stress**, **Results label**, **Result graph**, **Results**, **Cross-section**, **Stiffness** and **Type of results** are available.

In the Main graphical window the check is displayed, in the Data window the detailed text representation of the check is printed.

### 13.13.1 Ribbon group View

See 13.10.2 Ribbon group View.

### 13.13.2 Ribbon group View setting

See 13.10.3 Ribbon group View setting

### 13.13.3 Ribbon group checked directions

See 13.4 Setting of the checked direction for 2D members section checks

### 13.13.4 Ribbon group Strain

See 13.10.5 Ribbon group Strain.

### 13.13.5 Ribbon group Stress

See 13.10.6 Ribbon group Stress

### 13.13.6 Ribbon group Results label

See 13.10.7 Ribbon group Results label

### 13.13.7 Ribbon group Results graph

See 13.10.8 Ribbon group Results graph.

### 13.13.8 Ribbon group Results



- **Dimension lines x, d** – shows/hides the dimension lines for the position of neutral axis.

### 13.13.9 Ribbon group Cross-section

See 13.10.10 Ribbon group Cross-section

### 13.13.10 Ribbon group Stiffness



Buttons in this group enable to switch between drawing of results with taking into account short-term stiffness and calculation or taking into account long-term stiffness. Picture of stress and strain courses are drawn for selected stiffness.

This ribbon group is not available for staged section.

### 13.13.11 Ribbon group Type of results

See **13.10.11 Ribbon group Type of results**.


## 13.14 Crack width check

To execute the Crack width check for the current section and the current loads extreme click navigator command **Checks > Serviceability limit state > Crack width**.

Ribbon groups **View**, **Checked directions**, **View setting**, **Strain**, **Stress**, **Results label**, **Results graph**, **Results**, **Cross-section** and **Stiffness** are available.

In the Main graphical window the check is drawn, in the Data window the detailed text representation of the check is printed.

### 13.14.1 Ribbon group View



- **2D** – turns on drawing of results in 2D picture (cross-section areas, courses of stress and strain)
- **3D** – turns on drawing of courses of stress and strain of concrete and reinforcement in 3D view
- **Crack in slabs** – turns on drawing of crack in slabs. This button is available only for 2D sections.

### 13.14.2 Ribbon group checked directions

See 13.4 Setting of the checked direction for 2D members section checks

### 13.14.3 Ribbon group View setting

See 13.10.3 Ribbon group View setting.

### 13.14.4 Ribbon group Strain

See 13.10.5 Ribbon group Strain

### 13.14.5 Ribbon group Stress

See 13.10.6 Ribbon group Stress

### 13.14.6 Ribbon group Results label

See 13.10.7 Ribbon group Results label

### 13.14.7 Ribbon group Results graph

See 13.10.8 Ribbon group Results graph.

### 13.14.8 Ribbon group Results

See 13.13.8 Ribbon group Results

### 13.14.9 Ribbon group Cross-section

See 13.10.10 Ribbon group Cross-section, except buttons for highlighting of extreme fibres, which has no sense for crack width check.

### 13.14.10 Ribbon group Type of results

See 13.10.11 Ribbon group Type of results.

### 13.14.11 Ribbon group Stiffness

See 13.13.10 Ribbon group Stiffness.

### 13.14.12 Ribbon group Crack



This group is available when drawing of crack on slabs is active after clicking **Crack in slabs** in ribbon group **View**.

The crack size can be adjusted by clicking the button for scale increase/decrease.



### 13.15 Flexural slenderness check

To execute the flexural slenderness check according to article EN 1992: 7.4.2 for the current section and the current loads extreme click navigator command **Checks > Serviceability limit state > Flexural slenderness**.

In the Main graphical window the static scheme of beam with supports and effective length is drawn.

In the Data window a detailed text representation of the flexural slenderness check is printed.

### 13.16 Brittle failure check

To execute the brittle failure check for the current section and the current loads extreme click navigator command **Checks > Serviceability limit state > Brittle failure**.

This check is available only for prestressed reinforced sections for code EN 1992-2.

Graphical scheme of reinforced cross-section is drawn in Main window.

In the Data window detailed the text representation of the brittle failure check is printed.

### 13.17 Detailing check

To execute the check of the detailing rules for the current section and the current loads extreme click navigator command **Checks > Detailing**.

The content in the Main graphical window is the same as described in chapter **13.5 Overall check**.

In the Data window detailed the text representation of the detailing rules check is printed.

### 13.18 Advanced analysis

To run special checks and analysis for the current section and the current loads extreme click navigator commands in group **Checks > Advanced analysis**:

- Check of response
- Calculation of cross-section stiffnesses
- Calculation of M-N-k diagram – for Dutch national annex.

The content of graphical window is the same as for **13.5 Overall check**.

## 13.19 Response check

To execute the check of cross-section response for the current section and current loads extreme click navigator command **Checks > Advanced analysis > Response N-M-M**.

In the Main graphical window the check is drawn, in the Data window the detailed text representation of the check is printed.

Ribbon groups **Combinations, View, View setting, Checked directions, Strain, Stress, Results label, Results graph, Resultant forces, Cross-section** and **Type of results** are available.

### 13.19.1 Ribbon group Combinations

See **13.3 Setting the evaluated combination**.

### 13.19.2 Ribbon group View

See **13.10.2 Ribbon group View**.

### 13.19.3 Ribbon group View setting

See **13.10.3 Ribbon group View setting**.

### 13.19.4 Ribbon group checked directions

See **13.4 Setting of the checked direction for 2D members section checks**.

### 13.19.5 Ribbon group Strain

See **13.10.5 Ribbon group Strain**.

### 13.19.6 Ribbon group Stress

See **13.10.6 Ribbon group Stress**

### 13.19.7 Ribbon group Results label

See **13.10.7 Ribbon group Results label**.

### 13.19.8 Ribbon group Results graph

See **13.10.8 Ribbon group Results graph**.

### 13.19.9 Ribbon group Resultant forces

See **13.10.9 Ribbon group Resultant forces**.

### 13.19.10 Ribbon group Cross-section

See **13.10.10 Ribbon group Cross-section**.

### 13.19.11 Ribbon group Type of results

See **13.10.11 Ribbon group Type of results**.

## 13.20 Stiffness calculation

To execute the short and long term stiffnesses calculation of the cross-section for the current section and loads extreme click navigator command **Checks > Advanced analysis > Stiffnesses**.

Ribbon groups **View**, **View setting**, **Strain**, **Stress**, **Results label**, **Results graph**, **Results**, **Cross-section**, **Type of results** and **Stiffness** are available.

In the Main graphical window the check is drawn, in the Data window the detailed text representation of the calculation is printed.

### 13.20.1 Ribbon group View

See 13.10.2 Ribbon group View. Buttons **3D forces** and **Diagrams** are not available.

### 13.20.2 Ribbon group View setting

See 13.10.3 Ribbon group View setting.

### 13.20.3 Ribbon group Strain

See 13.10.5 Ribbon group Strain

### 13.20.4 Ribbon group Stress

See 13.10.6 Ribbon group Stress

### 13.20.5 Ribbon group Results label

See 13.10.7 Ribbon group Results label

### 13.20.6 Ribbon group Results graph

See 13.10.8 Ribbon group Results graph.

### 13.20.7 Ribbon group Results

See 13.13.8 Ribbon group Results

### 13.20.8 Ribbon group Cross-section

See 13.10.10 Ribbon group Cross-section, except buttons for highlighting of extreme fibres, which has no sense for stiffnesses calculation.

### 13.20.9 Ribbon group Stiffness

See 13.13.10 Ribbon group Stiffness.

### 13.20.10 Ribbon group Type of results

See 13.10.11 Ribbon group Type of results.


## 13.21 Calculation of M-N- $\kappa$ diagram

To run the calculation of M-N- $\kappa$  diagram for the current section and the current loads extreme click navigator command **Checks > Advanced analysis > M-N- $\kappa$** .

Ribbon groups **View**, **M-N- $\kappa$** , **View setting**, **Strain**, **Stress**, **Results label**, **Results graph**, **Results** and **Cross-section** are available.


In the Main graphical window the check is drawn, in the Data window the detailed text representation of the calculation is printed.

### 13.21.1 Ribbon group View



- **2D** – turns on drawing of results in 2D picture (cross-section areas, courses of stress and strain)
- **3D** – turns on drawing of courses of stress and strain of concrete and reinforcement in 3D view
- **M-N- $\kappa$**  – turns on drawing of M-N- $\kappa$  diagram

### 13.21.2 Ribbon group M-N- $\kappa$



Use commands in ribbon group **M-N- $\kappa$**  to set the drawing of M-N- $\kappa$  diagram.

- **ULS** – switch to drawing of diagram on ULS or drawing of stress-strain courses on ULS and the selected moment of the diagram.
- **Short** - switch to drawing of diagram for short term effect of load actions or drawing of stress-strain courses for short-term effects and the selected moment of the diagram.
- **Long** - switch to drawing of diagram for long term effect of load actions or drawing of stress-strain courses for long-term effects and the selected moment of the diagram.
- **Mr** – switch to drawing of stress-strain courses for the current diagram type and moment on concrete cracking
- **Mc** – switch to drawing of stress-strain courses for the current diagram type and moment on concrete plasticity
- **Ms** – switch to drawing of stress-strain courses for the current diagram type and moment on reaching yield strength of reinforcement steel.
- **Mu** – switch to drawing of stress-strain courses for the current diagram type and moment on ultimate limit state

### 13.21.3 Ribbon group View setting

See **13.10.3 Ribbon group View setting**.

### 13.21.4 Ribbon group Strain

See **13.10.5 Ribbon group Strain**

### 13.21.5 Ribbon group Stress

See **13.10.6 Ribbon group Stress**

### 13.21.6 Ribbon group Results label

See **13.10.7 Ribbon group Results label**

### **13.21.7 Ribbon group Results graph**

See **13.10.8 Ribbon group Results graph**

### **13.21.8 Ribbon group Results**


See **13.13.8 Ribbon group Results**

### **13.21.9 Ribbon group Cross-section**

See **13.13.9 Ribbon group Cross-section**



## 14 Report for the current section




Click navigator command **Report** to create new report for the current section. Ribbon groups **Report** and **Print** are available. Click **Setting** in group **Report** to launch setting dialog for the report of the project – see **5.5.1 Global report setting**.

Commands in ribbon group **Print**:

- **Print** –print of the report to the selected print device
- **Preview** – display print preview of the report
- **Save as** – save the report to the file of HTML, MHT (web archive including pictures) or TXT format.

### 14.1 Report setting

The report setting of the current section is available after clicking navigator command **Report** > **Setting**. The executed checks in the current section (making a selection is described in **13.1 Setting of Check execution of 1D members**) are enabled to be printed into report.

Click edit button  to specify, which tables should be printed into report for particular check. If check has graphical representation, it is possible to set picture name and size.

Report setting	P 2
<b>Data</b>	
Load effects	<input checked="" type="checkbox"/>
Action Stages	<input checked="" type="checkbox"/>
Losses	<input checked="" type="checkbox"/> 
<b>Checks - Ultimate Limit States</b>	
Capacity N-M-M	<input checked="" type="checkbox"/> 
Shear	<input checked="" type="checkbox"/> 
Torsion	<input checked="" type="checkbox"/> 
Interaction	<input checked="" type="checkbox"/> 
<b>Checks - Serviceability Limit States</b>	
Stress limitation	<input checked="" type="checkbox"/> 
Crack width	<input checked="" type="checkbox"/> 
<b>Checks - Detailing</b>	
Detailing	<input type="checkbox"/> 
<b>Advanced analysis</b>	
Response N-M-M	<input checked="" type="checkbox"/> 
Stiffnesses	<input checked="" type="checkbox"/> 
M-N-k diagram	<input type="checkbox"/> 
<b>Setting</b>	
Nonconformity tables	<input type="checkbox"/>
Explanation tables	<input type="checkbox"/>
Result pictures	<input type="checkbox"/>
Only critical extreme	<input checked="" type="checkbox"/>
<input type="button" value="Unselect All"/> <input type="button" value="Select All"/>	

If the report check setting is launched by navigator command **Report** > **Setting** the setting made in **Checks** > **Settings** is reflected in displayed dialog. Unmarked checks (not calculated

checks) have unavailable print setting and are invisible for print – the print is not possible because the checks weren't calculated. For the checks that have been turned on for calculation, it is possible to turn on/off the print of the current section.

If the report setting is launched by clicking button **Setting** in group **Report**, the setting to turn on/off the print of check is available for all checks without respect whether the check was activated to be calculated or not.

The edit box **Report setting** shows the name which is assigned to the current section (which has been inserted at the Navigator). The Report setting name is not editable here. To edit the Report setting name go to **Report setting** for the project – see **5.8 Ribbon group Report**

#### 14.1.1 Group Data

It adds tables of input data which can be inserted to Report for current section. The table of load effects according to input described in **Errore. L'origine riferimento non è stata trovata. Errore. L'origine riferimento non è stata trovata.** can be added. Automatically, for compression members it adds the table with recalculated values of inner forces, biaxial bending and stiffness.

#### 14.1.2 Group checks

It adds results of calculated checks activated to current section. For each check it is possible to change print setting (setting of tables and pictures) - see **14.1.4 Detailed protocol setting for check captions**

#### 14.1.3 Group Setting

Turning on/off options in group setting shows/hides the items in the report.

**Nonconformities tables** – if the option is turned off then no nonconformity table is shown in the report. In other case the tables are displayed if they haven't been switched off in detailed setting.

**Explanation tables** – if the option is turned off then no explanation table is shown in the report. In other case the tables are displayed if they haven't been switched off in detailed setting.

**Result pictures** – if the option is turned off then no picture with graphical presentation of results is shown in the report. In other case pictures are displayed if they haven't been switched off in detailed setting.

**Only critical extreme** – if the option is turned on for section with more loads extremes, the result is printed only for loads extreme, which causes the maximal value of exploitation. Otherwise results are printed for each loads extreme in section.

### 14.1.4 Detailed report setting for check chapters

Output items of selected check to be printed in the protocol	
<b>Tables</b>	
Nonconformities table	<input checked="" type="checkbox"/>
Explanations table	<input checked="" type="checkbox"/>
<b>Pictures</b>	
Picture Name	Print
Section N - Mres	<input checked="" type="checkbox"/>
Section N - My	<input checked="" type="checkbox"/>
Section N - Mz	<input checked="" type="checkbox"/>
Horizontal section	<input checked="" type="checkbox"/>
Eccentricity at ULS	<input checked="" type="checkbox"/>
Height of pictures	350
Width of pictures	500

**Nonconformity table** – turns on/off the print of nonconformity table into the report for edited check.

**Explanation table** – turns on/off the print of table with explanation of symbols into report for edited check.

**Pictures** – there are listed available graphical presentations of results for edited check. The picture name and option to print or not is available.

**Height and width of pictures** – setting for picture size in pixels.

## 14.2 Standard report

Click navigator command **Report > Standard** to create the standard report for the current section. Standard report contains only tables with overall check results of selected check types. The content of Standard report can be changed only by selection of performed check types – see **13.1 Setting of Check execution of 1D members**. To display detailed outputs of all data and checks **Detailed report** has to be generated..

Main
☰ ✕

### 1.1. Section S 2

Member : M 2  
Reinforced Cross-Section : R 2

Reinforced cross-section

#### 1.1.1. Overall

Governing type of check	Value [ % ]	Limit [ % ]	Check
Detailing	43,75	100,00	OK

#### 1.1.2. Capacity N-M-M

N Ed [ kN ]	M Ed,y [ kNm ]	M Ed,z [ kNm ]	Type	Value [ % ]	Limit [ % ]	Check
0,00	30,00	0,00	NuMuMu	7,99	100,00	OK

#### 1.1.3. Response N-M-M

N Ed,y [ kN ]	M Ed,y [ kNm ]	M Ed,z [ kNm ]	Extreme in fibre	Extreme in bar	Extreme in tendon	Value [ % ]	Limit [ % ]	Check
0,00	30,00	0,00	12	20007		8,93	100,00	OK


## 14.3 Detailed report

Click navigator command **Report > Detailed** to create the detailed report for the current section. The report includes tables with input data and results overview according to setting described in chapter **13.1 Setting of Check execution of 1D members**.

Main
☰

### 2.1. Section S 2

Member : M 2  
Reinforced Cross-Section : R 2



Concrete : C30/37  
Reinforcement : (B 500A)  
4ø16, elevation 352mm  
2ø16, elevation 268mm  
2ø16, elevation -268mm  
4ø16, elevation -352mm  
Stirrups :  
ø10 - 200mm  
ø10 - 200mm  
ø10 - 200mm  
Cover :  
Upper edge : 30mm  
Lower edge : 30mm  
Other edges : 30mm

Reinforced cross-section

#### 2.1.1. Load effects - internal forces

Load type	Combination type	Load Position	N [ kN ]	Vy [ kN ]	Vz [ kN ]	T [ kNm ]	My [ kNm ]	Mz [ kNm ]
Total	ULS	Current	0,00	0,00	50,00	0,00	30,00	0,00
Total	Frequent	Current	0,00	0,00	0,00	0,00	0,00	0,00
Total	Characteristic	Current	0,00	0,00	0,00	0,00	0,00	0,00
Total	Quasi permanent	Current	0,00	0,00	0,00	0,00	0,00	0,00

#### 2.1.2. Overall

Governing type of check	Value [ % ]	Limit [ % ]	Check
Detailing	43,75	100,00	OK

Type of check	Value [ % ]	Limit [ % ]	Check
Capacity N-M-M	7,99	100,00	OK
Response N-M-M	8,93	100,00	OK
Shear	39,09	100,00	OK
Torsion	0,00	100,00	OK
Interaction	39,09	100,00	OK
Lateral Shear	0,00	100,00	OK
Stress Limitation	0,00	100,00	OK
Crack Width	0,00	100,00	OK
Deflection	0,00	100,00	OK
Detailing	43,75	100,00	OK

**Nonconformity**


## 15 Code and calculation settings

Click button **Code** in ribbon group **Setting** to set the national code values and calculation variables.

Code dependent variables are grouped according to chapters and articles (clauses) of the code. Last group **General** contains settings of general (not code dependent) calculation values.

If national annex is enabled (using command **Code** in **Project data** dialog), values of national annex can be changed or default value of EC code can be used.

To display tooltip with detailed information about code variable point mouse cursor on row with code variable.




**Restore all values** – resets all values of code settings for EC and current national annex to default code and annex values.

**Restore NA values** – resets values of current national annex to default annex values.

**Save setup** – saves current code settings to file. Saved settings can be loaded into other project clicking **Code** button in **Project data** dialog. To display **Project data** dialog click **Project data** in ribbon group **Settings**.

**Find** – after entering a value in the text box, this function filters out those available code variables that contain the entered value of the article number.

**Grouping** – turns on/off the grouping of code variables by chapter. When grouping is on, you can collapse or expand individual chapters of code variables.



**Filtering** – turns on/off the filtering of code variables by chapter. When filtering is on, you can choose filtering criteria **By member** or **By check**.

**Expand all/Collapse all** – when grouping is on, you can expand or collapse all the code variable chapters.

Column **Clause** – numbers of particular code clauses are displayed in this column.

Column **Name** – names of code variables are displayed in this column.

Column **Value** – code variable values can be edited in this column. If there is a checkbox at code value, it can turn the value on/off to be taken into account or neglected in the check. Values of code variables can be edited only if column **Code** is set to EC-EN.

Column **Value NA** – value of national annex can be edited in this column if national annex value is available for particular code setting item. Values of annex variables can be edited only if column **Code** is set to national annex.


Column **Code** – flag in column indicates, which code is active for particular code setting item. Click flag icon to switch between national annex and EC code.



## 16 Application setting

### 16.1 Units setting

The units used by the application can be set by clicking button **Units** in ribbon group **Settings** of the page **Home**. The setting of units is valid for the instance (current run of the software) of the application. Settings are not automatically saved with the project.



Variables for which you can set the units are grouped into various categories that are displayed in the column on the left of the dialog 'main', 'material' and 'results'. The selected group is shown in a table of variable values for which user defined units are displayed. For each variable in the column **Unit** one of the available units can be set.

For each value the number of displayed decimal places can be set in the column **Decimals**.

For each value the format of number can be set pushing a button in Format column:

**D** –displays number in standard decimal format (“-ddd.ddd...”). The precision specifier indicates the desired number of decimal places.

**S** –displays number in scientific (exponential) format (“-d.ddd...E+ddd”). The precision specifier indicates the desired number of decimal places.

**A** – automatically chooses to displays number either in decimal or in exponential format according to length of resulting string. The precision specifier defines the maximum number of significant digits that can appear in the result string

To use the current changed units in the next application run, you must save them by clicking **Save** button.

**Save** - click this button to save the current configuration of units to a file with user settings. The saved setting of units are re-used next time you run the application.

**Import** - reads the units configuration from a file. To use the imported units in the next application run, you must save them by clicking **Save** button.

**Export** - saves the current units settings to anfile.


**Default** - sets the current units as default units. These units are stored and distributed within the application. To use default units in the next application run, you must save them by clicking **Save** button.

## 16.2 Application global settings

To change colours, line thicknesses, text heights settings click button **Application** in ribbon group **Setting** on panel **Home**.


### 16.2.1 Results display settings

Tab **Results** has option to set colour of drawn results.




## 16.2.2 Reinforcement display settings

Tab **Reinforcement** display has an option to set the colour of the drawn reinforcement.




### 16.2.3 Cross-section display setting

Click tab **Cross-Section display** to open dialog to set the outline thickness and cross-section colour.




### 16.2.4 Text height settings

Click tab **Text** to open dialog to set the text height used for the reinforced cross-section pictures and the result drawings.



## 16.2.5 Miscellaneous



**Language of user interface** – select required language in the list. Changes are applied after restart of application

**Autohide the Unused Windows** – turns on/off automatic hiding the unused windows with empty content (Info window, Data window). The change is taken into account after restarting the application.

**Autosave** – turns on/off automatic saving of actual data in the defined time interval. Automatic saving is only possible when a file extension is set in the textbox.

**Use default decimal separator** – if the checkbox is off, decimal separator can be set in list Current decimal separator. Otherwise decimal separator specified in Regional settings is used.

**Load customer's logo** – after clicking this button it is possible to select an image file (jpg, gif) to be used on the top right corner of the report.

## 17 Format of text files for import and export

### 17.1 File TXT

To export and import cross-section and reinforcement data, text files are used. A txt file can be used to import the outline of cross-section, openings, longitudinal reinforcement, stirrups, prestressing tendons and tendon ducts.

To import a cross-section shape, one vertex of outline is defined on each line in the text file. Coordinates y and z are separated by a space. An example of the file for import of a rectangle cross-section is:

```
-150 -250  
150 -250  
150 250  
-150 250  
-150 -250
```

To import an opening, one vertex of opening is defined at each line in the text file. Coordinates y and z are separated by a space. An example of the file for import of a rectangle hole:

```
-50 -50  
50 -50  
50 50  
-50 50  
-50 -50
```

To import a longitudinal reinforcement layout, one layer is defined at each line in the text file. It is mandatory that the parameters must be defined in the following order: *numbers of bars, bar diameter, begin Y coordinate, end Y coordinate, begin Z coordinate, end Z coordinate*. An example of a file for the import of two bar layers is:

```
2 16 352 252 -352 252  
2 16 -352 -252 352 -252
```

To import a stirrups layout there is one stirrup layout definition at each line in the text file. It is mandatory that the parameters must be defined in following order: *stirrup diameter, the distance between two adjacent stirrups, take into account the torsion check (0=no, 1=yes), the radius of mandrel (multiple of stirrup diameter)*. The example of the file for the import of one stirrup is as follows:

```
10 300 1 1.30  
-365 265  
-365 -265  
365 -265
```

365 265

-365 265

To import a tendons layer defined by coordinates of first and last tendon in layer, one layer is defined at each line in the text file. It is mandatory that the parameters must be defined in the following order: *number of tendons in layer, number of strands in tendon, order of prestressing, vertical slope of tendon, horizontal slope of tendon, begin Y, begin Z, end Y, end Z, pre/post-tensioned (1=post-tensioned, 0=pre-tensioned), duct diameter, duct material (0=metal,1=plastic)*

An example of a file for the import of one layer of tendons defined by coordinates:

```
2 6 1 0.0 0.0 -120 -190 120 -190 1 33 0
```

To import a tendons layer defined at cross-section edge, one layer is defined at each line in the text file. It is mandatory that the parameters must be defined in the following order: *number of tendons in layer, number of strands in tendon, I, vertical slope of tendon, horizontal slope of tendon, order of prestressing, number of edge, edge cover, left cover, right cover, pre/post-tensioned (1=post-tensioned, 0=pre-tensioned), duct diameter, duct material (0=metal,1=plastic)*

An example of a file for the import of one layer of tendons at cross-section edge

```
2 6 1 0.0 0.0 1 1 30 30 30 1 33 0
```

To import a ducts layer defined by coordinates of first and last duct in layer, one layer is defined at each line in the text file. It is mandatory that the parameters must be defined in the following order: *number of ducts in layer, duct diameter, begin Y, begin Z, end Y, end Z, duct material (0=metal,1=plastic)*

An example of a file for the import of one layer of ducts defined by coordinates:

```
2 33 -120 -220 120 -220 0
```

To import a ducts layer defined at cross-section edge, one layer is defined at each line in the text file. It is mandatory that the parameters must be defined in the following order: *number of ducts in layer, ducts diameter, number of edge, edge cover, left cover, right cover, duct material (0=metal,1=plastic)*

An example of a file for the import of one layer of ducts at cross-section edge

```
2 33 1 4 30 30 30 0
```

## 17.2 File .NAV

.NAV file includes XML tags for the defined groups of data. File in NAV format enables to import the whole reinforced cross-section (outline, openings, longitudinal reinforcement, stirrups, tendons and tendon ducts) at once. The following tags are used:

<ReinforcedCss> </ReinforcedCss> - begin and end tag for reinforced section. It can include tags <Css>,<Bars> , <Stirrups>,<Tendons> and <TendonDucts>

**<Css> </Css>** - begin and end tag for the definition of a cross-section shape. It contains tags **<Component>** and **<Opening>**

**<Component> </Component>** - begin and end tag for the definition of one cross-section component. The content includes lines with vertex coordinates for the cross-section shape.

**<Opening> </Opening>** - begin and end tag for one opening in cross-section. The content includes lines with vertex coordinates for the opening shape.

**<Bars> </Bars>** - begin and end tag for the definition of the longitudinal reinforcement. The content includes lines with the same reinforcement bars description as defined in the TXT file.

**<Stirrups> </Stirrups>** - begin and end tag for the definition of one stirrup. It contains the tags **<DataStirrup>** and **<GeometryStirrup>**

**<DataStirrup> </DataStirrup>** - it contains the lines with the same general stirrup parameters as defined in the TXT file.

**<GeometryStirrup></GeometryStirrup>** - it contains the lines with the same vertex coordinates as defined in the TXT file

**<Tendons> </Tendons>** - begin and end tag for definition of prestressing tendons. It contains tags **<TendonsInLine>** and **</TendonsOnCssEdge>**.

**<TendonsInLine></TendonsInLine>** - contains lines with the same tendons defined by coordinates description as defined in the TXT file.

**<TendonsOnCssEdge></TendonsOnCssEdge >** - contains lines with the same tendons at cross-section edge description as defined in the TXT file.

**<TendonDucts> </TendonDucts>** - begin and end tag for definition of tendon ducts. Contains tags **<TendonDuctsInLine>** a **</TendonDuctsOnCssEdge>**.

**<TendonDuctsInLine ></TendonDuctsInLine >** - contains lines with the same ducts defined by coordinates description as defined in the TXT file.

**<TendonDuctsOnCssEdge ></TendonDuctsOnCssEdge >** - contains lines with the same ducts at cross-section edge description as defined in the TXT file.

An example of a complete reinforced cross-section exported to .NAV file is as follows:

```
<ReinforcedCss>
  <Css>
    <Component>
      -150 -250
      150 -250
      150 250
      -150 250
      -150 -250
    </Component>
    <Opening>
      -50 -50
      50 -50
      50 50
      -50 50
```



```
        -50 -50
    </Opening>
</Css>

<Bars>
    2 16 102 202 -102 202
    2 16 -102 -202 102 -202
</Bars>

<Stirrups>
    <Stirrup>
        <DataStirrup>
            10 200 1 1.30
        </DataStirrup>
        <GeometryStirrup>
            -115 215
            -115 -215
            115 -215
            115 215
            -115 215
        </GeometryStirrup>
    </Stirrup>
</Stirrups>

<Tendons>
    <TendonsInLine>
        2 6 1 0.0 0.0 -110 210 110 210 1 33
    </TendonsInLine>
    <TendonsOnCssEdge>
        2 6 1 0.0 0.0 1 1 30 30 30 1 33
    </TendonsOnCssEdge>
</Tendons>

<TendonDucts>
    <TendonDuctsOnCssEdge>
        2 1.7 1 2 80 30 30
    </TendonDuctsOnCssEdge>
</TendonDucts>
</ReinforcedCss>
```

### 17.3 Import from XML file

- **If IDEA RCS is started from superior application, import from XML is not available.**

Sections of 1D and 2D members for reinforcement design can be imported from XML file. Loads extremes can be imported too. XML file is expected to be exported from program SCIA Engineer.

Import from versions 2010.0 and higher is supported, import from version 2009 is limited.

XML document for export into IDEA RCS must contain following tables:

- Cross-sections
- Materials
- Members 1D
- Haunches (SCIA Engineer 2010 and higher)
- Arbitrary members (SCIA Engineer 2010 and higher)
- 2D members (SCIA Engineer 2010 and higher)
- Load cases
- Combinations
- Named selection (SCIA Engineer 2010 and higher)

If sections for check of 1D member or 2D members should be generated, XML document should contain following chapters, respectively:

- Internal forces on members
- Member 2D – internal forces

To generate XML file with correct content tables of appropriate XML document chapters has to be generated (adapted). Tables must fulfill rules described in following paragraphs.

Content of XML document (list of chapters) can be loaded from template files, which are included in installation package of IDEA RCS:

- \Templates\IDEA\_importRCS1D.TDX (for SCIA Engineer 2010 and higher)
- \Templates\IDEA\_importRCS1D\_2009.TDX (for SCIA Engineer 2009)

Edited templates are stored in files

- \Templates\otx\_2010.zip (for SCIA Engineer 2010 and higher)
- \Templates\otx\_2009.zip (for SCIA Engineer 2009)


Template files from the appropriate package otx\_20xx.zip have to be unpacked into the following directory:

- xxx\DocumentTemplates\xml\, where xxx is User Settings Directory of SCIA Engineer application. Default full path of this directory is eq. for SCIA Engineer 2009: c:\Users\\_user\_name\_\ESA90\user\DocumentTemplates\XML\ on Win7 and Vista, c:\Documents and Settings\\_user\_name\_\ESA90\user\DocumentTemplates\XML\ on Win XP.


### 17.3.1 Chapter Cross-sections

Import of following cross-section types is supported:

a) all cross-section from **Concrete** group are converted to standard concrete sections in IDEA RCS (can be reinforced using reinforcement templates in IDEA RCS)




b) all cross-sections from **Geometric shapes** group can be imported into IDEA RCS. Cross-sections in green frames are converted to general cross-section (cannot be reinforced using reinforcement templates), other cross-sections are converted to standard concrete cross-sections (can be reinforced using reinforcement templates)




c) all cross-sections from **Geometric shapes** group can be imported into IDEA RCS. Cross-sections are imported as general cross-sections (defined by vertexes). Cross-sections in red frames are converted to one component cross-sections, because current IDEA RCS does not support more components in cross-section. If components of imported cross-section have different materials, material from first component is used for imported cross-section.

Cross-section Double T shape (in green frame) is imported as standard Double T, provided that haunch on webs is zero.



Shapes of particular precast bridge cross-sections after import into IDEA RCS:




c) all cross-sections from **Bridge** group can be imported into IDEA RCS. Cross-sections are imported as general cross-sections (defined by vertexes).

Cross-sections in red frames are converted to one component cross-sections, because current IDEA RCS does not support more components in cross-section. If components of imported cross-section have different materials, material from first component is used for imported cross-section.


Cross-sections in dark green frames are imported as standard Double T, provided that haunches on cross-sections are zero.





Cross-section T in blue frame is imported as standard T with haunches on flange, provided that haunches on flange of imported cross-section are non-zero.






Cross-sections in light green frames are imported as standard I shape, provided that haunches are zero.




Shapes of particular bridge cross-sections after import into IDEA RCS:











d) **general cross-sections** – import of cross-sections with one component only is supported. If general cross-section contains more components, only first one is imported. Number of openings is not limited.








It is not possible to import cross-sections with curved edges, because curved edge is not described in XML file. Circular holes are not supported

Circular cross-section generated as general cross-section (consists of two arches) cannot be imported.



e) **numerical cross-sections** – import of numerical cross-sections is not supported.

Table of chapter Cross-section must contain following columns:

- **Name**
- **Type** – type of cross-section
- Items from folder **Parameters**
- **Catalog ID** – number of catalogue for catalogue cross-sections
- **CatalogItem** – number of cross-section in catalogue
- Items from folder **Fibre** – for cross-sections not supported directly in IDEA RCS, to create general cross-section using fibres
- Items from folder **Elements** – items for general cross-sections, including general cross-sections, openings and stages

It is recommended to set item **Filter** to **Used** in properties of table **Cross-sections** to export only cross-sections assigned to beams.

### 17.3.2 Chapter Materials

Only concrete is imported into IDEA RCS, reinforced steel is not imported.

Value of parameter ‚**Calculated dependent values**‘ is important during import of concrete material. It determines, whether material characteristics correspond to national code or material characteristic were edited by user.

If only code materials were used in imported project, table **Materials** must contain following columns:

- **Name**
- **Material type**
- **Calculated depended values**
- **Characteristic compressive cylinder strength fck(28)**

According those parameters is imported material compared with materials in IDEA RCS materials. If no material is found with matching name and fck(28), new one is created. But then table **Materials** must contain more columns:

- **Thermal expansion**
- **Unit mass**
- **E modulus** or **Modul E** – acc. to version of SCIA Engineer
- **G modulus**
- **Poisson coeff.**
- **Stone diameter (dg)**
- **Cement class**
- **Characteristic compressive cylinder strength fck(28)**
- **Mean compressive strength fcm(28)**
- **Mean tensile strength fctm(28)**
- **fctk 0,05(28)**
- **fctk 0,95(28)**
- **Strain at reaching maximum strength eps c2**
- **Ultimate strain eps cu2**
- **Strain at reaching maximum strength eps c3**
- **Ultimate strain eps cu3**
- **n**
- **Type of aggregate**
- **Measured values of mean compressive strength (influence of ageing)**
- **Type of diagram**

It is recommended to set item **Filter** to **Used** in properties of table **Materials** to export only materials assigned to cross-sections.

### 17.3.3 Chapter Members 1D

Table of chapter **Members** must contain columns:

- **Name**
- **Cross-section**
- **Type** – type of member – for member type in v IDEA RCS
- **Length** – length of member

For Rib member type columns

- **Alignment**
- **Shapeofrib**
- **Effectivewidth**
- Folder **Reference table**  
Columns for effective width for check (the same columns twice, because first two columns are for width input by value, second for input by multiple of slab height)
- **forcheck**
- **widthright**
- **forcheck**
- **widthright**

Import of member of type Rib is limited to rectangular cross-section. Such cross-section is imported into IDEA RCS as T shape, L shape or X shape.

If first member in SCIA Engineer project is a non-rib, it is not possible to add folder **Reference table** into **Members 1D table**. Because of that data about corresponding slab are not exported into XML file, it is not possible to get height of slab and substitutive cross-section cannot be created in IDEA RCS.

In such case warning is displayed during import and substitutive cross-section is created using height of first slab in XML file or with default height 200 mm

It is possible to set item Selection in table Members 1D to required selection of members, for which export is required. Selection of members can be set in properties of chapter **Internal forces on members** too.

#### 17.3.4 Chapter Haunches

This table must be included into XML document only for structures which contain haunches.

Table of chapter **Haunches** must contain following columns:

- Folder **Reference table**
- **Coord. definition**
- **Length x**
- **Position**
- **Cross-section**
- Folder **Parameters**

#### 17.3.5 Arbitrary members

This table must be included into XML document only for structures which contain arbitrary members.

Table of chapter **Arbitrary members** must contain following columns:

- Folder **Reference table**
- **Coord. definition**

- **Cross-section**
- Folder **Spans table**

Warning – if the field of arbitrary member contains parametric haunch, only first parameter of cross-section in field is exported. It means, that when some field contains rectangular cross-section with parameters H (height) and B (depth), only value of H parameter is exported into XML file and value of B parameter is constant over the whole length of field. When using haunch cross-sections, it is recommended to use two different sections at the beginning and at the ending of field.

### 17.3.6 2D members

This table must be included into XML document only for structures, which contain ribs.

Table of chapter 2D members must contain columns:

- **Name**
- **Thickness**
- **Material**
- **Type** – determines type of member generated in IDEA RCS according to type of 2D member in SCIA Engineer – for type Wall in SCIA Engineer type Shell-Wall is generated in IDEA RCS, for types Slab or Shell in SCIA Engineer member with type Shell-Slab is generated in IDEA RCS.

### 17.3.7 Load cases

This table is required for generation of loads extremes content in IDEA RCS.

Table **Load cases** must contain columns:

- **Name** – name of load case

### 17.3.8 Combinations

Table is required for generation of loads extremes in IDEA RCS.

Table **Combinations** must contain columns:

- **Name** – name of combination
- **Type** – type of combination, which determines type of combination generated in IDEA RCS

### 17.3.9 Named selections

Named selections defined in SCIA Engineer can be used for automatic generation of representative members in IDEA RCS.

All sections in IDEA RCS, which were generated from members in named selection, have assigned the same (representative) member

Table **Named selections** must contain columns:

- **Name** – named selection name. This name is used as name of member data in IDEA RCS
- **Selected objects (GUID.ID)** – contains content of named selection

Following rules has to be followed:

- All members in named selection must have identical parameters. Members must have identical cross-section and length and must be of the same type (column, beam, rib). If the members contain haunch or arbitrary section, this data must be in named selection identical too.
- One member can be only in one named selection.

### 17.3.10 General rules used when converting internal forces to loads extremes in IDEA RCS

XML document may contain more chapters Internal forces on member or Members 2D – internal forces. Each chapter should represent other type of combination to import forces into IDEA RCS.

To import content of all combinations required in IDEA RCS, XML document should contain three chapters Internal forces on members (or Members 2D – internal forces). Particular chapters should have assigned following combinations:

- One (ULS combination
- One SLS-Quasi permanent combination
- One SLS-Characteristics permanent combination

If results are exported for load cases, result classes or more combinations of the same type, it is not possible to assign type of combination from SCIA Engineer to type of combination in IDEA RCS automatically. In this case dialog appears, in which exported results can be assigned to IDEA RCS combinations.

General rules for possible assignment of imported results to combinations:

- ULS combination in IDEA RCS – load cases, result classes, ULS combinations from SCIA Engineer
- SLS characteristics combination in IDEA RCS – SLS combinations except SLS EN Quasi-permanent from SCIA Engineer
- SLS Quasi-permanent in IDEA RCS – SLS combination except SLS EN Characteristics

More combinations from SCIA Engineer can be assigned to one combination type in IDEA RCS. Results from all assigned combinations are imported than.

If XML document contains more results – e.g. for ULS, SLS Quasi-permanent and SLS-Characteristics, the same selection of members and mode of extreme evaluation should be set for all of them. If selections and extreme evaluation are not the same, results from differing combinations are not imported.

Example of generated sections in IDA Concrete according to settings in XML document

- one chapter with results on member for combination ULS with results on member B1 in positions 0 and 10
- second chapter with results on member for combination SLS Characteristics with results on member B1 in positions 0 and 4
- third chapter with results for combination SLS Quasi-Permanent and results on member B, positions 0 and 4

For such defined result chapters following sections are generated in IDEA RCS:

- B1 in position 0, forces are imported for ULS and SLS Characteristics. Forces for SLS Quasi-permanent are zero.
- B1 in position 4, forces are imported only for SLS Characteristics
- B1 in position 10, forces are imported only for ULS
- B2 in position 0, forces are imported only for SLS Quasi-permanent
- B2 in position 4, forces are imported only for SLS Quasi-permanent

Generation of loads extremes for one section works in similar way. If more results are found for one combination in one position on member, the required number of loads extremes is generated

Example:

- 4 result tables are present in XML document with identical selection of members, identical section, following results are on member B1 in position 0:
  - ULS – for combination C01/1, C01/2
  - SLS Characteristics – for combination C02/1, C02/2, C02/3, C02/4
  - SLS Quasi-permanent – for combination C03/1, C03/2, C03/3
  - LC1 – load case
- IDEA RCS generates section with 4 loads extremes, with combinations in order for ULS, SLS Characteristics, SLS Quasi-permanent:
  - C01/1, C02/1, C03/1
  - C01/2, C02/2, C03/2
  - LC1/1, C02/3, C03/3
  - xxx, C02/4, xxx – where xxx means, that forces in this combination are zero

Example of 2D sections generation in IDEA RCS according to settings in XML document:

- XML file contains 3 chapters with results on slabs, property **Extreme** of result tables is set to No (all results are exported)
- The first chapter for combination C01 for ULS has property **Position** set to **In centre**, it means that for each finite element two values are exported –minimal and maximal value of combination
- The second chapter for combination C02 for SLS Characteristics has property Position set to **In nodes, no average** – it means that for each finite element 8 (or 6 for

triangular finite element) values are exported, 2 values (minimum and maximum) for each node (4 nodes on rectangular, 3 on triangular finite element)

- The third chapter for combination C03 for SLS Quasi-permanent has property Position set to **In nodes, average**. Table does not contain numbers of finite elements, but numbers of nodes, e.g. for node N1 table contains two values.
- IDEA RCS generates one section with 8 loads extremes for finite element
  - First two loads extremes contain results for ULS combination imported from combination C01 and for SLS Characteristics imported from C0.
  - There are no results for ULS in following extremes, so only forces for SLS Characteristics are imported.
  - Because results for SLS Quasi-permanent were exported for position In nodes, average, it is not possible import values for this combination into section for finite element.
- IDEA RCS than generates section for node N1
  - Into section generated for node cannot be imported results, which were exported for finite element. So in this example results from combinations C01 and C02 cannot be imported.
  - Two loads extremes are generated for node N1. Only values of forces for SLS Quasi-permanent are imported from combination C03, other load effects are zero.

### 17.3.11 Internal forces on members

Following options can be set in properties of chapter Internal forces on members:

- **Selection** – set selection of members, for which results are exported.  
Remark: An intersection of selections in chapters Members and Internal forces is performed during export. It means that if there are members B1 and B2 selected in chapter Members and B2 and B3 are selected in chapter Internal forces on members, only member B2 is imported into IDEA RCS.
- **Type of loads** – set type of evaluated load
- **Rib** – has to be checked for export of ribs
- **Values** – internal forces to be exported  
Remark: if e.g. component My is selected in the list of internal forces, it does not mean that only My is exported. This setting affects only drawing of internal forces, but all result components are exported. But if item More components is set and for this item only component My is selected, really only My is exported and other components of internal forces are zero after import into IDEA RCS.
- **System** – must be set to **LCS**, to have the same convention of internal forces in SCIA Engineer and IDEA RCS.
- **Extreme** – set mode of extremes evaluation. This mode affects number of generated sections in IDEA RCS.

### 17.3.12 Member 2D – internal forces

Table with internal forces on members 2D must contain following columns

- **Member** – name of slab
- **Case** – name of evaluated case/combi/result class
- **Section**
- **dx**
- **Node**
- **X, Y, Z**
- **Elem** – number of finite element
- **mx, my, mxy, vx, vy, nx, ny, nxy** – particular components of internal forces on slab

Following options can be set in properties of chapter 2D member - internal forces:

- **System : Local** – ensures, that forces and their directions corresponds with directions of slab. It is possible to use any direction of forces, but it must be kept in mind, for which direction forces were exported. The original direction of forces cannot be traced in IDEA RCS.
- **Type forces** – must be set to **Basic magnitudes**
- **Envelope** – has no sense in XML document, minimal and maximal values are always exported
- **Extreme** – set mode of extremes evaluation. This mode affects number of generated sections in IDEA RCS.
- **Location** – set mode of internal forces evaluation. It is possible to evaluate forces for different locations, internal forces are exported to IDEA RCS according to current setting of **Location**

In general it should be ensured, that when exporting more result chapters together (e.g. one slab, but one combination ULS and all SLSL), Location should be set to be the same for all result chapters. It is not required, but if it is not kept, results can be mismatched.

When export to XML is finished, it is not possible to determine the original setting of Location property. It is only possible to distinguish between results averaged to nodes and other results, because results table contains column Node and for other setting of **Location** the table contains column Element.