



FRAMING CONFIGURATION – Common Settings – Modify Settings

Modified on: Mon, 4 Jan, 2021 at 8:57 PM


Framing Configuration may be found in two locations:



or:



Modify Settings



Modify Settings – advanced settings that are applied to all configuration names, regardless of which configuration name is selected.

Read more about every feature here >> (<https://agacad.freshdesk.com/support/solutions/articles/44002139159-framing-configuration-%E2%80%93-modify-settings>).