



FRAMING CONFIGURATION – Secondary Joist

Modified on: Thu, 7 Jan, 2021 at 8:13 PM


Framing Configuration may be found in two locations:



OR:



Secondary Joist



Secondary Joist – settings to add secondary joist system. It has the same settings as **Bridging/Nogging**.

