



FRAMING CONFIGURATION – Joist Holes

Modified on: Fri, 8 Jan, 2021 at 7:42 PM

Framing Configuration may be found in two locations:





OR:



Joist Holes

Joist Holes – allows distributing service holes on joists according to predefined insertion rules.



[Read more about every feature here >>](https://agacad.freshdesk.com/support/solutions/articles/44002140169-framing-configuration-%E2%80%93-stud-joist-holes) (https://agacad.freshdesk.com/support/solutions/articles/44002140169-framing-configuration-%E2%80%93-stud-joist-holes)