



# FRAMING CONFIGURATION – Edge Joist

Modified on: Mon, 11 Jan, 2021 at 8:18 PM


Framing Configuration may be found in two locations:




OR:



## Ridge Stud



**Ridge Stud** – settings to insert studs for different ridges.



[Read more about every feature here >>](https://agacad.freshdesk.com/support/solutions/articles/44002139406-rigde-stud-joist) (<https://agacad.freshdesk.com/support/solutions/articles/44002139406-rigde-stud-joist>).

