



# FRAMING CONFIGURATION – Secondary Joist

Modified on: Tue, 12 Jan, 2021 at 7:55 PM


Framing Configuration may be found in two locations:



OR:



## Secondary Joist



**Secondary Joist** – settings to add secondary joist system. It has the same settings as **Horizontal Joist/Rafter/Bridging**.

