



# FRAMING CONFIGURATION – Joist Holes

Modified on: Tue, 12 Jan, 2021 at 8:32 PM

Framing Configuration may be found in two locations:





OR:



## Joist Holes

**Joist Holes** – allows distributing service holes on joists according to predefined insertion rules.



[Read more about every feature here >>](https://agacad.freshdesk.com/support/solutions/articles/44002140169-framing-configuration-%E2%80%93-stud-joist-holes) (<https://agacad.freshdesk.com/support/solutions/articles/44002140169-framing-configuration-%E2%80%93-stud-joist-holes>)

