



FRAMING CONFIGURATION – Common Settings – Modify Settings

Modified on: Sun, 27 Dec, 2020 at 7:10 PM


Framing Configuration may be found in two locations:



OR:



Modify Settings



Modify Settings - advanced settings that are applied to all configuration names, regardless of which configuration name is selected.

Read more here >> (<https://agacad.freshdesk.com/support/solutions/articles/44002139159-modify-settings>).