MULTI-FRAMING


Modified on: Wed, 4 Sep, 2019 at 7:47 PM

Multi-Framing

Frame Wall Bracing	Update Frame	• • • • • • • • • • • • • • • • • • •	Split Parts	Number Elements	Create Assembly	 Link Wall Configs • Settings •
Validate Walls]	Wall+M				
Number Walls						
Framing Configuration						
Frame Wall						
Add Secondary Frame						
Add Siding						
Frame Additional Layers						
Multi-Framing						

Multi-Framing features work extremely well in big projects, like multi-storey houses.


An additional window opens that contains tools for multi-framing tasks. Multi-Framing is used when there are groups or identical walls in a given project. Using Multi-Framing tools you can easily transfer framing elements between identical walls and update them automatically.



Filtering Rules in Model Groups

🖽 Wall+M. Multi-Framing 🛛 🗙
✓ Model Group Type affects Wall's Identity
Model Group Instance affects Wall's Identity
All Walls are Unique in Model Group
Copy/Update Frames in Model Groups
Copy/Update Frame in Model Groups
Select Walls in Model Group
Delete Frames in Model Groups
Show Identical Walls
Copy/Update Frames in Identical Walls
Frame and Copy/Update in Identical Walls
Update Frames in Identical Walls
Update Frames by Wall Link in Identical Walls
Delete Frames in Identical Walls
Isolate Selected Walls
Unhide Walls
Create Assemblies for Identical Walls
Disassemble Assemblies for Identical Walls
Show Primary Assembly
Show Primary & Secondary Assemblies

Filtering rules for work with walls from model groups. **Model Groups** should be created using Revit's **Create Group** function.




Model Group Type affects Wall's Identity

🖽 Wall+. Multi-Framing	×
Model Group Type affects Wall's Identity	
Model Group Instance affects Wall's Identity	
All Walls are Unique in Model Group	
Copy/Update Frames in Model Groups	
Copy/Update Frame in Model Groups	
Select Walls in Model Group	
Delete Frames in Model Groups	
Show Identical Walls	
Copy/Update Frames in Identical Walls	
Frame and Copy/Update in Identical Walls	
Update Frames in Identical Walls	
Update Frames by Wall Link in Identical Walls	
Delete Frames in Identical Walls	
Isolate Selected Walls	
Unhide Walls	
Create Assemblies for Identical Walls	
Disassemble Assemblies for Identical Walls	
Show Primary Assembly	
Show Primary & Secondary Assemblies	

Model Group Type affects Wall's Identity – sets filtering rules if wall's identity is affected by Model Group type. If ticked, only identical walls of the same Model Group type will be treated as the same wall.

Example: Identical walls are selected from the same model group type.




Model Group Instance affects Wall's Identity

🖾 Wall+. Multi-Framing	\times
Model Group Type affects Wall's Identity	
 Model Group Instance affects Wall's Identity 	
All Walls are Unique in Model Group	
Copy/Update Frames in Model Groups	
Copy/Update Frame in Model Groups	
Select Walls in Model Group	
Delete Frames in Model Groups	
Show Identical Walls	
Copy/Update Frames in Identical Walls	
Frame and Copy/Update in Identical Walls	
Update Frames in Identical Walls	
Update Frames by Wall Link in Identical Walls	
Delete Frames in Identical Walls	
Isolate Selected Walls	
Unhide Walls	
Create Assemblies for Identical Walls	
Disassemble Assemblies for Identical Walls	
Show Primary Assembly	
Show Primary & Secondary Assemblies	

Model Group Instance affects Wall's Identity – sets filtering rules if Wall's identity is affected by Model Group instance (only selected Model Group).

Example: Identical walls are selected from the selected model group instance.




All Walls are Unique in Model Group

 Model Group Type affects Wall's Identity Model Group Instance affects Wall's Identity All Walls are Unique in Model Group Copy/Update Frames in Model Groups Select Walls in Model Group Delete Frames in Model Groups Show Identical Walls Copy/Update Frames in Identical Walls Frame and Copy/Update in Identical Walls Update Frames in Identical Walls Delete Frames in Identical Walls Create Assemblies for Identical Walls Disassemble Assemblies for Identical Walls 	🕮 Wall+. Multi-Framing	×
All Walls are Unique in Model Group Copy/Update Frames in Model Groups Copy/Update Frame in Model Groups Select Walls in Model Group Delete Frames in Model Groups Show Identical Walls Copy/Update Frames in Identical Walls Frame and Copy/Update in Identical Walls Update Frames in Identical Walls Update Selected Walls Unhide Walls Create Assemblies for Identical Walls Disassemble Assemblies for Identical Walls		
Copy/Update Frames in Model Groups Copy/Update Frame in Model Groups Select Walls in Model Group Delete Frames in Model Groups Show Identical Walls Copy/Update Frames in Identical Walls Frame and Copy/Update in Identical Walls Update Frames in Identical Walls Update Frames in Identical Walls Delete Frames in Identical Walls Delete Frames in Identical Walls Isolate Selected Walls Unhide Walls Create Assemblies for Identical Walls Disassemble Assemblies for Identical Walls		
Copy/Update Frame in Model Groups Select Walls in Model Group Delete Frames in Model Groups Show Identical Walls Copy/Update Frames in Identical Walls Frame and Copy/Update in Identical Walls Update Frames in Identical Walls Update Frames by Wall Link in Identical Walls Delete Frames in Identical Walls Isolate Selected Walls Unhide Walls Create Assemblies for Identical Walls Disassemble Assemblies for Identical Walls	All Walls are Unique in Model Group	
Select Walls in Model Group Delete Frames in Model Groups Show Identical Walls Copy/Update Frames in Identical Walls Frame and Copy/Update in Identical Walls Update Frames in Identical Walls Update Frames by Wall Link in Identical Walls Delete Frames in Identical Walls Isolate Selected Walls Unhide Walls Create Assemblies for Identical Walls Disassemble Assemblies for Identical Walls	Copy/Update Frames in Model Groups	
Delete Frames in Model Groups Show Identical Walls Copy/Update Frames in Identical Walls Frame and Copy/Update in Identical Walls Update Frames in Identical Walls Update Frames by Wall Link in Identical Walls Delete Frames in Identical Walls Isolate Selected Walls Unhide Walls Create Assemblies for Identical Walls Disassemble Assemblies for Identical Walls	Copy/Update Frame in Model Groups	
Show Identical Walls Copy/Update Frames in Identical Walls Frame and Copy/Update in Identical Walls Update Frames in Identical Walls Update Frames by Wall Link in Identical Walls Delete Frames in Identical Walls Isolate Selected Walls Unhide Walls Create Assemblies for Identical Walls Disassemble Assemblies for Identical Walls	Select Walls in Model Group	
Copy/Update Frames in Identical Walls Frame and Copy/Update in Identical Walls Update Frames in Identical Walls Update Frames by Wall Link in Identical Walls Delete Frames in Identical Walls Isolate Selected Walls Unhide Walls Create Assemblies for Identical Walls Disassemble Assemblies for Identical Walls	Delete Frames in Model Groups	
Frame and Copy/Update in Identical Walls Update Frames in Identical Walls Update Frames by Wall Link in Identical Walls Delete Frames in Identical Walls Isolate Selected Walls Unhide Walls Create Assemblies for Identical Walls Disassemble Assemblies for Identical Walls	Show Identical Walls	
Update Frames in Identical Walls Update Frames by Wall Link in Identical Walls Delete Frames in Identical Walls Isolate Selected Walls Unhide Walls Create Assemblies for Identical Walls Disassemble Assemblies for Identical Walls	Copy/Update Frames in Identical Walls	
Update Frames by Wall Link in Identical Walls Delete Frames in Identical Walls Isolate Selected Walls Unhide Walls Create Assemblies for Identical Walls Disassemble Assemblies for Identical Walls	Frame and Copy/Update in Identical Walls	
Delete Frames in Identical Walls Isolate Selected Walls Unhide Walls Create Assemblies for Identical Walls Disassemble Assemblies for Identical Walls	Update Frames in Identical Walls	
Isolate Selected Walls Unhide Walls Create Assemblies for Identical Walls Disassemble Assemblies for Identical Walls	Update Frames by Wall Link in Identical Walls	
Unhide Walls Create Assemblies for Identical Walls Disassemble Assemblies for Identical Walls	Delete Frames in Identical Walls	
Create Assemblies for Identical Walls Disassemble Assemblies for Identical Walls	Isolate Selected Walls	
Disassemble Assemblies for Identical Walls	Unhide Walls	
	Create Assemblies for Identical Walls	
Show Primary Assembly	Disassemble Assemblies for Identical Walls	
show i filling reactiony	Show Primary Assembly	
Show Primary & Secondary Assemblies	Show Primary & Secondary Assemblies	

All Walls are Unique in Model Group – lets you treat each Wall Framing individually. This function is recommended when some identical walls in Model Group need to be framed differently.

Example: Only one wall is selected from model group, which will have unique framing




Copy/Update Frames in Model Groups

🖾 Wall+. Multi-Framing	\times
✔ Model Group Type affects Wall's Identity	
Model Group Instance affects Wall's Identity	
All Walls are Unique in Model Group	
Copy/Update Frames in Model Groups	
Copy/Update Frame in Model Groups	
Select Walls in Model Group	
Delete Frames in Model Groups	
Show Identical Walls	
Copy/Update Frames in Identical Walls	
Frame and Copy/Update in Identical Walls	
Update Frames in Identical Walls	
Update Frames by Wall Link in Identical Walls	
Delete Frames in Identical Walls	
Isolate Selected Walls	
Unhide Walls	
Create Assemblies for Identical Walls	
Disassemble Assemblies for Identical Walls	
Show Primary Assembly	
Show Primary & Secondary Assemblies	

Copy/Update Frame in Model Groups – copies and/or updates all frames from selected Model Group into identical walls from the same Model Groups.

MULTI-FRAMING : AGACAD

This feature helps save time because you will not need to frame walls from the same model groups individually. You just need to frame walls from one group and then, using this feature, copy/update it to other identical walls from the same groups.




Copy/Update Frame in Model Groups

🖾 Wall+. Multi-Framing	<
Model Group Type affects Wall's Identity Model Group Instance affects Wall's Identity	
All Walls are Unique in Model Group	
Copy/Update Frames in Model Groups	
Copy/Update Frame in Model Groups	
Select Walls in Model Group	
Delete Frames in Model Groups	
Show Identical Walls	
Copy/Update Frames in Identical Walls	
Frame and Copy/Update in Identical Walls	
Update Frames in Identical Walls	
Update Frames by Wall Link in Identical Walls	
Delete Frames in Identical Walls	
Isolate Selected Walls	
Unhide Walls	
Create Assemblies for Identical Walls	
Disassemble Assemblies for Identical Walls	
Show Primary Assembly	_
Show Primary & Secondary Assemblies	

Copy/Update Frame in Model Groups – copies (and/or updates) selected frame into identical walls from the same Model Groups.

MULTI-FRAMING : AGACAD

This feature helps save time because you will not need to frame walls from same model groups individually. You just need to frame one wall from one group and then, using this feature, copy/update it to other identical walls from the same groups.




Select Walls in Model Group

🖽 Wall+. Multi-Framing	×
✔ Model Group Type affects Wall's Identity	
Model Group Instance affects Wall's Identity	
All Walls are Unique in Model Group	
Copy/Update Frames in Model Groups	
Copy/Update Frame in Model Groups	
Select Walls in Model Group	
Delete Frames in Model Groups	
Show Identical Walls	
Copy/Update Frames in Identical Walls	
Frame and Copy/Update in Identical Walls	
Update Frames in Identical Walls	
Update Frames by Wall Link in Identical Walls	
Delete Frames in Identical Walls	
Isolate Selected Walls	
Unhide Walls	
Create Assemblies for Identical Walls	
Disassemble Assemblies for Identical Walls	
Show Primary Assembly	
Show Primary & Secondary Assemblies	

Select Walls in Model Group – selects all walls from selected Model Group.


After selecting walls, you can frame walls using Frame Wall feature.



Delete Frames in Model Group

🖾 Wall+. Multi-Framing 🛛 🗙	
✔ Model Group Type affects Wall's Identity	
Model Group Instance affects Wall's Identity	
All Walls are Unique in Model Group	
Copy/Update Frames in Model Groups	
Copy/Update Frame in Model Groups	
Select Walls in Model Group	
Delete Frames in Model Groups	
Show Identical Walls	
Copy/Update Frames in Identical Walls	
Frame and Copy/Update in Identical Walls	
Update Frames in Identical Walls	
Update Frames by Wall Link in Identical Walls	
Delete Frames in Identical Walls	
Isolate Selected Walls	_
Unhide Walls	
Create Assemblies for Identical Walls	_
Disassemble Assemblies for Identical Walls	
Show Primary Assembly	_
Show Primary & Secondary Assemblies	

Delete Frames in Model Group – deletes all frames from identical Model Groups.




Show Identical Walls

🖽 Wall+. Multi-Framing	\times
✔ Model Group Type affects Wall's Identity	
Model Group Instance affects Wall's Identity	
All Walls are Unique in Model Group	
Copy/Update Frames in Model Groups	
Copy/Update Frame in Model Groups	
Select Walls in Model Group	
Delete Frames in Model Groups	
Show Identical Walls	
Copy/Update Frames in Identical Walls	
Frame and Copy/Update in Identical Walls	
Update Frames in Identical Walls	
Update Frames by Wall Link in Identical Walls	
Delete Frames in Identical Walls	
Isolate Selected Walls	
Unhide Walls	
Create Assemblies for Identical Walls	
Disassemble Assemblies for Identical Walls	
Show Primary Assembly	
Show Primary & Secondary Assemblies	

Show Identical Walls - selects and shows identical walls in the project according to Model Group filtering rules.

Identical walls are those walls that are identical according to their geometry.



Copy/Update Frames in Identical Walls


83	Wall+. Multi-Framing	\times
•	Model Group Type affects Wall's Identity	
	Model Group Instance affects Wall's Identity	
	All Walls are Unique in Model Group	
	Copy/Update Frames in Model Groups	
	Copy/Update Frame in Model Groups	
	Select Walls in Model Group	
	Delete Frames in Model Groups	
	Show Identical Walls	
	Copy/Update Frames in Identical Walls	
	Frame and Copy/Update in Identical Walls	
	Update Frames in Identical Walls	
	Update Frames by Wall Link in Identical Walls	
	Delete Frames in Identical Walls	
	Isolate Selected Walls	
	Unhide Walls	
	Create Assemblies for Identical Walls	
	Disassemble Assemblies for Identical Walls	
	Show Primary Assembly	
	Show Primary & Secondary Assemblies	

Copy/Update Frames in Identical Walls – copies selected Frame or Secondary Frame into identical walls and/or updates existing Frame of identical walls. All changes will be transferred and overwritten according to the filtering rules.

Identical walls can be in the group or not.

MULTI-FRAMING : AGACAD

This function is recommended when a primary wall is framed (with all additional elements if needed) and all identical walls need to be framed according to the primary wall.




Frame and Copy/Update in Identical Walls


🖽 Wall+. Multi-Framing	×
✔ Model Group Type affects Wall's Identity	
Model Group Instance affects Wall's Identity	
All Walls are Unique in Model Group	
Copy/Update Frames in Model Groups	
Copy/Update Frame in Model Groups	
Select Walls in Model Group	
Delete Frames in Model Groups	
Show Identical Walls	
Copy/Update Frames in Identical Walls	
Frame and Copy/Update in Identical Walls	
Update Frames in Identical Walls	
Update Frames by Wall Link in Identical Walls	
Delete Frames in Identical Walls	
Isolate Selected Walls	
Unhide Walls	
Create Assemblies for Identical Walls	
Disassemble Assemblies for Identical Walls	
Show Primary Assembly	
Show Primary & Secondary Assemblies	

Frame and Copy/Update in Identical Walls – frames selected wall according to its Framing Configuration and then copies selected wall's Frame into identical walls and/or replaces existing Frame of identical walls. All framing elements will be transferred and overwritten according to filtering rules.

Identical walls can be in the group or not.

This function is recommended when all identical walls have to be framed only according to the **Framing Configuration** and manually-placed elements or modifications are not needed.






Update Frames in Identical Walls

🖽 Wall+. Multi-Framing	\times
✔ Model Group Type affects Wall's Identity	
Model Group Instance affects Wall's Identity	
All Walls are Unique in Model Group	
Copy/Update Frames in Model Groups	
Copy/Update Frame in Model Groups	
Select Walls in Model Group	
Delete Frames in Model Groups	
Show Identical Walls	
Copy/Update Frames in Identical Walls	
Frame and Copy/Update in Identical Walls	
Update Frames in Identical Walls	
Update Frames by Wall Link in Identical Walls	
Delete Frames in Identical Walls	
Isolate Selected Walls	
Unhide Walls	
Create Assemblies for Identical Walls	
Disassemble Assemblies for Identical Walls	
Show Primary Assembly	
Show Primary & Secondary Assemblies	

MULTI-FRAMING : AGACAD

Update Frames in Identical Walls – updates all framing elements in identical walls according to the changes that were made to framing elements of the selected wall. All framing elements will update according to filtering rules.

Identical walls can be in the group or by themselves.




Update Frames by Wall Link in Identical Walls

🛙 Wall+. Multi-Framing >	<
✔ Model Group Type affects Wall's Identity	
Model Group Instance affects Wall's Identity	
All Walls are Unique in Model Group	
Copy/Update Frames in Model Groups	
Copy/Update Frame in Model Groups	
Select Walls in Model Group	
Delete Frames in Model Groups	
Show Identical Walls	
Copy/Update Frames in Identical Walls	
Frame and Copy/Update in Identical Walls	
Update Frames in Identical Walls	
Update Frames by Wall Link in Identical Walls	
Delete Frames in Identical Walls	
Isolate Selected Walls	
Unhide Walls	
Create Assemblies for Identical Walls	
Disassemble Assemblies for Identical Walls	
Show Primary Assembly	
Show Primary & Secondary Assemblies	

Update Frames by Wall Link in Identical Walls – updates all framing elements in identical walls according to **Framing Configuration** of the selected wall in **Wall Link** assignment. All framing elements will be transferred and overwritten according to filtering rules.


Identical walls can be in the group or by themselves.



Delete Frame in Identical Walls

🖽 Wa	all+. Multi-Framing	\times
✔ Mo	odel Group Type affects Wall's Identity	
Mo	odel Group Instance affects Wall's Identity	
	Walls are Unique in Model Group	
Сој	py/Update Frames in Model Groups	
Co	py/Update Frame in Model Groups	
Sel	lect Walls in Model Group	
Del	lete Frames in Model Groups	
Sho	ow Identical Walls	
Co	py/Update Frames in Identical Walls	
Fra	ame and Copy/Update in Identical Walls	
Up	date Frames in Identical Walls	
Up	date Frames by Wall Link in Identical Walls	
De	lete Frames in Identical Walls	
lso	late Selected Walls	
Un	hide Walls	
Cre	eate Assemblies for Identical Walls	
Dis	sassemble Assemblies for Identical Walls	
Sho	ow Primary Assembly	
Sho	ow Primary & Secondary Assemblies	

Delete Frames in Identical Walls – deletes all framing elements in the selected wall and walls identical to it. Framing will be deleted in accordance with filtering rules.




Isolate Selected Walls

	Wall+. Multi-Framing	\times
✓	Model Group Type affects Wall's Identity	
	Model Group Instance affects Wall's Identity	
	All Walls are Unique in Model Group	
	Copy/Update Frames in Model Groups	
	Copy/Update Frame in Model Groups	
	Select Walls in Model Group	
	Delete Frames in Model Groups	
	Show Identical Walls	
	Copy/Update Frames in Identical Walls	
	Frame and Copy/Update in Identical Walls	
	Update Frames in Identical Walls	
	Update Frames by Wall Link in Identical Walls	
	Delete Frames in Identical Walls	
	Isolate Selected Walls	
	Unhide Walls	
	Create Assemblies for Identical Walls	
	Disassemble Assemblies for Identical Walls	
	Show Primary Assembly	
	Show Primary & Secondary Assemblies	

Isolate Selected Walls – isolates selected walls, including frames in the active view. All other elements will be permanently hidden in the active view.

To restore hidden elements, use Unhide Walls function.



Create Assemblies for Identical Walls

888 ∖	Nall+. Multi-Framing	\times
 N 	Nodel Group Type affects Wall's Identity	
N	Nodel Group Instance affects Wall's Identity	
A	Il Walls are Unique in Model Group	
C	Copy/Update Frames in Model Groups	
C	Copy/Update Frame in Model Groups	
S	elect Walls in Model Group	
C	Delete Frames in Model Groups	
S	how Identical Walls	
C	Copy/Update Frames in Identical Walls	
F	rame and Copy/Update in Identical Walls	
ι	Jpdate Frames in Identical Walls	
ι	Jpdate Frames by Wall Link in Identical Walls	
C	Delete Frames in Identical Walls	
ls	solate Selected Walls	
ι	Jnhide Walls	
C	Create Assemblies for Identical Walls	
C	Disassemble Assemblies for Identical Walls	
S	how Primary Assembly	
S	how Primary & Secondary Assemblies	

MULTI-FRAMING : AGACAD

Create Assemblies for Identical Walls – finds identical walls from the project and creates assembly, which contains user-predefined shop drawings, including schedules and sheets. One assembly is primary, which can be modified and updated; others are secondary.



Disassemble Assemblies for Identical Walls


🖾 Wall+. Multi-Framing	\times
✔ Model Group Type affects Wall's Identity	
Model Group Instance affects Wall's Identity	
All Walls are Unique in Model Group	
Copy/Update Frames in Model Groups	
Copy/Update Frame in Model Groups	
Select Walls in Model Group	
Delete Frames in Model Groups	
Show Identical Walls	
Copy/Update Frames in Identical Walls	
Frame and Copy/Update in Identical Walls	
Update Frames in Identical Walls	
Update Frames by Wall Link in Identical Walls	
Delete Frames in Identical Walls	
Isolate Selected Walls	
Unhide Walls	
Create Assemblies for Identical Walls	
Disassemble Assemblies for Identical Walls	
Show Primary Assembly	
Show Primary & Secondary Assemblies	

Disassemble Assemblies for Identical Walls – finds identical assemblies in the project and disassembles them.


Show Primary Assembly

🖾 Wall+. Multi-Framing	\times
Model Group Type affects Wall's Identity	
Model Group Instance affects Wall's Identity	
All Walls are Unique in Model Group	
Copy/Update Frames in Model Groups	
Copy/Update Frame in Model Groups	
Select Walls in Model Group	
Delete Frames in Model Groups	
Show Identical Walls	
Copy/Update Frames in Identical Walls	
Frame and Copy/Update in Identical Walls	
Update Frames in Identical Walls	
Update Frames by Wall Link in Identical Walls	
Delete Frames in Identical Walls	
Isolate Selected Walls	
Unhide Walls	
Create Assemblies for Identical Walls	
Disassemble Assemblies for Identical Walls	
Show Primary Assembly	
Show Primary & Secondary Assemblies	

Show Primary Assembly – selects and shows primary assembly so that it can be modified/updated if needed.



Show Primary & Secondary Assemblies



Show Primary & Secondary Assemblies – selects and shows primary and secondary assemblies so that they can be found and checked in a big project.

