



FRAMING CONFIGURATION – Dialog


Modified on: Sun, 3 Jan, 2021 at 8:25 PM

Framing Configuration Dialog




OR:





Framing Configuration – defines all framing settings. It allows user to configure and save settings for all sorts of frames – **Main Floor Frame, Secondary Frames, Battens, Flooring**. It is very a versatile tool with thousands of possibilities.

Main Divisions



The **Framing Configuration** dialog is divided into three main parts: **Top (1), Left (2), and Right (3)**.

In the Top part, choose the **Configuration Type** that you want to use and **Configuration Name** that you want to modify.

The Left part lets you select the framing type going in an easy top-to-bottom direction. In the Right part are the settings.

Material Class – defines material. **Wood Framing Floor+** (<http://www.aga-cad.com/products/bim-solutions/wood-framing-floor>), uses Wood and **Metal Framing Floor+** (<http://www.aga-cad.com/products/bim-solutions/metal-framing-floor>), uses Metal/Steel.

Material Class:	Steel
-----------------	-------