


Recalculate Assemblies

Modified on: Fri, 12 Jun, 2020 at 10:46 AM



Recalculate Assemblies – recalculates Gravity Point position of Smart Assembly and moves it to the updated place if necessary.

Views are not updated.

Recalculate Assembly will also change Smart Assembly name to the main element Mark value. If there is already an Assembly with that name, naming will follow last Assembly naming logic.

