



# FRAMING CONFIGURATION – Common Settings – Modify Configuration Settings

Modified on: Sun, 3 Jan, 2021 at 8:52 PM


**Framing Configuration** may be found in two locations:



OR:



## Modify Configuration Settings



**Modify Configuration Settings** – tab with advanced settings for the selected configuration name.

**[Read more about every feature here >>](https://agacad.freshdesk.com/support/solutions/articles/44002139157-modify-configuration-settings)** (<https://agacad.freshdesk.com/support/solutions/articles/44002139157-modify-configuration-settings>).