

Delete Rebars

Modified on: Mon, 28 Oct, 2019 at 12:15 PM

Deletes all reinforcement hosted in the wall.

