



# FRAMING CONFIGURATION – Common Settings – Modify Settings

Modified on: Sat, 9 Jan, 2021 at 8:23 PM


Framing Configuration may be found in two locations:



OR:



## Modify Settings



**Modify Settings** - advanced settings that are applied to all configuration names, regardless of which configuration name is selected.

[Read more about every feature here >>](https://agacad.freshdesk.com/support/solutions/articles/44002139159-modify-settings) (<https://agacad.freshdesk.com/support/solutions/articles/44002139159-modify-settings>)