



FRAMING CONFIGURATION – Brace

Modified on: Sat, 2 Jan, 2021 at 7:41 PM


Framing Configuration may be found in two locations:




OR:




Brace



Brace – settings where you can predefine rules for adding wood or metal regular braces, corner braces, or brace groups.



Braces can be added after **Wall+** → **Add/Modify Bracing**:



[Read more about every feature here >> \(https://agacad.freshdesk.com/support/solutions/articles/44002140168-framing-configuration-%E2%80%93-brace\)](https://agacad.freshdesk.com/support/solutions/articles/44002140168-framing-configuration-%E2%80%93-brace)